Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER AC-DC Power Adapter

PKPOWER AC-DC Power Adapter

User Manual for ProForm 8.0 EX Bike PFEX14914 and 14.0 EX Bike PFEX17914

1. Introduction

Thank you for choosing the PKPOWER AC-DC Power Adapter. This adapter is designed to provide reliable power to your ProForm 8.0 EX Bike (Model PFEX14914) and ProForm 14.0 EX Bike (Model PFEX17914). Please read this manual carefully before use to ensure proper operation and safety.

2. Safety Information

Always observe the following safety precautions to prevent injury or damage to the product and connected devices:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or modify the adapter. This will void the warranty and may cause electrical shock or fire.
- Ensure the power outlet voltage matches the adapter's input voltage (AC 100-240V).
- Avoid placing heavy objects on the power cord.
- Unplug the adapter from the power outlet when not in use for extended periods.
- This adapter features OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), and SCP (Short Circuit Output Protection) for enhanced safety.

3. Package Contents

Verify that all items are present in your package:

- 1 x PKPOWER AC-DC Power Adapter

4. Setup

Follow these steps to set up your power adapter:

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Locate the power input port on your ProForm 8.0 EX Bike (PFEX14914) or 14.0 EX Bike (PFEX17914). Insert the barrel connector of the PKPOWER adapter firmly into this port.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard AC 100-240V wall outlet. Ensure

the connection is secure.



Image 1: PKPOWER AC-DC Power Adapter showing the main unit, cable, and two-prong plug.

5. Operating Instructions

Once properly connected, the power adapter will supply power to your ProForm exercise bike. No further action is required for the adapter itself.

- Ensure the bike's power switch (if applicable) is in the 'ON' position to receive power.
- The adapter is designed for continuous use within its specified voltage and current limits.



Image 2: Close-up view of the PKPOWER AC-DC Power Adapter, highlighting the brand logo and regulatory markings.

6. Maintenance

Proper maintenance ensures the longevity and safe operation of your power adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and moisture. Avoid tightly winding the cord to prevent damage.
- **Cable Care:** Regularly check the power cord for any cuts, fraying, or kinks. If any damage is observed, discontinue use immediately and replace the adapter.

7. Troubleshooting

If you encounter issues with your power adapter, refer to the following common solutions:

Problem	Possible Cause	Solution
No power to the exercise bike.	Adapter not properly plugged in.	Ensure both ends of the adapter are securely connected.
	Power outlet is not functional.	Test the outlet with another device or try a different outlet.
	Damaged adapter or cable.	Inspect for visible damage. If damaged, discontinue use and replace.
Bike's power switch is off.	Ensure the exercise bike's power switch is in the 'ON' position.	

If the problem persists after trying these steps, please contact PKPOWER customer support.

8. Specifications

- **Input Voltage:** AC 100-240V, 50/60Hz
- **Cord Length:** 6.6 feet (2 meters)
- **Connector Type:** Barrel Connector
- **Protection Features:** OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), SCP (Short Circuit Output Protection)
- **Compatible Devices:** ProForm 8.0 EX Bike (PFEX14914), ProForm 14.0 EX Bike (PFEX17914)
- **Item Weight:** Approximately 4 ounces

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or visit the official PKPOWER website. If you have any questions or require assistance, please contact PKPOWER customer service.

Manufacturer: PKPOWER

Date First Available: May 22, 2020

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0891LJY1G

More documents and user manuals: **https://manuals.plus/**