Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO 4500

MINISO Ultrasonic Cool Mist Humidifier Model 4500 User Manual

Model: 4500 | Brand: MINISO

1. Safety Instructions

- Use only pure water. Do not add essential oils, perfumes, or other chemical substances to the water reservoir.
- Keep the humidifier out of reach of children and pets.
- Do not immerse the product in water or other liquids.
- Ensure the USB cable is connected securely and the power source is appropriate.
- Disconnect the humidifier from the power source before cleaning or refilling.
- Do not block the mist outlet.

2. Package Contents

Please check the box for the following items:

- 1 x MINISO Ultrasonic Cool Mist Humidifier
- 1 x USB Charging Cable
- 1 x Replacement Cotton Filter Core



This image displays the MINISO Ultrasonic Cool Mist Humidifier in blue and white, alongside its USB charging cable and a white replacement cotton filter stick.

3. Product Overview

The MINISO Ultrasonic Cool Mist Humidifier Model 4500 is a compact and silent device designed to add moisture to the air. It features a single button for operation and a convenient USB charging port, making it ideal for small spaces like bedrooms or offices.

PRODUCT DETAIL



A close-up view of the humidifier's top section, highlighting the power button with an indicator light and the mist outlet.



An internal view of the humidifier's water reservoir, showing the area where water is held for mist generation.

4. Setup Instructions

1. **Fill with Water:** Gently twist and lift the top section of the humidifier to access the water reservoir. Fill the bottom reservoir with clean, pure water. Do not exceed the maximum fill line.
2. **Prepare Cotton Core:** Before first use, ensure the cotton filter core is fully saturated with water. If it's dry, soak it in water for a few minutes. Insert the cotton core firmly into its designated slot within the top section.
3. **Assemble:** Carefully place the top section back onto the water reservoir, ensuring it is securely seated.
4. **Connect Power:** Connect the provided USB cable to the humidifier's USB port. Plug the other end of the USB cable into a compatible USB power source, such as a computer, power bank, or a wall adapter (not included).

5. Operating Instructions

The humidifier is controlled by a single power button located on the top section.

- **Power On/Off:** Press the power button once to turn on the humidifier and activate continuous mist mode. Press the button again to turn it off.
- **Mist Modes:** (Based on product features, this model supports two spray modes.)

- Press the power button once for continuous mist.
- Press the power button a second time for intermittent mist (e.g., mist for a few seconds, then pause).
- Press the power button a third time to turn the humidifier off.

- **Auto Shut-off:** The humidifier features an 8-hour auto shut-off timer for safety and energy saving.
- **LED Indicator:** An LED light indicates the operating status of the humidifier.



This image highlights key features of the humidifier: USB charging, two spray modes, an 8-hour auto shut-off timer, and an LED light indicator.

6. Maintenance

Cleaning the Water Reservoir

Regularly clean the water reservoir to prevent mineral buildup and bacterial growth, which can affect mist quality and product lifespan.

1. Disconnect the humidifier from the power source.
2. Empty any remaining water from the reservoir.

3. Wipe the inside of the reservoir with a soft, damp cloth. For stubborn mineral deposits, use a mild descaling solution (e.g., white vinegar diluted with water) and rinse thoroughly with clean water.
4. Do not use harsh chemicals, abrasive cleaners, or scrub brushes, as these can damage the unit.

Replacing the Cotton Filter Core

The cotton filter core should be washed at least once a month or replaced if you notice a significant decrease in mist output or if the core appears discolored or damaged.

1. Disconnect the humidifier from the power source.
2. Remove the top section and carefully extract the old cotton core from its housing.
3. Insert a new, fully saturated cotton core into the slot. Ensure it is properly seated.
4. Reassemble the humidifier.

7. Troubleshooting

Problem	Possible Cause	Solution
No mist output	No water in reservoir	Fill reservoir with clean, pure water.
No mist output	Cotton core not saturated	Ensure cotton core is fully wet before use. Soak if dry.
No mist output	Cotton core clogged or worn	Clean or replace the cotton filter core.
No mist output	Power not connected	Check USB cable connection and power source.
Weak mist output	Mineral buildup in reservoir or on transducer	Clean the water reservoir and the ultrasonic transducer (small metal disc) gently.
Weak mist output	Low water level	Refill the water reservoir.

8. Specifications

Feature	Detail
Brand	MINISO
Model Number	4500
Color	Blue
Product Dimensions	8 x 8 x 18 cm
Product Weight	200 g
Water Capacity	280 Milliliters
Filter Material	Cotton

Feature	Detail
Operating Time	Up to 8 hours (with auto shut-off)
Special Feature	Silent Operation
Area Coverage	Up to 50 square meters



A diagram illustrating the humidifier's dimensions, indicating a height of 17 cm and a base width of 7.4 cm.



The product packaging box for the MINISO Humidifier, displaying various product details and specifications in multiple languages.

9. Warranty and Support

No specific warranty information is provided in the product data. For support or warranty inquiries, please contact MINISO customer service or refer to the retailer's return policy where the product was purchased.

For more information about MINISO products, you may visit the official MINISO store:

MINISO Official Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0893PKRCV

More documents and user manuals: **https://manuals.plus/**