Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easyfone Prime-A5

Easyfone Prime-A5 Mobile Phone User Manual

Model: Prime-A5

Introduction

Thank you for choosing the Easyfone Prime-A5 Mobile Phone. This device is specifically designed for the elderly, featuring an easy-to-use interface, large Arabic keyboard, and essential functions for reliable communication. This manual provides detailed instructions on how to set up, operate, and maintain your new phone.

Package Contents



Image: Contents of the Easyfone Prime-A5 package.

The image displays the Easyfone Prime-A5 mobile phone, its charging base, a power adapter, a lanyard, and a quick start guide, all neatly arranged on a wooden surface, indicating the items included in the product package.

Please check the package contents to ensure all items are present:

- Easyfone Prime-A5 Mobile Phone
- Charging Base
- Power Adapter
- Lanyard
- User Manual (this document)

Product Overview

Familiarize yourself with the key components of your Easyfone Prime-A5.





Image: Front view of the Easyfone Prime-A5.

This image shows the Easyfone Prime-A5 mobile phone placed in its charging base. The front of the phone is visible, highlighting its large, clearly labeled Arabic keyboard and the display screen showing time and network information.


SOS
Easyfone

Image: Back view of the Easyfone Prime-A5.

The back of the Easyfone Prime-A5 is shown, featuring a prominent red SOS button for emergency calls and a speaker grille located near the top.

Key Features:

- **Large Arabic Keyboard:** Easy to see and press buttons with clear Arabic characters and backlighting.
- **1.8-Inch HD Screen:** Clear display for better viewing.
- **SOS Button:** Programmable emergency button on the back for quick assistance.
- **Speed Dial Buttons:** Eight dedicated direct dial keys for frequently called contacts.
- **Charging Base:** Convenient and easy charging solution.
- **Integrated Flashlight:** For illumination in dark environments.
- **FM Radio:** Enjoy local radio stations.
- **Audio Player & Bluetooth:** For media playback and wireless connectivity.

Setup

1. Inserting SIM Card and Battery

Before using your phone, you need to insert a SIM card and the battery.

1. Carefully remove the back cover of the phone.
2. Insert your GSM SIM card into the designated slot. Ensure the gold contacts face downwards and the cut corner aligns with the phone's slot.
3. Insert the battery, aligning the gold contacts with the phone's terminals.
4. Replace the back cover until it clicks into place.

2. Charging the Phone

For first-time use, fully charge the phone for at least 4 hours.





Image: Easyfone Prime-A5 in charging base.

The image shows the Easyfone Prime-A5 mobile phone securely placed in its dedicated charging base, illustrating how the device is charged.

1. Connect the power adapter to the charging base.
2. Plug the power adapter into a wall outlet.
3. Place the Easyfone Prime-A5 into the charging base. Ensure it is seated correctly and the charging indicator appears on the screen.
4. Alternatively, you can charge the phone directly using the micro-USB port on the side of the phone with the provided cable and adapter.

A full charge provides up to 14 hours of talk time and almost 7 days on standby.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the **Red (End Call/Power)** button until the screen lights up.
- **To Power Off:** Press and hold the **Red (End Call/Power)** button until the power off options appear, then confirm.

Making and Receiving Calls

- **To Make a Call:** Dial the number using the large keypad and press the **Green (Call)** button.
- **To Receive a Call:** Press the **Green (Call)** button when the phone rings.
- **To End a Call:** Press the **Red (End Call/Power)** button.

SOS Emergency Button





Image: SOS button on the back of the phone.

This image highlights the red SOS button located on the back panel of the Easyfone Prime-A5, designed for emergency use.

The SOS button is a critical safety feature. When pressed and held, it will automatically dial up to 5 pre-programmed emergency contacts sequentially until one answers. It can also send an emergency SMS message to these contacts.

- **Programming SOS Contacts:** Navigate to the SOS settings in the phone's menu to add or edit emergency numbers.
- **Activating SOS:** Press and hold the **SOS button** on the back of the phone for 3 seconds.

Speed Dial

The phone supports eight speed dial buttons (keys 2-9). You can assign frequently called numbers to these keys for quick dialing.

- **Programming Speed Dial:** Go to the phonebook or speed dial settings in the menu to assign contacts to numbers 2-9.
- **Using Speed Dial:** Press and hold the assigned number key (e.g., '2' for the first speed dial contact) to dial the number.

Flashlight



Image: Easyfone Prime-A5 flashlight in use.

This image demonstrates the Easyfone Prime-A5's integrated flashlight, showing a bright beam of light emanating from the top of the phone in a dark setting.

The built-in flashlight can be easily activated for convenience.

- **To Turn On/Off:** Locate the dedicated flashlight switch on the side of the phone (if available) or access it through the phone's menu/shortcuts.

FM Radio

Enjoy your favorite FM radio stations on the go.

- **Accessing FM Radio:** Navigate to the "FM Radio" option in the main menu.
- **Scanning Channels:** Use the navigation keys to scan for available stations.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone and charging base. Avoid liquid cleaners.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Do not leave the phone fully discharged for long periods.
- **Storage:** Store the phone in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Possible Solution

Problem	Possible Solution
Phone does not power on.	Ensure the battery is correctly inserted and fully charged. Try charging the phone for at least 30 minutes.
Cannot make or receive calls.	Check if the SIM card is properly inserted. Ensure you have network signal. Contact your service provider if issues persist.
Poor network reception.	Move to an area with better signal strength. Avoid using the phone in basements or remote areas.
SOS button not working.	Verify that emergency contacts are correctly programmed in the SOS settings. Ensure the phone has network signal.
Charging issues.	Check if the power adapter and charging base are properly connected. Ensure the phone is correctly seated in the charging base. Try cleaning the charging contacts.

Specifications

Feature	Detail
Model Name	Prime A5
Brand	Easyfone
Screen Size	1.8 Inches
Cellular Technology	2G (GSM)
Connectivity Technology	Bluetooth
Wireless Carrier Support	STC, Zain, Mobily, BASE
CPU Speed	1.3 GHz
Color	Black
Package Dimensions	13 x 11 x 7 cm
Item Weight	320 g

Warranty and Support

Easyfone products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact Easyfone customer service through their official website or the contact information provided in your product documentation.
Always ensure you purchase from authorized sellers to guarantee genuine products and valid warranty support.

© 2024 Easyfone. All rights reserved.
For more information, visit www.easyfone.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089D15L7Q

More documents and user manuals: **https://manuals.plus/**