Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell Tour V5

Bushnell Golf Tour V5 Rangefinder User Manual

Model: Tour V5

1. Introduction

This manual provides comprehensive instructions for the proper use and care of your Bushnell Golf Tour V5 Rangefinder. Please read this manual thoroughly before using your device to ensure optimal performance and longevity.



Image 1.1: The Bushnell Golf Tour V5 Rangefinder, a compact and ergonomic device designed for golf course distance measurement.

The Bushnell Tour V5 is a precision laser rangefinder designed to provide accurate distance measurements on the golf course. It features advanced technologies such as Slope-Switch, Pinseeker with Visual JOLT, and a BITE Magnetic Cart Mount to enhance your golfing experience.

2. Package Contents

Verify that all items are present in your package:

- Bushnell Golf Tour V5 Rangefinder
- Carrying Case
- CR2 Battery
- Instruction Manual (this document)
- Additional accessories (e.g., divot tool, depending on pack)



Image 2.1: Contents of the Bushnell Tour V5 Patriot Pack, including the rangefinder, carrying case, CR2 battery, and a branded divot tool.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the side of the rangefinder.
2. Twist the battery cap counter-clockwise to open.
3. Insert the supplied CR2 battery, ensuring the positive (+) terminal is facing outwards.
4. Replace the battery cap and twist clockwise until secure.

Note: A fresh CR2 battery is included. If the device does not power on, ensure the battery is correctly inserted or replace it with a new one.

4. Operating Instructions

4.1 Powering On and Taking a Measurement

1. Press and release the Power/Fire button (located on the top of the device) to activate the display.
2. Look through the eyepiece and aim the reticle (crosshairs) at your desired target.

3. Press and hold the Power/Fire button until the distance reading appears in the display.
4. Release the button. The measurement will remain displayed for a few seconds.



Image 4.1: The Bushnell Tour V5 Rangefinder held comfortably in hand, ready for use. The power button is easily accessible for quick measurements.

4.2 Changing Units of Measure (Yards/Meters)

To switch between Yards (Y) and Meters (M):

1. With the device powered on, press the "Y/M" button (located on the side of the device) to toggle between units.
2. The selected unit will be indicated in the display.



Image 4.2: Side view of the Bushnell Tour V5 Shift, showing the "Y/M" button for changing measurement units and the "TOUR V5 SHIFT" branding.

4.3 Slope-Switch Technology

The Tour V5 Shift model features Slope-Switch Technology, allowing you to easily toggle between slope-compensated distances and non-slope distances. This makes the device legal for tournament play when slope is disabled.

- To enable/disable Slope mode, slide the side switch up or down.
- When Slope mode is active, the display will show compensated distances.
- When Slope mode is disabled, the device provides line-of-sight distances only.

4.4 Pinseeker with Visual JOLT

Pinseeker with Visual JOLT technology provides confirmation when the laser locks onto the flagstick, filtering out background objects. When the flag is acquired:

- The device will vibrate (JOLT).
- A flashing red ring will appear in the display, providing visual confirmation.



Image 4.3: Front view of the Bushnell Tour V5, showcasing the optical lenses used for clear viewing and precise laser targeting for features like Pinseeker.

4.5 BITE Magnetic Cart Mount

The integrated BITE magnetic technology allows for convenient attachment of your Tour V5 to a golf cart bar or any magnetic surface. This keeps your rangefinder easily accessible during your round.

- Simply place the side of the rangefinder with the "BITE Magnetic Grip" label against a metal surface.
- Ensure a secure attachment before releasing the device.



Image 4.4: Side view of the Bushnell Tour V5 highlighting the "Bushnell BITE Magnetic Grip" area, designed for secure attachment to metal surfaces like golf cart frames.

4.6 Official Product Video

Watch this official video from Bushnell for an overview of the Tour V5 Rangefinder's features and benefits.

▶ **Watch video online**
Bushnell Tour V5 Rangefinder

Video 4.1: An official product video from Bushnell Inc. demonstrating the key features and usage of the Bushnell Tour V5 Rangefinder.

5. Maintenance

- **Cleaning Lenses:** Gently wipe lenses with a soft, clean microfiber cloth. Do not use abrasive materials or harsh chemicals.
- **Cleaning Body:** Wipe the body of the rangefinder with a soft, damp cloth.
- **Storage:** Store the device in its protective carrying case in a cool, dry place when not in use. Avoid extreme temperatures and direct sunlight.
- **Battery:** Remove the battery if the device will not be used for an extended period to prevent leakage.

6. Troubleshooting

6.1 No Display or Device Not Powering On

- Check if the CR2 battery is inserted correctly with the positive (+) terminal facing out.
- Replace the battery with a new CR2 battery.

6.2 Inaccurate Readings

- Ensure the target is within the device's measuring range (5-1,300 yards).
- Confirm the lens is clean and free from smudges or debris.
- Ensure you are holding the device steady during measurement.
- In Pinseeker mode, ensure the device has locked onto the flagstick and not a background object.

6.3 Display is Dim or Flickering

- The battery may be low. Replace with a new CR2 battery.
- Extreme temperatures can affect display performance. Allow the device to return to a moderate temperature.

7. Specifications

Feature	Detail
Brand	Bushnell
Model Number	201911P (Product), 2032 (Manufacturer Part)
Measuring Range	5-1,300 yards
Item Weight	10.4 ounces
Dimensions (L x W x H)	6" x 4.5" x 4.75"
Material	Plastic
Battery Type	CR2 Lithium Metal
Water Resistance Level	Water Resistant (IPX4)
UPC	029757006455



Image 7.1: Dimensional view of the Bushnell Tour V5 Rangefinder, showing its length, width, and height.

8. Warranty Information

Your Bushnell Golf Tour V5 Rangefinder is covered by a**2 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship. For full warranty terms and conditions, please refer to the official Bushnell website or contact customer support.

9. Customer Support

For further assistance, technical support, or warranty claims, please visit the official Bushnell website or contact their customer service department. You can find contact information and FAQs on their support pages.
Bushnell Official Website: www.bushnellgolf.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089K1RSK2

More documents and user manuals: **https://manuals.plus/**