Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka Atom 65

Eureka Atom 65mm Espresso Grinder User Manual

Model: Atom 65 | Brand: Eureka

Product Overview

The Eureka Atom 65mm Espresso Grinder is engineered for exceptional coffee grinding, providing both speed and precision. It is equipped with 65mm flat burrs, ensuring consistent particle size for optimal extraction. The grinder's design prioritizes quiet operation and ease of use, making it a valuable addition to any coffee setup. Its advanced features cater to a range of grinding needs, from fine espresso to coarser drip coffee.

Key Features

- **65mm Flat Burrs:** Utilizes commercial-grade 65mm flat burrs for efficient and consistent grinding, suitable for various coffee preparations.
- **Silent Grind Technology:** Features a thick, non-resonant casing and rubber hush gaskets to significantly reduce grinding noise, allowing for quiet operation.
- **ACE System (Anti-Clump & Electrostatic):** Prevents clumping and static electricity in the grind chute, ensuring fluffy grounds and a clean workspace.
- **Stepless Bottom Burr Adjustment:** Offers near-infinite grind adjustments via an easy-to-use knurled knob located below the motor, preserving grind settings after cleaning.
- **Programmable Dosing:** Allows users to program single and double shot grind times via a color screen, with an additional manual grinding option.
- **Large Hopper Capacity:** Equipped with a hopper that holds up to 2.5 pounds of whole beans, reducing the frequency of refills.

Setup

Before initial use, carefully unbox the Eureka Atom 65mm Espresso Grinder and place it on a stable, flat surface. Ensure the power switch is in the OFF position before plugging the unit into a grounded electrical outlet. Attach the bean hopper securely to the top of the grinder.



Figure 1: Front view of the Eureka Atom 65mm Espresso Grinder with short hopper.

The grinder is designed for easy setup. Once positioned, you can proceed to fill the hopper with your preferred whole coffee beans.

Operating Instructions

Grind Adjustment

The Atom 65 features a stepless grind adjustment system, allowing for precise control over your grind size. To adjust, turn the knurled knob located on the top right side of the grinder. Turning towards 'FINE' will result in a finer grind, while turning towards 'COARSE' will produce a coarser grind. This system ensures that your grind setting remains consistent even after disassembling for cleaning.



Figure 2: Detailed view of the stepless grind adjustment knob.

Dosing & Programming

The grinder's control panel allows for programmable dosing for single and double shots, as well as a manual grinding option. Use the '+' and '-' buttons to adjust the grinding time for each programmed dose. The display shows the current time setting in seconds.



Figure 3: The intuitive control panel for programming and manual operation.

Grinding Process

To begin grinding, place your portafilter onto the portafilter rest. Select your desired dose (single, double, or manual) on the

control panel. The grinder will dispense coffee directly into your portafilter. The built-in light illuminates the grinding area for better visibility. The ACE system ensures minimal clumping and static, providing a clean and consistent dose.

Video 1: An official review demonstrating the Eureka Atom 65mm Espresso Grinder's features, including its quiet operation and grinding process.

Maintenance

Cleaning Burrs

Regular cleaning of the burrs is essential for optimal performance. The Eureka Atom 65 allows for easy burr cleaning without losing your established grind setting. Simply remove the top lid and the upper burr. Clean both burrs and the grinding chamber using a brush or vacuum. Reassemble, and your grind setting will remain intact.

General Cleaning

Wipe down the exterior of the grinder with a damp cloth. Avoid using abrasive cleaners or submerging the unit in water. Regularly empty and clean the grounds tray to prevent buildup and maintain hygiene.

Troubleshooting

- **Grinder not turning on:** Ensure the power cord is securely plugged into a working outlet and the main power switch is in the 'ON' position.
- **Inconsistent grind:** Check that the burrs are clean and free of old coffee residue. Verify the grind adjustment knob is set correctly and has not shifted.
- **Coffee not dispensing:** Ensure the bean hopper is not empty and the shut-off valve (if present) is open. Check for any blockages in the grind chute.
- **Excessive noise during grinding:** While the Atom 65 is designed to be quiet, unusual loud noises may indicate a foreign object in the burrs or a need for professional inspection.

Specifications

Attribute	Detail
Color	Chrome
Brand	Eureka
Style	Classic
Product Dimensions	10.5"L x 7.2"W x 17.25"H
Recommended Uses	Espresso - Designed for precision grinds at fine settings just for espresso.
Specific Uses	Grinding
Voltage	120 Volts
Manufacturer	Eureka
Item Weight	25 pounds
ASIN	B089NZSVRX
Item model number	Atom 65
Date First Available	June 4, 2020

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official Eureka website. You may also contact the seller directly for assistance. Keep your proof of purchase for warranty claims.

© 2024 Eureka. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B089NZSVRX

More documents and user manuals: **https://manuals.plus/**