Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luxspire BZXP03JA901

Luxspire 3D Starburst Lighted Christmas Tree Topper with Timer, Silver

Model: BZXP03JA901

Brand: Luxspire

Introduction

This instruction manual provides detailed guidance for the setup, operation, and maintenance of your Luxspire 3D Starburst Lighted Christmas Tree Topper. Learn how to install the topper on various tree types and utilize its integrated timer function for effortless holiday illumination. Please read this manual thoroughly before use to ensure safe and optimal performance.

Safety Information

- This product is designed for **indoor use only**.
- Keep the tree topper away from water, moisture, and flammable materials.
- Ensure the power outlet voltage is compatible with the product's requirements.
- Unplug the tree topper from the power source when not in use, during installation, or before performing any maintenance.
- Do not attempt to modify or repair the product. Contact customer support if issues arise.

Package Contents

- 1 x Luxspire 3D Starburst Lighted Christmas Tree Topper (Silver)
- 1 x Instruction Manual

Setup and Installation

The Luxspire 3D Starburst Tree Topper is designed for easy installation on various Christmas tree types. It features a durable and stable base to ensure a secure fit.

Installation Steps:

1. **For Artificial Trees:** Gently bend the top branches of your artificial tree upward. Position the tree topper's base over these branches and secure it firmly.
2. **For Real Trees:** If necessary, trim the very top branches to create a relatively flat surface. Push the tree topper's coil base down firmly onto the top of the tree for a snug and stable fit.
3. Connect the 16.4ft extended power cable to a suitable indoor power outlet.



Image: A family placing the Luxspire 3D Starburst Tree Topper on top of a decorated Christmas tree. The topper is silver and illuminated, adding a festive touch.



Image: A visual guide demonstrating the process of securing the tree topper onto the top branches of an artificial Christmas tree.



Image: A visual guide illustrating the method for attaching the tree topper to the trimmed top of a real Christmas tree.

Installation Video:

▶ **Watch video online**
Luxspire Christmas Tree Topper

Video: This video provides a visual demonstration of how to install the Luxspire Christmas Tree Topper, showcasing its design and placement on a tree.

Operating Instructions

The Luxspire 3D Starburst Tree Topper features a convenient plug-in design with an integrated timer function.

Timer Function:

- The tree topper is equipped with an automated **6-hour on / 18-hour off cycle**.
- Once plugged in, the lights will illuminate for 6 hours, then automatically turn off for 18 hours. This cycle repeats daily.
- This feature helps conserve energy and eliminates the need for manual switching.



Image: A visual representation of the tree topper's 6-hour on and 18-hour off automatic timer cycle.

Operation Video:

▶ **Watch video online**
Luxspire Christmas Tree Topper with Timer

Video: This video highlights the Luxspire Christmas Tree Topper, specifically demonstrating its timer functionality and how the lights operate.

▶ **Watch video online**
Luxspire Christmas Tree Topper Lights

Video: A demonstration of the Luxspire Christmas Tree Topper lights, showcasing their brightness and visual effect when illuminated.

Maintenance

- To clean the tree topper, gently wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Store the tree topper in its original packaging or a protective container in a cool, dry place when not in use.
- Ensure the power cable is not kinked or damaged during storage.

Troubleshooting

- **Lights not turning on:** Ensure the power cable is securely plugged into a working outlet. Check if the outlet is receiving power.
- **Timer not functioning correctly:** Unplug the topper for a few minutes and then plug it back in to reset the timer cycle. Ensure it's plugged in at the desired 'on' time for the 6-hour cycle to begin.
- **Topper is unstable:** Re-adjust the base on the tree top, ensuring branches are bent or trimmed as needed for a snug fit. For heavier toppers, additional securing methods (e.g., zip ties, floral wire) may be used.

Specifications

Feature	Detail
Model Number	BZXP03JA901

Color	A-bursting Star-silver
Material	Metal
Style	Vintage, Modern, Classic
Size	11 inch (6.69"D x 7.87"W x 11.02"H)
Item Weight	11.3 Ounces
Power Source	Plug-in (No batteries required)
Cable Length	16.4 ft
Timer Function	6-hour on / 18-hour off cycle
Recommended Tree Height	4ft to 12ft
UPC	723314007250

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Luxspire website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08BC8B7FP

More documents and user manuals: **https://manuals.plus/**