Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER CMA3549, CMA3568

PKPOWER AC DC Adapter User Manual

For Craig Electronics Portable Bluetooth Speakers (Models: CMA3549, CMA3568 Series)

1. Introduction

Thank you for choosing the PKPOWER AC DC Adapter. This manual provides essential information for the safe and effective use of your power adapter, designed for various Craig Electronics portable Bluetooth speakers. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open, modify, or repair the adapter. Refer servicing to qualified personnel.
- Ensure the power outlet voltage matches the adapter's input range (100-240V).
- Unplug the adapter from the power outlet when not in use for extended periods.
- This adapter features Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) for enhanced safety.

3. Product Overview

The PKPOWER AC DC Adapter is a reliable power supply designed to charge and power your compatible Craig Electronics portable Bluetooth speakers. It features a compact design and a durable cable with a Micro-USB connector.



Figure 1: PKPOWER AC DC Adapter with integrated Micro-USB cable.



Figure 2: Side view of the adapter, highlighting the US standard plug prongs.



Figure 3: Close-up of the adapter's label, displaying input voltage (100-240VAC) and DC output information.

4. Setup

Follow these steps to set up your PKPOWER AC DC Adapter:

1. Ensure your Craig Electronics portable Bluetooth speaker is turned off or in a charging-ready state.
2. Locate the charging port on your speaker. This is typically a Micro-USB port.
3. Connect the Micro-USB end of the PKPOWER adapter cable firmly into the speaker's charging port.
4. Plug the AC prongs of the PKPOWER adapter into a standard wall power outlet (100-240V AC).
5. The speaker should indicate that it is charging, usually via an LED indicator light.

5. Operating Instructions

Once connected, the adapter will automatically begin charging your speaker. No further user interaction is typically required during the charging process. Refer to your speaker's manual for specific charging indicators and battery status information.

6. Maintenance and Care

Proper care will extend the life of your adapter:

- Keep the adapter clean and free from dust. Use a soft, dry cloth for cleaning.
- Store the adapter in a cool, dry place when not in use.
- Avoid wrapping the cable too tightly around the adapter to prevent damage to the cable or connectors.
- Do not pull the cable to disconnect the adapter from the outlet or speaker; always grasp the plug or connector directly.

7. Troubleshooting

If you encounter issues with your adapter, try the following:

- **Speaker not charging:** Ensure the adapter is securely plugged into both the wall outlet and the speaker. Try a different wall outlet to rule out a power supply issue.
- **Adapter feels warm:** It is normal for the adapter to become slightly warm during operation. If it becomes excessively hot or emits a burning smell, immediately unplug it and discontinue use.
- **No power indicator on speaker:** Verify that the speaker is compatible with this adapter and that its charging port is not damaged.

If problems persist, contact customer support.

8. Specifications

Brand	PKPOWER
Input Voltage	100-240V AC, 50/60Hz
Output	DC Output (refer to your device's power requirements for specific voltage/amperage)
Connector Type	Micro-USB (wired)
Color	Black
Weight	Approximately 3 ounces
Certifications	CE, FCC, RoHS
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Compatible Devices	Craig Electronics CMA3549, CMA3568, CMA3568BLUE, CMA3568-BK, CMA3568BK, CMA3568BI, CMA3568BL, CMA3568RD, CMA3568RDL Wireless Portable Bluetooth Speakers

9. Warranty and Support

PKPOWER products are designed for reliability. For warranty information and customer support, please refer to the seller or contact PKPOWER customer service. Our friendly and reliable customer service team aims to respond to inquiries within 24 hours.
For further assistance, please visit the PKPOWER Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08C2WQTN2

More documents and user manuals: **https://manuals.plus/**