Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP BD-40

ZOKOP BD-40 Compact Vertical Freezer User Manual

Model: BD-40 | Brand: ZOKOP

Introduction

This manual provides essential information for the safe and efficient operation of your ZOKOP BD-40 compact vertical freezer. Please read it thoroughly before use and retain it for future reference.
The ZOKOP BD-40 is a 1.1 cubic foot vertical freezer featuring a reversible stainless steel door and a sleek black cabinet. Its compact design makes it suitable for small spaces, while the adjustable thermostat allows for precise temperature control to meet various storage needs.



Figure 1: Front view of the ZOKOP BD-40 compact vertical freezer.

Key Features:

- **Modern and Elegant Design:** 1.1 cubic foot capacity with a reversible stainless steel door and black cabinet.
- **Space-Saving:** Compact footprint, ideal for small kitchens or limited spaces.
- **Adjustable Temperature:** Manual 7-level temperature control knob for settings from -8°F to 7°F (-22°C to -14°C).
- **Flexible Storage:** Includes a removable slide-out chrome shelf for organized storage.
- **Convenient Access:** Features an embedded door handle for easy opening.
- **UL Certified:** Ensures product safety and quality.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and

injury.

- Ensure the power supply matches the appliance's requirements (115V / 60Hz).
- Do not operate the freezer with a damaged cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the freezer before cleaning or performing maintenance.

Setup and Installation

Unpacking:

1. Remove all packaging materials, including foam and adhesive tape.
2. Inspect the freezer for any damage during transit. Report any damage to your retailer immediately.
3. Clean the interior and exterior of the freezer with a soft cloth and mild detergent before use.

Placement:

- Place the freezer on a firm, level surface away from direct sunlight or heat sources.
- Ensure adequate air circulation around the unit. Maintain at least 4 inches (10 cm) of space from walls or other appliances.
- The space-saving flat back design allows for neat placement against a wall or in a corner.



Figure 2: The compact freezer fits well under kitchen counters.

Door Reversal (Optional):

The door is reversible, allowing you to choose the opening direction. Refer to the detailed instructions in the separate door reversal guide (if provided) or consult a qualified technician for assistance.

Operating Instructions

Initial Startup:

1. After placing the freezer, allow it to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle.
2. Plug the freezer into a dedicated 115V / 60Hz power outlet.
3. Set the temperature control knob to the desired setting.

Temperature Control:

The manual 7-level temperature control knob is located on the back of the unit. Rotate the knob to adjust the internal temperature. The temperature range is approximately -8°F to 7°F (-22°C to -14°C).

- **"1" (Min):** Least cold setting.
- **"7" (Max):** Coldest setting.

For optimal freezing performance, it is recommended to start with a mid-range setting and adjust as needed based on ambient temperature and food load.



Figure 3: Interior view demonstrating storage capacity with the removable shelf.

Storage:

- Utilize the removable slide-out chrome shelf to organize your frozen items efficiently.
- Do not overload the freezer, as this can impede air circulation and freezing efficiency.

Maintenance

Cleaning:

1. Always unplug the freezer before cleaning.
2. Clean the interior with a solution of mild detergent and warm water. Wipe dry thoroughly.
3. Clean the exterior with a soft cloth and mild detergent.
4. Regularly clean the antibacterial door gasket to ensure a proper seal.
5. Do not use abrasive cleaners or sharp objects, as they can damage surfaces.



Figure 4: Key features and components of the freezer.

Defrosting:

This freezer features manual defrost. Frost buildup on the interior walls can reduce efficiency. Defrost the unit when frost accumulation reaches approximately 1/4 inch (6 mm) thickness.

1. Unplug the freezer from the power outlet.
2. Remove all frozen food and store it in another freezer or insulated container.
3. Leave the door open to allow frost to melt naturally. You can place towels at the bottom to absorb water.
4. Once defrosted, clean and dry the interior thoroughly before plugging the unit back in and returning food.

Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Freezer does not operate.	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Temperature is not cold enough.	Temperature control set too warm; door opened too frequently; heavy frost buildup; poor ventilation.	Adjust temperature setting; minimize door openings; defrost unit; ensure adequate clearance around freezer.
Excessive noise.	Freezer not level; objects vibrating against the unit.	Adjust leveling feet; ensure nothing is touching the back or sides of the freezer.
Door does not close completely.	Door gasket dirty or damaged; freezer not level; items obstructing door.	Clean or replace gasket; level the freezer; rearrange contents.

Specifications

Feature	Specification
Brand	ZOKOP
Model Name	ZOKOP BD 40
Power Supply	115V / 60Hz
Ampere	0.8A
Freezing Capacity	31.1 L / 1.1 CU.FT
Freezing Temperature Range	-22°C to -14°C / -8°F to 7°F
Refrigerant	R600a
Dimensions (W x D x H)	17.5" x 18.6" x 19.6" (approx.)
Net Weight	31 lbs / 14.1 kg
Certification	UL certification
Installation Type	Countertop, Freestanding
Defrost Type	Manual
Door Hinges	Reversible
Door Material Type	Stainless Steel
Shelf Type	Slide out
Number of Shelves	1



Figure 5: Exterior and interior dimensions of the freezer.

Warranty and Support

For warranty information, returns, or replacement inquiries, please refer to the documentation provided with your purchase or contact your retailer. The product is supported by U.S. warehouse distribution for timely and convenient service.

© 2023 ZOKOP. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08CY5LJ2Z

More documents and user manuals: **https://manuals.plus/**