Howard Miller 635-223

Howard Miller Lakeside Mantel Clock Model 635-223 User Manual

1. Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your Howard Miller Lakeside Mantel Clock, Model 635-223. Please read this manual thoroughly before using your clock to ensure proper function and longevity.



Figure 1: Front view of the Howard Miller Lakeside Mantel Clock.

2. Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Handle the clock with care to avoid damage to the glass and wooden case.

3. Package Contents

Verify that all items are present in the packaging:

- Howard Miller Lakeside Mantel Clock (Model 635-223)
- User Manual

4. Setup

4.1 Battery Installation

The clock requires three (3) AA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert three AA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

4.2 Placement

Place the mantel clock on a stable, flat surface such as a mantelpiece, shelf, or side table. Ensure the surface is level to prevent the clock from tipping and to ensure accurate timekeeping.



Figure 2: Side view of the mantel clock, showing its profile.

5. Operation

5.1 Setting the Time

To set the time on your clock:

1. Locate the time-setting knob on the back of the clock mechanism.
2. Gently turn the knob clockwise until the hands display the correct time.

5.2 Westminster Chime

The clock features a Westminster chime that sounds on the hour. It is designed with an automatic night shutoff feature to ensure quiet during sleeping hours.

- The chime will automatically turn off between 10:01 PM and 5:59 AM.
- The chime will resume automatically at 6:00 AM.
- Consult the clock mechanism for any manual chime control options, if available.

6. Maintenance

6.1 Battery Replacement

Replace the batteries when the clock stops running or the chime becomes weak. Refer to Section 4.1 for battery installation instructions.

6.2 Cleaning

To maintain the appearance of your clock:

- Dust the wooden case with a soft, dry cloth.
- For the glass, use a soft, lint-free cloth and a non-abrasive glass cleaner. Apply cleaner to the cloth, not directly to the clock.
- Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

7. Troubleshooting

If you encounter issues with your clock, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly installed batteries	Replace batteries with new AA batteries, ensuring correct polarity.
Chime not sounding	Automatic night shutoff active	The chime is designed to be silent between 10:01 PM and 5:59 AM. It will resume automatically.
Time is incorrect	Time not set correctly or batteries low	Reset the time using the setting knob. If issue persists, replace batteries.

8. Specifications

Key specifications for the Howard Miller Lakeside Mantel Clock Model 635-223:

Feature	Detail
Brand	Howard Miller
Model Number	635-223
Display Type	Analog
Power Source	Battery Powered (3 AA batteries required, not included)
Material	Wood, Glass
Product Dimensions	16.54"W x 9.06"H
Item Weight	5.39 pounds
Special Feature	Westminster Chime with Automatic Night Shutoff



Figure 3: Dimensions of the Howard Miller Lakeside Mantel Clock.

9. Warranty and Support

9.1 Warranty Information

This Howard Miller Lakeside Mantel Clock comes with a 3-month manufacturer warranty. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

9.2 Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Howard Miller store or contact their customer service department. You can find more information at the Howard Miller Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question