Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tiny Dreny B08DHWV6MM

Tiny Dreny 7-in-1 Convertible Baby High Chair Instruction Manual

Model: B08DHWV6MM

Introduction

Thank you for choosing the Tiny Dreny 7-in-1 Convertible Baby High Chair. This versatile product is designed to grow with your child, offering multiple configurations for infants and toddlers. Please read this manual carefully before assembly and use to ensure safe and proper operation.

Safety Information

Your child's safety is our top priority. Always follow these guidelines:

- The high chair features four pyramid-shaped beech wooden legs and a steel frame, along with non-slip feet, to provide a stable and sturdy structure.
- Always secure your child with the adjustable harness system.
- Ensure all parts are correctly assembled and securely fastened before each use.
- The materials used are non-toxic.
- Never leave your child unattended in the high chair.

Product Features

The Tiny Dreny High Chair offers 7-in-1 versatility to adapt to your child's growth:

- **Infant Rest Chair:** For newborns and young infants.
- **Play and Eat Chair:** Standard high chair mode for feeding and play.
- **High Chair by the Table:** Allows your child to join family meals at the table.
- **Toddler Chair:** Converts to a standalone chair for toddlers.
- **Rocking Chair:** Easily transforms into a rocking chair for relaxation and fun.
- **Reclining Seat:** Features 3 adjustable positions (90°, 110°, 135°) for feeding, learning to sit, and comfortable breastfeeding.
- **Double Removable Tray:** Includes two depth modes, is dishwasher safe, BPA-free, and heat resistant.
- **Comfortable Design:** Arc-shaped corners for safety, heightened seat back for support, and a soft, 3D-forming leather pad that is warm in winter and cool in summer.



Image: The 7-in-1 versatility of the Tiny Dreny High Chair, illustrating its different modes from infant rest chair to high chair by the table.



Image: Illustration of the high chair's 3 reclining levels for comfort and developmental stages.

Setup and Assembly

Assembly is designed to be straightforward. Connect the various parts through screw rotation. The feet are designed in two parts, allowing for height adjustment.

- Identify all components as per the included parts list.
- Attach the legs to the main seat unit, ensuring secure screw rotation.
- Install the footrest and any support bars.
- Attach the seat cushion and harness.
- Slide the double tray into position.

▶ **Watch video online**
Baby high chair

Video: A demonstration of the baby high chair assembly and key features. This video is provided by HM-TECH.



Image: Detailed product dimensions for both the high chair and rocking chair configurations.

Operating Instructions

Familiarize yourself with the chair's adjustable features:

- **Adjusting Recline:** Locate the recline adjustment buttons on the sides of the seat. Press and hold to select one of the three reclining positions.
- **Adjusting Height:** The chair's height can be adjusted between 29.1 and 40.6 inches by modifying the two-part feet. Refer to the assembly instructions for detailed steps.
- **Tray Attachment/Removal:** The double tray easily slides on and off the chair. Press the release buttons (if applicable) to remove the tray for cleaning or to convert the chair.
- **Converting to Rocking Chair:** Follow the specific instructions in the assembly guide to reconfigure the legs and frame to transform the high chair into a rocking chair.



Image: The high chair in its rocking chair configuration, suitable for play and relaxation.

Maintenance and Cleaning

Keeping your Tiny Dreny High Chair clean is simple:

- **Seat Cushion:** The premium leatherette cushion is waterproof and can be easily wiped clean after meals. For deeper cleaning, the cushion is removable.
- **Trays:** The double removable tray is dishwasher safe for thorough cleaning.
- **Frame and Legs:** Wipe down the wooden legs and steel frame with a damp cloth as needed. No additional special care is required for the wooden legs in daily use.
- Regularly check all parts for wear and tear. Replace any damaged components immediately.



Image: Close-up view emphasizing the food-grade materials, transparent modern seat, waterproof cushion, and ease of cleaning.



Image: The double removable tray, showcasing its two depth modes, BPA-free material, and heat resistance.

Troubleshooting

If you encounter any issues with your high chair, please refer to the following common solutions:

- **Chair Instability:** Ensure all leg connections and screws are tightened. Verify that the non-slip feet are properly positioned on a flat surface.
- **Tray Difficulty:** If the tray is hard to attach or remove, check for any food debris obstructing the mechanism. Ensure it is aligned correctly before pushing or pulling.
- **Recline Adjustment Issues:** Make sure the recline buttons are fully depressed when attempting to change the seat angle.

For further assistance, please contact customer support.

Specifications

Attribute	Detail
Brand	Tiny Dreny
Model Number	B08DHWV6MM
Age Range Description	Baby, Toddler
UPC	719209248198
Manufacturer	Tiny Dreny
Unit Count	1.0 Count
Maximum Weight Recommendation	33 Pounds
Assembly Required	Yes
Item Dimensions (D x W x H)	18.5"D x 11"W x 23.2"H
Item Weight	16.46 Pounds
Color	Clear Seat Taupe Cushion
Material Type	Beech Wood, Steel Frame
Is Portable	No

Warranty and Support

For warranty information or customer support, please refer to the product packaging or contact Tiny Dreny directly through their official website or the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

© 2026 Tiny Dreny. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08DHWV6MM

More documents and user manuals: **https://manuals.plus/**