Manuals+
Q & A | Deep Search | Upload

BLAUPUNKT ATF401

Blaupunkt ATF401 Table Fan User Manual

Model: ATF401

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Blaupunkt ATF401 Table Fan. Please read this manual thoroughly before using the appliance and retain it for future reference.

Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following safety precautions:

- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate the fan with a damaged cord or plug. If damaged, contact qualified service personnel.
- Keep fingers, pencils, or any other objects out of the fan grille when it is operating.
- Unplug the fan from the outlet when not in use, before cleaning, or when moving it.
- Do not use the fan in wet locations such as bathrooms or laundry areas.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

The Blaupunkt ATF401 is a 30 cm diameter table fan designed for air circulation in home and office environments. It features a modern design and portable functionality.

Figure 1: Front view of the Blaupunkt ATF401 Table Fan. The fan features a white body, a protective grille, and three blades. Control buttons are visible on the base.

Components:

- Fan Head (Grille and Blades)
- Motor Housing
- Control Panel (on base)
- Base
- Power Cord

Setup

The Blaupunkt ATF401 Table Fan is designed for tabletop use and typically requires minimal assembly. Ensure all packaging materials are removed before use.

1. **Unpack:** Carefully remove the fan from its packaging.
2. **Placement:** Place the fan on a firm, level, and stable surface. Ensure there is adequate space around the fan for proper air circulation and to prevent obstruction of the air intake/outlet.
3. **Power Connection:** Insert the power cord plug into a standard electrical outlet (AC 220-240V, 50Hz).

Operating Instructions

The fan is operated using the control buttons located on the base.

1. **Power On/Off:** Press the '0' button to turn the fan off. Press '1', '2', or '3' to turn the fan on at the

desired speed.

2. **Speed Selection:**
    - **'1'** for Low speed
    - **'2'** for Medium speed
    - **'3'** for High speed
3. **Oscillation Function:** To activate the oscillation (side-to-side movement) function, press down the oscillation knob located on top of the motor housing. To stop oscillation, pull the knob up.
4. **Tilt Adjustment:** The fan head can be manually tilted up or down to direct airflow. Gently push or pull the fan head to the desired angle.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your fan.

- **Before Cleaning:** Always unplug the fan from the power outlet before cleaning or performing any maintenance.
- **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Grille and Blades:** For thorough cleaning, the front grille may be removed (refer to specific instructions if provided with the product for grille removal). Use a vacuum cleaner with a brush attachment or a soft cloth to remove dust from the blades and grilles. Ensure all parts are completely dry before reassembling and operating the fan.
- **Storage:** When not in use for extended periods, store the fan in its original packaging or cover it to protect it from dust. Store in a cool, dry place.

Troubleshooting

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Fan not plugged in. Power button not pressed.	Check if the power outlet is working. Ensure the power cord is securely plugged in. Press one of the speed buttons (1, 2, or 3).
Weak airflow.	Fan speed set too low. Grille or blades are dirty.	Increase the fan speed. Clean the fan grille and blades as per maintenance instructions.
Fan is noisy.	Loose parts. Fan not on a stable surface.	Check for any loose components. Place the fan on a flat, stable surface.
Oscillation not working.	Oscillation knob not engaged.	Ensure the oscillation knob on top of the motor housing is pressed down.

Specifications

Feature	Detail
Brand	BLAUPUNKT
Model Number	ATF401
Electric Fan Design	Table Fan
Power Source	Corded Electric
Wattage	45 watts
Number of Blades	3
Mounting Type	Tabletop Mount
Recommended Use	Air Circulation
Special Feature	Portable
Product Dimensions	19.69 x 19.69 x 11.02 inches

Warranty Information

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or contact Blaupunkt customer support. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or spare parts, please contact Blaupunkt customer service. Contact details can typically be found on the official Blaupunkt website or on the product packaging. *Please have your model number (ATF401) and purchase date available when contacting support.*

© 2023 Blaupunkt. All rights reserved.