BALDERIA EF279A-MT279C

BALDERIA Aidan Electric Fireplace User Manual

Model: EF279A-MT279C

1. Introduction

Thank you for choosing the BALDERIA Aidan Electric Fireplace. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new electric fireplace. Please read all instructions carefully before use and retain this manual for future reference.

Figure 1.1: BALDERIA Aidan Electric Fireplace

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this fireplace.
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the fireplace.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the fireplace is left operating and unattended.
- Do not operate any fireplace with a damaged cord or plug, or after the fireplace malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- Never locate fireplace where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect fireplace, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fireplace.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This fireplace has an automatic overheat protection system. If the heater overheats, the system will automatically shut off the heater.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- The fireplace does not burn fossil fuels and produces no emissions, soot, or dangerous carbon monoxide. It is safe for children and pets.

3. Package Contents

Please check that all components are present and undamaged:

- BALDERIA Aidan Electric Fireplace Unit
- Remote Control
- Mounting Hardware (screws, wall anchors)
- User Manual

4. Product Overview

The BALDERIA Aidan electric fireplace features a realistic 3D flame effect, 2000W heating capability, and ambient LED lighting. It is designed for wall-mounted installation and can be controlled via the integrated control panel or the included remote control.

Figure 4.1: Control Panel and Remote Control Overview

1. Reset Button
2. Heating Display
3. Light Switch
4. Main Power Switch
5. Ambient Lighting Control
6. LED Log Bed
7. Flame Image Control



Figure 4.2: Key Features - Cool Flame, 2000W Power, Overheat Protection, Mains Power

5. Installation

The BALDERIA Aidan electric fireplace is designed for wall-mounted installation. Ensure you have appropriate tools and follow local building codes.

5.1 Dimensions

Before installation, verify the dimensions to ensure proper placement and clearance.

Figure 5.1: Product Dimensions (Width: 1000mm, Height: 632mm, Depth: 240mm)

5.2 Mounting Instructions

1. Choose a suitable wall location, ensuring it is structurally sound and away from combustible materials.
2. Mark the desired mounting height and positions for the mounting brackets using the provided template (if included) or by measuring the unit.
3. Drill pilot holes and insert wall anchors if necessary.
4. Securely attach the mounting brackets to the wall using the provided screws.
5. Carefully lift the fireplace unit and hook it onto the installed wall brackets. Ensure it is securely seated.
6. Connect the power cable to a standard electrical outlet.

6. Operation

Your BALDERIA Aidan electric fireplace can be operated using the control panel on the unit or the included remote control.

6.1 Powering On/Off

- To turn on the fireplace, press the Main Power Switch (4) on the control panel or the power button on the remote control.
- To turn off, press the same button again.

6.2 Electric Heating

The fireplace features a 2000W heater with adjustable heat levels and a thermostat.

- Press the 'Heat' button on the remote or control panel to activate the heating function.
- Use the '+' and '-' buttons to adjust the desired temperature setting.
- The heating display (2) will show the current settings.

6.3 Flame Effects

Experience a realistic 3D flame effect with multiple color and intensity options.

Figure 6.1: Flame Effect in 3 Colors

Figure 6.2: Flame Intensity Adjustable in 5 Levels

- Press the 'Flame' button (7) on the control panel or remote to cycle through flame colors and effects.
- Use the intensity adjustment buttons on the remote to change the brightness of the flames.

Your browser does not support the video tag.

Video 6.1: Demonstration of the BALDERIA Aidan Electric Fireplace flame effects.

6.4 LED Ambient Lighting

Enhance your room's ambiance with 13 different LED lighting colors.

Figure 6.3: Ambient Lighting in 13 Colors

- Press the 'Light' button (5) on the control panel or remote to cycle through the 13 ambient LED colors.
- Press the 'Light Switch' (3) to turn the ambient lighting on or off.

6.5 Timer Function

Set a timer for automatic shutdown of the fireplace.

- Press the 'Timer' button on the remote control to activate and adjust the timer settings.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your fireplace.

7.1 Cleaning

- Always unplug the fireplace from the power outlet before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- Gently clean the glass panel with a glass cleaner and a soft cloth.
- Ensure all vents are clear of dust and debris to maintain proper airflow.

7.2 Storage

If storing the fireplace for an extended period, ensure it is clean and dry. Store in a cool, dry place, preferably in its original packaging.

8. Troubleshooting

If you encounter any issues, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power supply. Main power switch off.	Check power cord connection. Ensure main power switch is ON. Check household circuit breaker.
No heat output.	Heater function not activated. Overheat protection triggered.	Activate heater function via remote or control panel. Allow unit to cool down if overheat protection was triggered. Ensure vents are not blocked.
Flame effect not working.	Flame effect turned off. LED components malfunction.	Ensure flame effect is activated. If problem persists, contact customer support.
Remote control not working.	Batteries depleted. Obstruction between remote and unit.	Replace remote control batteries. Ensure clear line of sight to the fireplace's receiver.

9. Specifications

Detailed technical specifications for the BALDERIA Aidan Electric Fireplace:

Feature	Specification
Brand	BALDERIA
Model Number	EF279A-MT279C
Power Source	Electric Cable
Product Dimensions (D x W x H)	25P x 127l x 58,9H centimeters (approx. 9.8 x 50 x 23.2 inches)
Material	Engineered Wood
Finish Type	Lacquered
Installation Type	Wall Mount
Heat Output	2 Kilowatts (2000W)
Special Feature	Easy to Use, 3D Flame Effect, LED Lighting, Remote Control, Timer, Thermostat
Color	White
Room Type	Living Room
Ventilation Type	Ventless
Heating Coverage	Up to 30 m^2
Orientation	Vertical
Heating Element Type	Ceramic
Item Shape	Rectangular Parallelepiped
Item Weight	34 Kilograms (approx. 75 lbs)
Chamber Depth	24 Centimeters (approx. 9.4 inches)

10. Warranty and Support

This product comes with a limited warranty. For detailed warranty information or technical support, please refer to the warranty card included with your purchase or contact BALDERIA customer service through the retailer where the product was purchased.