Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER QS-2615BA

PKPOWER AC Power Cord for Ridgeway QS-2615BA Speaker - Instruction Manual

Model: QS-2615BA

1. Important Safety Information

- **Read all instructions:** Before using the power cord, read and understand all safety and operating instructions.
- **Proper Voltage:** Ensure the power source voltage matches the requirements of your device (100-240V, 50-60Hz).
- **Avoid Overloading:** Do not overload wall outlets or extension cords. This can result in a risk of fire or electric shock.
- **Protection:** This product features Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP). However, always use with caution.
- **Handle with Care:** Do not bend, twist, or pull the power cord excessively. Avoid placing heavy objects on the cord.
- **Indoor Use Only:** This power cord is designed for indoor use. Do not expose to rain or moisture.
- **Unplug When Not in Use:** Disconnect the power cord from the outlet when not in use for extended periods.
- **Damaged Cords:** Do not operate any appliance with a damaged cord or plug. Contact customer support for replacement.

2. Product Overview

The PKPOWER AC Power Cord is designed to provide reliable power to compatible electronic devices, such as the Ridgeway QS-2615BA 15-inch Rechargeable Portable Bluetooth PA Speaker. This power cord is built to meet or exceed OEM specifications and includes multiple safety features.



Figure 2.1: PKPOWER AC Power Cord showing the male plug (left) and female connector (right).

Key Features:

- **Input:** 100-240V 50-60Hz, suitable for global use.
- **Certifications:** CE / FCC / RoHS certified, ensuring quality and safety standards.
- **Safety Protection:** Equipped with Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your devices.
- **Compatibility:** Specifically designed for devices requiring a standard AC power input, including the Ridgeway QS-2615BA speaker.



Figure 2.2: The PKPOWER AC Power Cord, illustrating its use with various compatible devices such as monitors, desktop computers, kettles, and projectors.

3. Setup Instructions

Follow these steps to properly connect your PKPOWER AC Power Cord to your device and power source.

1. **Identify Ports:** Locate the AC power input port on your device (e.g., Ridgeway QS-2615BA speaker) and an available standard wall outlet.
2. **Connect to Device:** Insert the female end of the PKPOWER AC Power Cord firmly into the AC power input port of your device. Ensure a snug fit.
3. **Connect to Power Source:** Insert the male plug end of the PKPOWER AC Power Cord into a standard, grounded wall outlet.
4. **Verify Connection:** Ensure both ends of the power cord are securely connected.
5. **Power On Device:** Once the power cord is connected, you may power on your device according to its own operating instructions.

Note: Always ensure your device is turned off before connecting or disconnecting the power cord to prevent potential damage.

4. Operating Instructions

The PKPOWER AC Power Cord functions as a direct power supply. Once properly connected as described in the "Setup Instructions" section:

- The power cord will supply the necessary AC power from the wall outlet to your compatible device.
- Your device will draw power as needed for operation or charging (if applicable).
- To discontinue power, simply unplug the cord from the wall outlet first, then from the device.

No specific operational steps are required for the power cord itself beyond proper connection and disconnection.

5. Maintenance

Proper maintenance ensures the longevity and safe operation of your power cord.

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cord and connectors with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or kinking, which can damage the internal wires. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the power cord for any signs of damage, such as cuts, fraying, or bent pins. If any damage is observed, discontinue use immediately and replace the cord.

6. Troubleshooting

If you encounter issues with your power cord, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not receiving power.	Cord not fully plugged in. Wall outlet is not active. Cord is damaged. Device power switch is off.	Ensure both ends of the cord are securely connected. Test the wall outlet with another device or check the circuit breaker. Inspect the cord for visible damage. If damaged, replace it. Ensure the device's power switch is in the "ON" position.
Cord feels warm during use.	Normal operation (slight warmth). Overload or faulty connection.	Slight warmth is normal. If it's excessively hot, unplug immediately. Ensure the device's power requirements do not exceed the cord's rating. Check connections for looseness.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Brand	PKPOWER
Model Compatibility	Ridgeway QS-2615BA, QS2615BA 15" inch Rechargeable Portable Bluetooth PA Speaker
Input Voltage	100-240V AC
Frequency	50-60Hz
Connector Gender	Male-to-Female
Item Length	15 Inches
Item Weight	3 ounces
Certifications	CE / FCC / RoHS

Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)

8. Warranty and Support

PKPOWER is committed to providing high-quality products and excellent customer service.

After-Sale Service:

Our friendly and reliable customer service team is available to assist you with any questions or concerns. We aim to respond to all inquiries within 24 hours.

For support, please contact the seller directly through the platform where you purchased the product or refer to the contact information provided with your purchase.

Return Policy:

This product typically comes with a 30-day return policy for refund or replacement. Please refer to your purchase details for specific terms and conditions.

© 2024 PKPOWER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08FM5NJM5

More documents and user manuals: **https://manuals.plus/**