Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK HPBT010SP

LEXiBOOK Spiderman 2-in-1 Bluetooth Headphones User Manual

Model: HPBT010SP

1. Introduction

Thank you for purchasing the LEXiBOOK Spiderman 2-in-1 Bluetooth Headphones. These headphones are designed for children, offering both wireless Bluetooth 5.0 connectivity and a wired option via a removable jack cable. They feature a sound limit of 85 dB to protect children's hearing and come with a built-in microphone for calls and controls for music playback.

2. Safety Information

Please read this safety information carefully before using the headphones.

- **Age Recommendation:** Suitable for ages 3 years and up.
- **Volume Limit:** The headphones are designed with a built-in sound limit of 85 dB to protect children's ears. Do not attempt to bypass or modify this safety feature.
- **Choking Hazard:** Keep small parts, such as the removable cable, away from very young children to prevent choking.
- **Battery Safety:** The headphones contain a rechargeable Lithium Polymer battery. Do not expose to extreme temperatures, puncture, or disassemble. Dispose of batteries responsibly according to local regulations.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use liquid cleaners or immerse in water.

3. Features

- **2-in-1 Connectivity:** Listen wirelessly via Bluetooth 5.0 (up to 10m range) or wired with the included 3.5mm jack cable.
- **Kids Safe:** Sound output is limited to 85 dB to protect children's hearing.
- **Integrated Controls:** Built-in microphone, play/pause, and volume buttons for easy control of music and phone calls.
- **Wide Compatibility:** Compatible with all smartphones, tablets, audio, and video players equipped with Bluetooth or a 3.5mm audio jack output.
- **Rechargeable Battery:** Offers several hours of battery life in wireless mode. Unlimited playtime in wired mode.
- **Design:** Features a Spiderman theme, robust, lightweight, foldable, and adjustable for various head sizes.

4. Package Contents

Please check that all items are present in the package:

- LEXiBOOK Spiderman 2-in-1 Bluetooth Headphones
- USB Charging Cable
- 3.5mm Audio Jack Cable
- User Manual (this document)

5. Setup

5.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the supplied USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will typically turn red while charging and turn off or change color when fully charged.



Image: The LEXiBOOK Spiderman headphones shown with their charging cable and audio jack cable, indicating connectivity options.

5.2 Bluetooth Pairing (Wireless Mode)

1. Ensure the headphones are charged.
2. Press and hold the Power button on the headphones until the LED indicator light flashes blue and red, indicating pairing mode.

3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings and turn Bluetooth on.
4. Search for available devices. The headphones should appear as "LEXiBOOK HPBT010SP" or similar.
5. Select the headphones from the list to pair. Once successfully paired, the LED indicator will typically show a solid blue light or flash slowly.




Image: A close-up view of the headphone earcup, highlighting the control buttons for power, volume, and track control, along with the charging port and audio jack input.

5.3 Wired Connection

To use the headphones in wired mode, simply plug the 3.5mm audio jack cable into the audio input port on the

headphones and the other end into the audio output jack of your device. The headphones will automatically switch to wired mode, and no battery power is required for this connection.



Image: The LEXiBOOK Spiderman headphones with the 3.5mm audio jack cable prominently displayed, illustrating the wired connection option.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Press and hold the Power button until the LED indicator lights up.

- **Power Off:** Press and hold the Power button until the LED indicator turns off.

6.2 Music Playback (Wireless Mode)

- **Play/Pause:** Press the Play/Pause button once.
- **Next Track:** Press the "Next Track" button (usually labeled with a forward arrow).
- **Previous Track:** Press the "Previous Track" button (usually labeled with a backward arrow).
- **Volume Up:** Press the Volume Up button (+).
- **Volume Down:** Press the Volume Down button (-).




Image: A detailed view of the headphone earcup, illustrating the various control buttons for media playback and volume adjustment.

6.3 Call Handling (Wireless Mode)

- **Answer/End Call:** Press the Play/Pause button once during an incoming call to answer, and press again to end the call.
- **Reject Call:** Press and hold the Play/Pause button for a few seconds during an incoming call to reject it.

6.4 Kids Safe Volume Limit

These headphones are designed with an integrated sound limit of 85 dB to protect children's hearing. This feature is always active and cannot be disabled. This ensures a safe listening experience for extended periods.



Image: The LEXiBOOK Spiderman headphones with an overlay emphasizing the "Kids Safe! 85dB sound limit" feature, highlighting its importance for child safety.

7. Maintenance

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.
- **Cable Care:** Handle the audio and charging cables gently. Avoid sharp bends or excessive pulling to prevent damage.



Image: The LEXiBOOK Spiderman headphones in their folded state, demonstrating their portability and ease of storage.

8. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Battery is low or depleted.	Charge the headphones fully using the supplied USB cable.
Cannot pair via Bluetooth.	Headphones not in pairing mode; Bluetooth off on device; too far from device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn Bluetooth off and on again on your device. Move headphones closer to the device (within 10m).
No sound in wireless mode.	Not paired correctly; volume too low; device output issue.	Re-pair the headphones. Increase volume on both headphones and connected device. Check if audio is playing on the device.
No sound in wired mode.	Audio cable not fully inserted; faulty cable; device output issue.	Ensure the 3.5mm audio cable is fully inserted into both the headphones and the device. Try a different audio cable if available. Check device audio output.
Microphone not working.	Device microphone settings; app permissions.	Check microphone settings on your connected device. Ensure the app you are using has microphone permissions.

9. Specifications

Feature	Detail
Brand	LEXiBOOK
Model Number	HPBT010SP
Connectivity Technology	Wireless (Bluetooth 5.0), Wired (3.5 mm Jack)
Bluetooth Range	Up to 10 meters
Sound Limit	85 dB (Kids Safe)
Battery Type	Lithium Polymer
Battery Life (Wireless)	Approximately 4 hours
Control Type	Volume Control, Play/Pause, Track Skip, Call Handling
Microphone	Built-in
Material	Plastic

Feature	Detail
Item Weight	169 Grams (6 ounces)
Product Dimensions	16.5 x 7.5 x 17 inches
Recommended Age	3 years and up
Color	Red/Blue (Spiderman theme)

10. Warranty and Support

LEXiBOOK products are covered by a limited warranty. Please refer to the warranty card included in your product packaging or visit the official LEXiBOOK website for detailed warranty terms and conditions.
For technical support, troubleshooting assistance, or warranty claims, please contact LEXiBOOK customer service. Contact information can typically be found on the product packaging or the official LEXiBOOK website.
Online Resources:

- Visit the LEXiBOOK Store on Amazon for more products and information.

© 2024 LEXiBOOK. All rights reserved. Spiderman © Marvel.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GPDVHM4

More documents and user manuals: **https://manuals.plus/**