Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OUKITEL WP26

OUKITEL WP26 Rugged Smartphone User Manual

Model: WP26

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your OUKITEL WP26 Rugged Smartphone. Designed for durability and performance, the WP26 features a large battery, powerful camping light, and robust protection against environmental elements. Please read this manual thoroughly before using your device.

Setup

1. Package Contents

Verify that your package contains the OUKITEL WP26 smartphone, a charging adapter, a USB Type-C cable, and this user manual.

2. SIM Card and TF Card Installation

The OUKITEL WP26 supports dual nano-SIM cards or one nano-SIM card and one TF (microSD) card for expanded storage. Locate the SIM tray on the side of the device. Use the provided SIM ejector tool to open the tray. Carefully place your SIM card(s) and/or TF card into the designated slots, ensuring correct orientation. Close the tray securely to maintain water and dust resistance.

3. Initial Charging

Before first use, fully charge your OUKITEL WP26. Connect the USB Type-C cable to the phone's charging port and the other end to the power adapter. Plug the adapter into a wall outlet. The device features a 10000mAh battery, which may take several hours for a full charge.

4. Power On/Off

To power on, press and hold the Power button located on the side of the device until the OUKITEL logo appears. To power off, press and hold the Power button, then select 'Power off' from the options displayed on the screen.

Operating

1. Android 13 Operating System

Your OUKITEL WP26 runs on Android 13, offering an intuitive and secure user experience. Navigate the interface

using touch gestures, access apps from the home screen or app drawer, and customize settings via the 'Settings' application.



Image: The OUKITEL WP26 smartphone showcasing the Android 13 operating system interface.

2. Camping Light Functionality

The OUKITEL WP26 is equipped with a powerful 1200 Lumens camping light. This light offers five distinct modes for various situations:

- **SOS:** For emergency signaling.
- **Full Bright:** Maximum illumination.
- **1/2 Bright:** Moderate illumination.
- **1/4 Bright:** Low illumination for extended use.
- **Explosion Flash:** A rapid, high-intensity strobe.

Access and control the camping light through the dedicated button or a quick settings toggle.



Image: Visual representation of the OUKITEL WP26's camping light modes, including SOS and various brightness levels.



Image: A person utilizing the 1200LM powerful camping light of the OUKITEL WP26 during an outdoor journey.

3. Camera Features

The WP26 is equipped with a 20MP Night Vision camera, allowing for clear photos in low-light conditions. It also features multiple rear cameras for versatile photography and a front camera for selfies and video calls. Explore various camera modes and settings within the camera application.

4. Connectivity

The device supports 4G LTE for fast mobile data, Wi-Fi for wireless internet access, and Bluetooth 5.0 for connecting to accessories. GPS functionality is integrated for navigation. NFC (Near Field Communication) is available for contactless payments and data exchange, compatible with services like Google Pay.

5. Biometric Security

For enhanced security and convenient unlocking, the OUKITEL WP26 includes both fingerprint recognition and Face ID. Set up these features in the 'Security' section of your phone's settings.

6. Battery Management

The 10000mAh battery provides extended usage times. Monitor battery levels and optimize power consumption through the 'Battery' settings. The device also supports fast charging via its USB Type-C port.



Image: The OUKITEL WP26 connected to a charger, illustrating its 10000mAh battery and fast charging capability.

Maintenance

1. Cleaning Your Device

To clean your OUKITEL WP26, use a soft, damp cloth. Avoid harsh chemicals or abrasive materials that could damage the screen or casing. Ensure all port covers are securely closed before cleaning, especially if using a damp cloth.

2. Water, Dust, and Drop Resistance

The WP26 is designed with IP68 waterproof, IP69K dustproof, and MIL-STD-810H drop-proof ratings. This means it can withstand immersion in water, dust ingress, and drops from certain heights. However, these protections are not permanent and may decrease over time with normal wear. Always ensure all port covers are tightly sealed to maintain water and dust resistance. Avoid exposing the device to high-pressure water or extreme temperatures.



Image: The OUKITEL WP26 highlighting its rugged features: MIL-STD-810H drop-proof, IP68 waterproof, and IP69K dustproof.



Image: The 6.78-inch FHD+ display of the OUKITEL WP26, showcasing its visual clarity.

3. Battery Care

To prolong the lifespan of your battery, avoid fully discharging it frequently. Charge the device using only the provided or certified compatible chargers and cables. Extreme temperatures can affect battery performance; avoid exposing the phone to very hot or cold environments for extended periods.

Troubleshooting

1. Device Not Powering On

Ensure the battery is sufficiently charged. Connect the phone to its charger and wait a few minutes before attempting to power it on again. If the issue persists, try a different charging cable and adapter.

2. Poor Network Signal

Check if your SIM card is correctly inserted. Ensure you are within an area with network coverage. Try restarting the device. If the problem continues, contact your mobile service provider.

3. Apps Crashing or Freezing

Close and reopen the problematic app. Clear the app's cache and data through 'Settings > Apps'. If the issue persists, uninstall and reinstall the app. Ensure your device's software is up to date.

4. Device Overheating

Excessive use of demanding applications or prolonged charging can cause the device to warm up. If it becomes excessively hot, close background apps, disconnect from charging, and allow it to cool down. Avoid using the phone in direct sunlight or hot environments.

5. Factory Reset

As a last resort for persistent software issues, you may perform a factory reset. This will erase all data on your device. Back up all important information before proceeding. Navigate to 'Settings > System > Reset options > Erase all data (factory reset)'.

Specifications

Feature	Specification
Model	OUKITEL WP26
Operating System	Android 13
Processor	MediaTek Helio P90
RAM	16GB (8GB + 8GB Extended)
Internal Storage	256GB
Display	6.78-inch FHD+ (2408x1080)
Battery Capacity	10000mAh
Rear Camera	20MP Night Vision + Multiple Lenses
Front Camera	5MP
Camping Light	1200 Lumens, 5 Modes
Ruggedness	IP68 Waterproof, IP69K Dustproof, MIL-STD-810H Drop-proof
Connectivity	4G LTE, Wi-Fi, Bluetooth 5.0, GPS, NFC, OTG
SIM Card Slot	Dual Nano-SIM or 1 Nano-SIM + 1 TF Card
Biometric Security	Fingerprint Recognition, Face ID



Image: The OUKITEL WP26's internal components, highlighting the MediaTek Helio P90 processor for fast and solid performance.

Warranty and Support

1. Warranty Information

Your OUKITEL WP26 smartphone is covered by a 12-month warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

2. Technical Support

OUKITEL provides lifetime technical support for your device. If you encounter any issues not covered in this manual or require further assistance, please contact OUKITEL customer service. Refer to the official OUKITEL website for the most up-to-date contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HQH1XGF

More documents and user manuals: **https://manuals.plus/**