Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Minecraft 16213

Minecraft Storage Bin Cube Organizer User Manual

Model: 16213 | Brand: Minecraft

1. Product Overview

The Minecraft Grass Block Storage Bin is a versatile and fun solution for organizing various items. Designed with the iconic Minecraft grass block texture, it adds a playful touch to any room while providing practical storage. This 15-inch cube is engineered for convenience, featuring a foldable design for easy storage when not in use and built-in handles for effortless portability.



Figure 1.1: Fully assembled Minecraft Grass Block Storage Bin with its lid securely in place.

2. Product Features

- **Thematic Design:** Features an authentic Minecraft grassy block texture, blending organization with popular gaming aesthetics.
- **Space-Saving Foldable Design:** The 15-inch cube can be easily folded flat for compact storage when not in use, maximizing space efficiency.
- **Integrated Base Support:** Includes an MDF insert that provides robust support for the base when the bin is expanded, ensuring stability.
- **Convenient Portability:** Equipped with built-in handles on the sides, allowing for easy lifting and relocation of the bin.
- **Multi-purpose Functionality:** Ideal for storing toys, clothing, gaming accessories, or other household items. Its sturdy construction also allows it to function as an ottoman or extra seating.

- **Official Licensing:** This storage cube is an officially licensed Minecraft product.



Figure 2.1: Visual representation of key product features, including design, size, and convenience aspects.

3. Setup and Assembly

The Minecraft Grass Block Storage Bin is designed for quick and easy assembly. No tools are required.

1. **Unfold the Bin:** Carefully remove the bin from its packaging. It will arrive in a folded, flat configuration. Gently unfold the main body of the bin to form a cube shape.
2. **Insert Base Support:** Locate the rigid MDF insert. Place this insert at the bottom of the unfolded bin. Push it down firmly to ensure it lies flat and provides a stable base for the bin.
3. **Place the Lid:** Position the lid securely on top of the assembled bin. The lid is designed to fit snugly, providing a covered storage solution.




Figure 3.1: The storage bin with its lid slightly ajar, demonstrating the separate lid component.



Figure 3.2: The storage bin with the lid fully removed, showing the open top for easy access.

4. Operating Instructions

Using your Minecraft Grass Block Storage Bin is straightforward:

- **Storage:** Lift the lid to place items inside the bin. Replace the lid to keep contents out of sight and maintain a tidy appearance.
- **Portability:** Utilize the built-in handles on the sides to easily move the bin between rooms or locations.
- **Seating/Footrest:** Due to its sturdy construction, the bin can be used as a temporary seat or footrest. Ensure the lid is securely in place before use.
- **Folding for Storage:** To fold the bin flat, remove the lid and the MDF base insert. Collapse the sides of the bin inward. Place the base insert and lid on top of the folded bin for compact storage.



Figure 4.1: The storage bin in use, demonstrating its capacity for holding items such as plush toys.

5. Care and Maintenance

To ensure the longevity and appearance of your Minecraft Grass Block Storage Bin, follow these care instructions:

- **Cleaning:** Wipe the exterior and interior surfaces with a damp cloth. For tougher spots, a mild soap solution can be used, followed by wiping with a clean, dry cloth.
- **Drying:** Allow the bin to air dry completely before closing the lid or storing items inside to prevent mold or mildew.
- **Water Resistance:** This product is **not water resistant**. Avoid exposing it to excessive moisture or liquids. Do not submerge in water.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or strong chemical solvents, as these can damage the material and finish.
- **Storage:** When not in use, store the bin in a dry, cool place, ideally in its folded state to protect its structure.

6. Troubleshooting

Most issues with the Minecraft Grass Block Storage Bin are minor and easily resolved:

Problem	Possible Cause	Solution
Bin does not stand upright or is wobbly.	Base insert not properly seated.	Ensure the MDF base insert is pushed firmly to the bottom of the bin and lies flat.
Lid does not fit properly.	Bin not fully expanded or items inside are too tall.	Make sure the bin is fully unfolded and the base is flat. Adjust contents if they are preventing the lid from closing.
Bin appears creased or misshapen.	Prolonged storage in a folded state or heavy items placed on top.	Fill the bin with items to help it regain its shape. Avoid placing excessively heavy objects on the bin when it's empty or folded.

7. Specifications

Attribute	Detail
Brand	Minecraft
Model Number	16213
Product Dimensions	15"L x 15"W x 15"H
Capacity	15 Inches (referring to its cubic dimensions)
Item Weight	5.39 pounds (approx. 2.45 Kilograms)
Material	Minecraft-themed, simulated block texture (fabric over rigid structure, likely MDF)
Color	Brown (referring to the dirt block part) / Green (referring to the grass top)
Special Feature	Foldable
Closure Type	Flip Top / Lift-Off Lid
Water Resistance Level	Not Water Resistant
Manufacturer	Robe Factory LLC
UPC	886388162130
Date First Available	September 12, 2020

8. Warranty and Support

For any questions regarding your Minecraft Storage Bin Cube Organizer, including product information, care, or potential defects, please contact the manufacturer directly.
Manufacturer: Robe Factory LLC
Please retain your proof of purchase for any warranty claims or support inquiries.

© 2024 Minecraft / Robe Factory LLC. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HX9ZLW3

More documents and user manuals: **https://manuals.plus/**