Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEXiBOOK HPBT010S

Lexibook Acoustix 2-in-1 Bluetooth Headphones User Manual

Model: HPBT010S | Brand: LEXiBOOK

Introduction

Welcome to the user manual for your Lexibook Acoustix 2-in-1 Bluetooth Headphones. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your headphones. Please read it carefully to ensure optimal performance and longevity of your device.

Product Overview

What's in the Box

- Lexibook Acoustix 2-in-1 Bluetooth Headphones
- Removable 3.5mm Jack Cable
- Built-in Microphone (integrated)
- Charging Cable (USB)

Key Features

- **2-in-1 Connectivity:** Listen wirelessly via Bluetooth 5.0 or wired with the included 3.5mm jack cable.
- **Integrated Controls:** Built-in microphone, play/pause, and volume buttons for easy music and call management.
- **Rechargeable Battery:** Offers several hours of wireless playback. Unlimited use in wired mode.
- **Durable & Portable:** Robust, lightweight, and foldable design for easy transport and storage.
- **Adjustable Fit:** Adapts to various head sizes for comfortable wear by adults, teens, and children.





Image: The Lexibook Acoustix 2-in-1 Bluetooth Headphones, showcasing their sleek white and silver design.



Image: The headphones highlighting their dual wireless and wired capabilities, branded as 'Acoustix Freedom'.

Setup

Charging the Headphones

1. Locate the charging port on your headphones (usually a micro-USB or USB-C port).
2. Connect the provided USB charging cable to the headphones and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator on the headphones will typically show red during charging and turn off or change color (e.g., blue) when fully charged.
4. A full charge provides several hours of wireless playback.

Adjusting the Fit

The headband of your Acoustix headphones is adjustable. Gently slide the earcups up or down along the headband to achieve a comfortable and secure fit over your ears. Ensure the earcups fully cover your ears for optimal sound quality and comfort.

Operating Instructions

Power On/Off

- **To Power On:** Press and hold the Power button (refer to controls diagram) for approximately 3-5 seconds until the LED indicator lights up and/or you hear an audible prompt.
- **To Power Off:** Press and hold the Power button for approximately 3-5 seconds until the LED indicator turns off and/or you hear an audible prompt.

Bluetooth Pairing (Wireless Mode)

1. Ensure the headphones are powered off.
2. Press and hold the Power button for about 5-7 seconds until the LED indicator flashes rapidly (often blue and red alternately), indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for new devices.
4. Select "Lexibook Acoustix" or "HPBT010S" from the list of available devices.
5. Once connected, the LED indicator will typically slow its flashing or turn solid blue. You will hear a confirmation tone.
6. The headphones have a Bluetooth 5.0 range of up to 10 meters (33 feet).

Wired Mode Connection

To use the headphones in wired mode, simply plug one end of the provided 3.5mm audio jack cable into the headphone's audio input port and the other end into the 3.5mm audio output of your device. The headphones will automatically switch to wired mode, and no battery power is required for this operation.

Controls



Image: A detailed view of the headphone's control panel, indicating buttons for track navigation, volume adjustment, power, and call management.

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Microphone:** Integrated for hands-free calling.



Image: A user enjoying music or working with the Lexibook Acoustix headphones while using a laptop in an outdoor setting.




Image: A woman wearing the Lexibook Acoustix headphones, demonstrating their comfortable fit and stylish appearance during use.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents. For earcups, a slightly damp cloth can be used, but ensure no moisture enters the speaker grilles.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To preserve battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not used for extended periods.



Image: The Lexibook Acoustix headphones in their folded position, illustrating their portability and ease of storage.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headphones won't turn on	Low battery	Charge the headphones fully.
Cannot pair via Bluetooth	Headphones not in pairing mode / Device Bluetooth off / Too far from device	Ensure headphones are in pairing mode (flashing LED). Turn device Bluetooth off/on. Move headphones closer to device (within 10m).
No sound in wireless mode	Not connected / Volume too low / Paused	Verify Bluetooth connection. Increase volume on headphones and device. Check if music is paused.
No sound in wired mode	Cable not fully inserted / Cable damaged / Device volume too low	Ensure 3.5mm cable is fully inserted into both headphone and device. Try a different 3.5mm cable. Increase volume on device.
Poor sound quality	Weak Bluetooth signal / Audio source quality / Earcup fit	Move closer to the Bluetooth device. Try a different audio source. Adjust headphones for a better fit.

Technical Specifications

Feature	Specification
Model Name	HPBT010S
Connectivity Technology	Wired, Wireless (Bluetooth 5.0)
Wireless Communication Range	Up to 10 meters (33 feet)
Included Components	Cable, Built-in Microphone
Frequency Range	20 Hz - 20,000 Hz
Battery Capacity	900 mAH (Rechargeable)
Material	Plastic
Item Weight	0.32 Pounds (5.1 ounces)
Product Dimensions	16.5 x 7.5 x 17 inches
Color	White
Ear Placement	Over Ear
Manufacturer Recommended Age	3 years and up

Warranty and Support

Your Lexibook Acoustix 2-in-1 Bluetooth Headphones come with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical support, warranty claims, or any questions regarding your product, please contact Lexibook customer service. Refer to the contact information provided on the product packaging or the official Lexibook website for the most up-to-date support details.

Image: The official Lexibook brand logo.

© 2024 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08K35M4BZ

More documents and user manuals: **https://manuals.plus/**