Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CHUWI CoreBook X

CHUWI CoreBook X 14-inch Laptop User Manual

Model: CoreBook X

1. Introduction

Thank you for choosing the CHUWI CoreBook X laptop. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual carefully before using your laptop to ensure optimal performance and longevity.

1.1 Safety Information

- Do not expose the laptop to extreme temperatures, direct sunlight, or high humidity.
- Avoid placing heavy objects on the laptop.
- Use only the original power adapter provided with the device.
- Keep the laptop away from water or other liquids.
- Do not attempt to disassemble or repair the laptop yourself. Contact authorized service personnel for assistance.
- Ensure proper ventilation when using the laptop to prevent overheating.

2. Product Overview

The CHUWI CoreBook X is a high-performance 14-inch laptop designed for productivity and entertainment, featuring an Intel Core i5 processor, a 2K display, and a lightweight metal body.

2.1 Package Contents

- CHUWI CoreBook X Laptop
- Power Adapter
- User Manual (this document)

2.2 Laptop Components

Familiarize yourself with the various ports and features of your CoreBook X.



Image Description: A close-up view of the CHUWI CoreBook X laptop's left and right sides, highlighting its various ports. On one side, a headphone jack, TF Card Slot, and a full-function Type-C port are visible. On the other side, a USB 3.0 port, a DC Charge port, and another Type-C port are shown, illustrating the comprehensive connectivity options.

The CoreBook X offers a range of connectivity options to suit your needs:

- **USB-C (Full-Function):** Supports data transfer, video output (up to 4K 60Hz), and charging via USB-PD 2.0.
- **USB-A 3.0:** For connecting standard USB devices.
- **MicroSD Card Slot:** For expanding storage or transferring files from memory cards.
- **3.5mm Headphone Jack:** For audio output.
- **DC-in Port:** For charging the laptop with the provided power adapter.

▶ **Watch video online**
CHUWI CoreBook X i5 Laptop

Video Description: An official product video showcasing the CHUWI CoreBook X i5 Laptop. The video highlights key features such as its slim design, display quality, keyboard, and overall performance, providing a visual overview of the device's capabilities and aesthetics.

3. Setup

3.1 Connecting the Power Adapter

1. Connect the power adapter to the DC-in port on the side of your laptop.
2. Plug the other end of the power adapter into a wall outlet.

3. The battery indicator light (if present) will illuminate to show that the laptop is charging.




Image Description: A side view of the CHUWI CoreBook X laptop, illustrating its USB-C port being used for charging. A charging cable is plugged into the port, with visual effects indicating power flow, emphasizing the laptop's modern USB-C charging capability.

3.2 First-Time Power On

1. Ensure the laptop is connected to the power adapter or has sufficient battery charge.
2. Open the laptop lid.
3. Press the power button, usually located on the top-right of the keyboard area.
4. The laptop will power on, and you will see the CHUWI logo, followed by the Windows setup screen.

3.3 Initial Windows Setup

Follow the on-screen instructions to complete the Windows setup process. This typically includes:

- Selecting your region and language.
- Connecting to a Wi-Fi network.
- Accepting the license agreement.
- Creating a user account or signing in with a Microsoft account.
- Setting up privacy settings.

4. Operating Your Laptop

4.1 Power Management

- **Power On:** Press the power button.
- **Sleep Mode:** Briefly press the power button while the laptop is on, or close the lid. Press the power button again or open the lid to wake it up.
- **Shut Down:** Click the Windows Start button > Power > Shut down.
- **Restart:** Click the Windows Start button > Power > Restart.

4.2 Keyboard Usage

The CoreBook X features a full-size keyboard with a backlight for comfortable typing in various lighting conditions.



Image Description: A top-down view of the CHUWI CoreBook X laptop's keyboard, illuminated by its white backlight. The keys are clearly visible against the dark chassis, highlighting the backlit feature for use in low-light environments.

- **Function Keys (Fn):** Many keys have dual functions. Press and hold the **Fn** key (usually near the bottom-left)

and then press the desired function key (F1-F12) to activate its secondary function (e.g., volume control, screen brightness, Wi-Fi toggle).

- **Backlight Control:** Use the appropriate Fn key combination (refer to keyboard icons, often Fn + F5 or F6) to adjust the keyboard backlight brightness or turn it on/off.

▶ **Watch video online**
CoreBook X i5 laptop with 14 inch 2K resolution display

Video Description: An official product video demonstrating the features of the CoreBook X i5 laptop, specifically highlighting its 14-inch 2K resolution display and the functionality of its backlit keyboard. The video provides close-ups of the screen clarity and the keyboard illumination.

4.3 Touchpad Usage

The integrated touchpad supports multi-touch gestures for intuitive navigation:

- **Single Tap:** Left-click.
- **Two-Finger Tap:** Right-click.
- **Two-Finger Scroll:** Scroll up/down or left/right.
- **Pinch-to-Zoom:** Zoom in or out on documents and web pages.

4.4 Display Settings

Your CoreBook X features a 14-inch 2160x1440 IPS display with a 3:2 aspect ratio.



Image Description: A dynamic image showcasing the CHUWI CoreBook X laptop with its screen displaying vibrant, abstract colors. Text overlays highlight its

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KZRZ63G

More documents and user manuals: **https://manuals.plus/**