Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eureka P1002 (Compatible with NEC280TL, NEC285GR, NEC180)

Eureka Non Woven Filter Components User Manual

Model: P1002

Compatible with Eureka Cordless Stick Vacuums: NEC280TL, NEC285GR, NEC180

1. Product Overview

The Eureka Non Woven Filter Component (Model P1002) is a genuine replacement part designed to maintain the optimal performance of your Eureka Cordless Stick Vacuum. This filter is specifically engineered to fit models NEC280TL, NEC285GR, and NEC180, ensuring efficient dust and debris capture and consistent suction power.



Figure 1: Eureka Non Woven Filter Component. This image shows the circular filter with a black rubber frame, featuring a blue mesh on the top half and a white non-woven material on the bottom half, designed for trapping fine particles.

2. Installation

Proper installation of the filter is crucial for your vacuum's performance and longevity. Always ensure the vacuum is turned off and unplugged (if applicable) before attempting any maintenance.

2.1. Filter Replacement Steps

1. **Power Off:** Ensure your Eureka Cordless Stick Vacuum is powered off and disconnected from its charging base or power source.
2. **Locate Dust Cup:** Detach the dust cup from the main body of the vacuum cleaner. Refer to your vacuum's specific user manual for instructions on dust cup removal.
3. **Remove Old Filter:** Carefully remove the existing filter from the dust cup. It may be secured by a twist or pull mechanism. Note its orientation for correct installation of the new filter.
4. **Clean Dust Cup:** Empty any debris from the dust cup and wipe it clean with a dry cloth.
5. **Install New Filter:** Insert the new Eureka Non Woven Filter Component (P1002) into the dust cup. Ensure it is seated firmly and correctly, matching the orientation of the filter you removed.
6. **Reattach Dust Cup:** Reattach the dust cup to the vacuum cleaner, ensuring it clicks securely into place.
7. **Test:** Power on the vacuum to confirm proper operation and suction.

3. Maintenance

Regular cleaning and timely replacement of your filter are essential for maintaining optimal vacuum performance and air quality. This filter is designed to be washable and reusable.

3.1. Cleaning the Filter

1. **Remove Filter:** Follow steps 1-3 from the Installation section to remove the filter from the dust cup.
2. **Tap Out Debris:** Gently tap the filter over a trash can to dislodge loose dust and debris.
3. **Rinse:** Rinse the filter under cool, running water until the water runs clear. Do not use hot water or detergents.
4. **Dry Completely:** Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Ensure it is absolutely dry to prevent mold or damage to the vacuum. Do not use a dryer or direct heat.
5. **Reinstall:** Once completely dry, reinstall the filter as per the Installation section.

Frequency: It is recommended to clean the filter after every 4-6 uses, or more frequently if you notice a decrease in suction or if the filter appears visibly dirty. Replace the filter every 3-6 months, or as needed, depending on usage and household conditions, to ensure peak performance.

4. Troubleshooting

If you experience issues with your vacuum's performance, the filter may be a contributing factor. Here are some common problems and solutions related to the filter:

Symptom	Possible Cause	Solution
Reduced Suction Power	Filter is clogged with dust and debris.	Clean the filter as described in Section 3.1. If cleaning does not restore suction, replace the filter.
Vacuum Emits Dust	Filter is damaged or not installed correctly.	Check filter for tears or damage. Ensure it is seated firmly and correctly in the dust cup. Replace if damaged.
Unusual Odor from Vacuum	Filter is dirty or has absorbed odors.	Clean the filter thoroughly. Ensure it is completely dry before reinstallation. Consider replacing the filter if odors persist.

5. Specifications

Key specifications for the Eureka Non Woven Filter Component (P1002):

- **Manufacturer:** Eureka
- **Part Number:** P1002
- **Item Weight:** 1.76 ounces
- **Product Dimensions:** 4.13 x 4.13 x 0.55 inches (L x W x H)
- **Color:** White and Black
- **Material:** Non woven filter
- **Item Package Quantity:** 1
- **Number Of Pieces:** 1
- **Special Features:** Washable Filter
- **Included Components:** Non woven filter components
- **Compatible Devices:** Eureka Cordless Stick Vacuums NEC180, NEC280TL, NEC285GR
- **Reusability:** Reusable

6. Warranty Information

This Eureka Non Woven Filter Component (P1002) is covered by a**2-year warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, please refer to the official Eureka website or contact customer support.

7. Customer Support

For further assistance, questions, or to purchase additional genuine Eureka parts, please visit the official Eureka website or contact their customer support team.

- **Eureka Official Store:** Visit the Eureka Store on Amazon
- **Online Support:** Refer to the Eureka official website for FAQs and support resources.
- **Contact:** Consult your vacuum's main manual or the Eureka website for direct contact information.

© 2024 Eureka. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L3998M1

More documents and user manuals: **https://manuals.plus/**