Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Haofy B08L6M9L7P

Haofy 200g x 0.01g Pocket Digital Scale User Manual

Model: B08L6M9L7P

Introduction

This user manual provides comprehensive instructions for the proper setup, operation, maintenance, and troubleshooting of your Haofy 200g x 0.01g Pocket Digital Scale. Please read this manual thoroughly before using the device to ensure accurate measurements and prolonged product life.
The Haofy Pocket Digital Scale is designed for precise weighing of small items, such as jewelry, gold, silver, and other gram-level materials, with a high accuracy sensor and a maximum capacity of 200g.

Package Contents

- 1 x Haofy 200g/0.01g Jewelry Pocket Scale
- User Manual (this document)

Note: 2 x AAA batteries are required and are not included in the package.

Setup

1. Battery Installation

The scale requires two AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment on the underside of the scale.
2. Gently slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: Underside of the scale showing the battery compartment. Ensure correct battery polarity when installing.

2. Initial Placement

For accurate readings, place the scale on a hard, flat, and stable surface. Avoid placing it on soft, uneven, or vibrating surfaces. Ensure there are no drafts or air currents that could affect the weighing process.

Operation

1. Power On/Off

- To turn the scale **ON**: Press the **ON/OFF** key. The display will show "88888" and then "0.00g" when ready.
- To turn the scale **OFF**: Press and hold the **ON/OFF** key for a few seconds until the display turns off. The scale will also automatically shut off after a period of inactivity to conserve battery life.

2. Unit Conversion

The scale supports multiple weighing units. To switch between units:

- With the scale turned on, press the **MODE** key repeatedly.
- The display will cycle through the available units: **g** (grams), **oz** (ounces), **gn** (grains), **ct** (carats), **ozt** (troy ounces), and **dwt** (pennyweights).
- Stop pressing the **MODE** key when your desired unit is displayed.

3. Tare Function

The Tare function allows you to subtract the weight of a container or tray, so you can weigh only the contents. The scale's protective flip cover can be used as a weighing tray.

1. Place the empty container or tray on the weighing platform.
2. Wait for the display to stabilize and show the weight of the container.
3. Press the **TARE** key. The display will reset to "0.00g" (or "0.00" in the selected unit).
4. You can now add items to the container, and the scale will display only the net weight of the items.



Image: The scale with its flip cover open, which can be used as a weighing tray.

4. Calibration Adjustment

Calibration and adjustments are performed at the factory. However, the weighing range can shift slightly during shipping or due to changes in local acceleration of gravity. Regular calibration ensures accuracy. It is recommended when moving the scale from one location to another.

1. Press the **ON/OFF** key to turn the scale on.
2. Wait for the display to show "0.00g" then press and hold the **MODE** key until the display shows "**CAL**", then release.
3. Press the **MODE** key again. The display will flash the required calibration weight (e.g., "200.00g").
4. Place the required calibration weight on the center of the platform. The display will show "**PASS**" then return to normal weighing mode. Calibration is complete.



Image: The scale's display and control buttons, with the quick user guide visible on the lid, detailing calibration steps.

Maintenance

- **Cleaning:** The scale is easy to clean. Use a soft, damp cloth to wipe the weighing platform and body. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a cool, dry place. Keep the protective flip cover closed when not in use to prevent dust and damage to the weighing platform.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display or if the scale does not power on. Always use new AAA batteries and dispose of old batteries responsibly.
- **Handle with Care:** Avoid dropping the scale or subjecting it to strong impacts, as this can damage the internal sensor and affect accuracy.

Troubleshooting

Problem	Possible Cause	Solution
Scale does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity or replace with new AAA batteries.
Inaccurate readings.	Unstable surface, drafts, scale not calibrated, overloaded.	Place on a flat, stable surface. Avoid drafts. Perform calibration. Ensure weight is within 200g capacity.
Display shows "Lo".	Low battery power.	Replace batteries.
Display shows "O_LD".	Overload.	Remove excess weight immediately. Do not exceed 200g.

Specifications

Brand	Haofy
Model	B08L6M9L7P
Material	Metal Wire-drawing Stainless Steel, ABS Plastic
Measurement Units	g, oz, gn, ct, ozt, dwt
Display Screen	LCD Display Screen
Graduation Value	0.01g
Maximum Bearing Range	200g

Acceptable Error	0.03g
Power Supply	2 x AAA Batteries (not included)
Battery Life	Approximately 1 Year
Product Dimensions	5.91 x 3.94 x 1.18 inches (15 x 10 x 3 cm)
Item Weight	4.69 ounces (133 grams)

Support

For any questions, concerns, or technical assistance regarding your Haofy Pocket Digital Scale, please contact Haofy customer service. We are committed to providing sincere service and will respond to your inquiries within 24 hours. Please refer to the contact information provided with your purchase or visit the official Haofy store on Amazon:

Visit the Haofy Store

© 2024 Haofy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L6M9L7P

More documents and user manuals: **https://manuals.plus/**