Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NexiGo N660P

NexiGo N660P 1080P 60FPS Webcam User Manual

Model: N660P

1. Introduction

Thank you for choosing the NexiGo N660P 1080P 60FPS Webcam. This manual provides essential information for setting up, operating, and maintaining your webcam to ensure optimal performance. Please read this manual thoroughly before use.

What's in the Box

- NexiGo N660P 1080P 60FPS Webcam (with integrated USB cable)
- Privacy Cover (pre-attached or separate)
- User Manual

2. Product Overview

The NexiGo N660P webcam delivers high-definition video and clear audio for various applications, including video conferencing, streaming, and online education. It features advanced technology for an enhanced user experience.

Key Features

- **Full HD 1080p at 60fps:** Provides crisp, clear video with smooth motion.
- **Autofocus:** Automatically adjusts focus to keep you sharp and clear.
- **Dual Stereo Noise-Cancelling Microphones:** Captures clear audio while reducing background noise.
- **Integrated Privacy Cover:** Ensures your privacy and security when the webcam is not in use.
- **Plug and Play:** No additional drivers required for most operating systems.
- **Wide Compatibility:** Works with Windows, macOS, and various video conferencing platforms.
- **Software Control:** Allows for fine-tuning of image settings.



Image 2.1: The NexiGo N660P webcam mounted on a laptop, displaying a video conference call. This image illustrates the webcam's primary use for online communication.



Image 2.2: A close-up view of a person wearing a headset, with a focus box indicating the webcam's autofocus capability. This highlights the precision of the autofocus technology.

Your browser does not support the video tag.

Video 2.1: An official video introducing the NexiGo N660P Webcam, showcasing its design and key features. This provides a visual overview of the product.

3. Setup

Setting up your NexiGo N660P webcam is a straightforward process. Follow these steps to get started.

3.1 Mounting the Webcam

1. Unfold the flexible clip base of the webcam.
2. Place the webcam on top of your computer monitor, laptop screen, or tripod. Ensure the front of the webcam is facing you.

3. Adjust the clip base so that it securely grips the top of your display. The front of the clip should rest on the front of your monitor, and the rear part should rest against the back.
4. Adjust the angle of the webcam to achieve your desired viewing position.

3.2 Connecting to Your Computer

1. Locate an available USB port on your computer.
2. Plug the USB cable from the NexiGo N660P webcam into the USB port.
3. Your computer should automatically detect and install the necessary drivers. This is a plug-and-play device, so no manual driver installation is typically required.
4. Wait for a few moments for the installation to complete. You may see a notification indicating that the device is ready for use.



Image 3.1: The USB connector of the NexiGo N660P webcam being inserted into a laptop's USB port, demonstrating the plug-and-play setup.

Your browser does not support the video tag.

Video 3.1: An instructional video demonstrating the setup process for the NexiGo N660P webcam, including physical connection and initial use.

4. Operating Instructions

Once your webcam is set up, you can begin using it with your preferred applications.

4.1 Using with Video Conferencing Software

1. Open your video conferencing application (e.g., Zoom, Skype, Microsoft Teams, Google Meet).
2. Navigate to the application's settings or preferences, usually found under

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question