Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Philips Beauty BRE720/14

Philips Epilator Series 8000 Instruction Manual

Model: BRE720/14 | Brand: Philips Beauty

Introduction

The Philips Epilator Series 8000 (Model BRE720/14) is a versatile hair removal device designed for use on the legs and body. This 3-in-1 system offers epilation, shaving, and trimming functionalities, providing long-lasting smooth skin for up to 4 weeks. Its advanced design features ceramic micro-ridged discs and an intuitive usage angle for efficient hair removal, even on shorter hairs.

Key features include wet and dry operation, a built-in light for enhanced visibility, and a cordless design with quick charge capability for convenience.

Safety Information

Keep the device out of reach of children.

Do not use the epilator on irritated skin, varicose veins, moles, or sunburned skin. Consult a doctor if you have any skin conditions or concerns before use.
Ensure the device is fully charged before wet use. Do not use while plugged into a power outlet in wet conditions.
The device operates at 15 volts. Use only with the provided charger.

Package Contents

Your Philips Epilator Series 8000 package includes the following items:

- Philips Epilator Series 8000 main unit
- Epilator head with optimal contact cap
- Delicate area cap
- Shaver head with trimming comb
- Trimming head with bikini comb
- Exfoliation glove

- Drawstring pouch
- Cleaning brush
- Power adapter



Image: Philips Epilator Series 8000 main unit, epilator head, shaver head, trimmer head, various caps, exfoliation glove, and charging cable.

Setup

Charging the Device

Before first use, fully charge your epilator. Connect the power adapter to the device and plug it into a wall outlet. The charging indicator light will show the charging status. A full charge provides up to 40 minutes of cordless usage.

Attaching/Detaching Heads

To attach a head, align it with the main unit and press firmly until it clicks into place. To detach, press the release button (if applicable) and pull the head off.



Image: Close-up view of the epilator head, showing the ceramic discs and built-in light.





Image: The Philips Epilator main unit with the shaver head attachment.




Wet & Dry
PHILIPS



Image: The Philips Epilator main unit with the trimmer head attachment.

Operating Instructions

The Philips Epilator Series 8000 can be used wet or dry. For best results, ensure your skin is clean. You may use it in the shower or bath for a more comfortable experience.

General Usage Tips

- Turn on the device by pressing the power button.
- Select the desired speed setting (Speed I for gentle, Speed II for efficient).
- Hold the epilator at a 90-degree angle to your skin.
- Gently move the epilator against the direction of hair growth.
- The built-in light helps illuminate fine hairs for thorough removal.

Using the Epilator Head

Attach the epilator head. For legs and body, use the optimal contact cap. For delicate areas like underarms or bikini line, use the delicate area cap for extra gentleness.



Image: A woman using the Philips Epilator on her leg, demonstrating the upward motion for hair removal.




Image: A woman using the Philips Epilator on her underarm, highlighting its use in delicate areas.

Using the Shaver Head

Attach the shaver head for a close shave. It can be used wet or dry. Glide the shaver head gently over the skin in the direction of hair growth.

Using the Trimmer Head

Attach the trimmer head with the bikini comb for precise trimming of longer hairs before epilation, or for maintaining the bikini line.

Official Product Video: Philips Epilator Series 8000

▶ **Watch video online**
Philips Epilator Series 8000 Wet & Dry Epilator BRE720/14

Video: An official Philips video demonstrating the features and usage of the Philips Epilator Series 8000, including its wet and dry capabilities, ceramic discs, and various attachments for different body areas.

Maintenance

Cleaning

After each use, clean the epilator head and attachments. Detach the head and use the provided cleaning brush to remove any trapped hairs. The epilator head and shaver head can be rinsed under warm, soapy water. Ensure all parts are completely dry before reattaching or storing.

Storage

Store the epilator and its accessories in the provided drawstring pouch in a dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause / Solution
Device not turning on	Battery may be depleted. Recharge the device. Ensure it is not plugged in during wet use.
Ineffective hair removal	Ensure the epilator is held at a 90-degree angle against the skin and moved against hair growth. Hair might be too short (minimum 0.5mm) or too long (trim longer hairs first). Clean the epilator head.
Discomfort/Pain during epilation	Initial discomfort is normal, especially for new users or sensitive areas. Use the device wet (in shower/bath) for a more comfortable experience. Ensure skin is taut. Use the delicate area cap for sensitive zones.
Skin irritation/redness	Redness is common after epilation and usually subsides quickly. Apply a soothing lotion. Avoid using on irritated or damaged skin.

Specifications

- **Brand:** Philips Beauty
- **Model Number:** BRE720/14
- **Product Dimensions:** 2.56 x 8.27 x 7.28 inches
- **Item Weight:** 1.18 ounces (33.5 Grams)
- **Power Source:** Li-Ion Battery
- **Batteries:** 2 AA batteries required (internal, rechargeable)
- **Water Resistance Level:** Waterproof (Wet & Dry use)
- **Manufacturer:** Philips Norelco
- **Country of Origin:** China

- **First Available Date:** December 29, 2022

Warranty and Support

Philips products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to register your product, please visit the official Philips website or contact Philips customer service.

You can typically find support contact information in the product packaging or on the Philips Beauty website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08LJN1668

More documents and user manuals: **https://manuals.plus/**