Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DERCASS LP000028

DERCASS Twin Over Full Bunk Bed with Playhouse and Slide, White - Instruction Manual

Model: LP000028 | Brand: DERCASS

1. Introduction

Thank you for choosing the DERCASS Twin Over Full Bunk Bed with Playhouse and Slide. This manual provides essential information for the safe assembly, operation, and maintenance of your new bunk bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This bunk bed is designed to provide a fun and functional sleeping solution for children, featuring a unique playhouse design, a secure ladder, and a playful slide.

2. Important Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always assemble according to the provided instructions to prevent instability or collapse.
- Use the guardrails on the upper bunk at all times to prevent falls.
- Do not exceed the weight capacity of **250 lbs** on the upper bed and **250 lbs** on the bottom bed.
- Only mattresses meeting the following specifications should be used:
  - Upper bed: Maximum thickness 6 inches.
  - Bottom bed: Maximum thickness 8 inches.
- Ensure all connections are tight before use and check periodically.
- Do not allow children under 6 years of age on the upper bunk.
- Prohibit more than one person on the upper bunk.
- Always use the ladder for entering and exiting the upper bunk.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.
- Keep these instructions for future reference.

3. Package Contents

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.

- Bed Frame Components (Plywood, MDF, Pinewood)
- Ladder
- Slide (if applicable to your model)
- Guardrails
- Slats for Upper Bed (14 pieces)
- Slats for Bottom Bed (7 pieces)
- Hardware Pack (screws, bolts, nuts, etc.)
- Assembly Manual (this document)

The product is shipped in 3 packages. Please ensure all packages have arrived before starting assembly.

4. Setup and Assembly Instructions

Assembly requires at least two adults. Clear a large area for assembly. Do not use power tools for assembly as they may overtighten and damage the wood.

4.1 General Assembly Steps

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Identify each part using the included parts list (not provided in this manual, refer to the physical manual).
2. **Assemble the Bottom Bed Frame:** Connect the side rails and end panels for the bottom bed using the provided hardware. Ensure all connections are secure but do not fully tighten until the frame is stable.
3. **Install Bottom Bed Slats:** Place the 7 bottom bed slats evenly across the frame and secure them according to the instructions.
4. **Assemble the Upper Bed Frame:** Construct the upper bed frame, including the playhouse structure, following the same principles as the bottom bed.
5. **Install Upper Bed Slats:** Place the 14 upper bed slats evenly across the frame and secure them.
6. **Attach Guardrails:** Securely attach the full-length guardrails to the upper bunk.
7. **Connect Upper and Lower Bunks:** Carefully lift the upper bunk onto the lower bunk and secure them together using the designated connectors and hardware.
8. **Attach Ladder:** Securely attach the 3-step ladder to the designated access point for the upper bunk.
9. **Attach Slide:** If your model includes a slide, attach it securely to the designated opening on the upper bunk.
10. **Final Tightening:** Once all components are assembled and aligned, go back and fully tighten all screws and bolts. Do not overtighten.
11. **Safety Check:** Before use, perform a thorough safety check. Ensure all parts are securely fastened, the bed is stable, and there are no loose components.

4.2 Assembly Options

This bunk bed offers two assembly methods, allowing you to position the entire lower half of the bunk on either the left or right side to best suit your room layout. Refer to the detailed diagrams in your physical assembly manual for specific instructions on these configurations.

4.3 Visual References for Assembly



Figure 4.3.1: Angled view of the assembled bunk bed, showing the upper playhouse, ladder, and slide. This image provides a general overview of the bed's structure and components.



Figure 4.3.2: Front view of the bunk bed, highlighting the lower full-size bed frame and the upper twin-size playhouse structure with its window openings.



Figure 4.3.3: Detailed view of the upper bunk's playhouse roof, window, and the integrated guardrails, essential for safety.



Figure 4.3.4: Side profile of the bunk bed, illustrating the connection points for the slide and the overall height of the structure.

5. Operating Instructions

To ensure safe and proper use of your DERCASS bunk bed, please adhere to the following guidelines:

- **Ladder Use:** Always use the integrated ladder for accessing and exiting the upper bunk. Ensure hands and feet are clean and dry to prevent slipping.
- **Slide Use:** If your model includes a slide, ensure it is clear of obstructions before use. Only one child should use the slide at a time, and they should slide feet first.
- **Weight Limits:** Do not exceed the specified weight limits for each bunk (250 lbs for upper, 250 lbs for lower).
- **Playhouse Area:** The upper bunk's playhouse area is designed for imaginative play. Supervise children to ensure safe play and prevent climbing on the exterior of the structure.
- **Mattress Placement:** Ensure mattresses are properly seated within the bed frame and do not extend above the guardrails on the upper bunk.

6. Maintenance

Regular maintenance will help prolong the life and safety of your bunk bed.

- **Cleaning:** Wipe down the wooden surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as necessary, but do not overtighten.
- **Structural Integrity:** Inspect the bed frame for any signs of damage, cracks, or loose joints. Discontinue use if any significant damage is found and contact customer support.
- **Mattress Support:** Ensure all bed slats are securely in place and undamaged. Replace any broken slats immediately.

7. Troubleshooting

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all hardware. If squeaking persists, disassemble and reassemble the affected section, ensuring proper alignment. Applying a small amount of wax or lubricant to friction points can help.
Missing parts during assembly.	Packaging error or lost during unpacking.	Double-check all packaging materials. If still missing, contact DERCASS customer support with your purchase details.
Difficulty aligning parts.	Incorrect orientation or overtightened screws.	Loosen previously tightened screws. Ensure parts are oriented correctly as per the physical manual's diagrams. Do not force parts together.

8. Specifications

Feature	Detail
Product Type	Bunk Bed
Size	Twin-Over-Full
Color	White
Material	Plywood + MDF + Pinewood
Overall Product Dimensions	78.7"L x 78.7"W x 82.8"H
Overall Product Weight	193.65 LBS
Weight Capacity (Upper Bed)	250 LBS
Weight Capacity (Bottom Bed)	250 LBS
Recommended Mattress Thickness (Upper Bed)	6 inches
Recommended Mattress Thickness (Bottom Bed)	8 inches
Number of Slats (Upper Bed)	14
Number of Slats (Bottom Bed)	7
Recommended Age	> 6 Years Old (for upper bunk)
Assembly Required	Yes
Country of Origin	Vietnam
Model Number	LP000028
UPC	768297036804



Figure 8.1: Dimensional drawing of the bunk bed, illustrating key measurements for length, width, and height of various components including the playhouse, ladder, and slide.

9. Warranty and Support

Your DERCASS Twin Over Full Bunk Bed comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product packaging or contact DERCASS customer support.

For any questions, missing parts, or assistance with assembly or product issues, please contact DERCASS customer support.

- **Customer Support:** Refer to your purchase documentation or the DERCASS official website for contact information.
- When contacting support, please have your model number (LP000028) and purchase date readily available.

© 2023 DERCASS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08LPBYBXQ

More documents and user manuals: **https://manuals.plus/**