Manuals+
Q & A | Deep Search | Upload

RovyVon A8

RovyVon Aurora A8 G4 LED Keychain Flashlight User Manual

Model: A8 G4

1. Product Overview

The RovyVon Aurora A8 G4 is a compact and powerful LED keychain flashlight designed for everyday carry (EDC). It features a high-brightness main LED, multi-color side lights, and a USB-C rechargeable battery. Its robust design includes a new lock mode to prevent accidental activation and offers various lighting modes for diverse situations.

2. Setup and First Use

2.1. Unlocking the Device

Before first use, the flashlight is in lock mode to prevent accidental activation during shipping. To unlock, rapidly click the main button 5 times. The front LED will flash 3 times to indicate it is unlocked.

Image Description: A hand holds the RovyVon Aurora A8 G4 flashlight. A lock icon with an arrow points from "Lock" to "Unlock" with text explaining 5 rapid clicks to unlock (front LED flashes 3 times) and 5 rapid clicks to lock (front LED flashes 2 times). It also mentions that charging instantly unlocks the device.

2.2. Charging

The Aurora A8 G4 is equipped with a USB-C charging port. Connect the flashlight to a power source using a USB-C cable. The indicator light will show charging status. Charging also instantly unlocks the device.

Image Description: The RovyVon Aurora A8 G4 flashlight is shown connected to a white USB-C charging cable. A blue light indicates that the device is charging. Text on the image states "Charging" and "Charge -> Instant Unlock".

3. Operating Instructions

The RovyVon Aurora A8 G4 features a single main button for all operations.

3.1. Main Light Operation

- **Momentary On:** Press and hold the button for instant illumination at maximum output. Release to turn off.
- **Constant On/Off:** Double-click the button to turn the main light on. Double-click again to turn it off.
- **Brightness Adjustment:** When the main light is on (constant mode), click the button to cycle through brightness levels: Moonlight, Low, Medium, High.

Image Description: A hand holds the RovyVon Aurora A8 G4 flashlight, which emits a bright beam of light. Japanese text indicates "　" (Instant On) and "　　" (Long press for maximum output).

Image Description: A dark outdoor scene illuminated by the RovyVon Aurora A8 G4 flashlight. Insets show different brightness levels: 0.5 lumens (Moonlight), 25 lumens (Low), 200 lumens (Medium), and 650 lumens (High).

3.2. Side Light Operation

The Aurora A8 G4 features multi-color side lights for various signaling and utility purposes.

- **Activate Side Lights:** Triple-click the button to turn on the side lights.
- **Cycle Side Light Modes:** Once side lights are active, click the button to cycle through the following modes: Red, Blue, Red Flash, Red Beacon, Amber, Amber Flash, Amber Beacon.
- **Turn Off Side Lights:** Press and hold the button for 0.5 seconds to turn off the side lights from any mode.

Your browser does not support the video tag.

Video Description: This video demonstrates the operational controls of the RovyVon Aurora A8 G4 flashlight. It shows how to use long-press for momentary on, double-click for constant on and cycling through brightness levels, triple-click for

red/blue flashing, and single-click to cycle through red flash, red beacon, amber light, amber beacon, and amber flash. The video also illustrates how to turn off the light with a long press.

3.3. Lock Mode

To prevent accidental activation and conserve battery, you can manually engage the lock mode. Rapidly click the main button 5 times. The front LED will flash 2 times to indicate it is locked.

4. Key Features

4.1. Compact and Lightweight Design

The Aurora A8 G4 is designed for ultimate portability, similar in size to an AA battery. Its dimensions are 60.5mm in length and 15.6mm in diameter, making it easy to carry in pockets, bags, or attached to a keychain.

Image Description: The RovyVon Aurora A8 G4 flashlight is displayed alongside a standard AA battery and a house key, illustrating its compact and lightweight design. Text on the image states "Compact and lightweight" and "Similar size to an AA battery or a key".

サイズ比較

Image Description: A detailed image of the RovyVon Aurora A8 G4 flashlight with its dimensions clearly marked: 60.5mm (2.38") length and 15.6mm (0.61") diameter. A Japanese 100 yen coin is placed next to it for visual size comparison, showing its diameter as 22.6mm (0.87").

4.2. Multi-purpose Side Lights

The integrated amber, red, and blue side lights offer versatile functionality. Red and blue flashing modes are ideal for emergency signaling or as warning lights, while the amber light can serve as a comfortable reading light, protecting eye strain.

Image Description: The RovyVon Aurora A8 G4 flashlight is positioned on an open book, emitting a soft amber light. Text on the image highlights "AMBER BOOK LIGHT" and "The most comfortable and best protect your eyes."

Image Description: The RovyVon Aurora A8 G4 flashlight is shown emitting alternating red and blue flashing lights, creating a warning signal effect. Text describes "Red/Blue flash light" and its role as "warning lights" with "Blue and red lights flash alternately."

Image Description: The RovyVon Aurora A8 G4 flashlight is placed on a document, casting a steady red light over the text.

4.3. Water Resistance

The Aurora A8 G4 is designed with water resistance, making it suitable for use in various weather conditions. Avoid prolonged submersion.

Image Description: The RovyVon Aurora A8 G4 flashlight is depicted partially submerged in clear water, with the text "A8" floating nearby, illustrating its water-resistant capabilities.

5. Maintenance

5.1. Cleaning

Wipe the flashlight with a soft, damp cloth to remove dirt and debris. Do not use harsh chemicals or abrasive materials, as these can damage the casing or lens.

5.2. Charging Port Care

Keep the USB-C charging port clean and free of dust. Ensure the port cover is properly sealed when not charging to maintain water resistance.

Image Description: An image displaying the accessories included with the RovyVon Aurora A8 G4 flashlight. These include a magnetic clip, magnetic base, USB-C cover, and a keychain ring, along with the user manual and a RovyVon card.

6. Troubleshooting

- **Light not turning on:** Ensure the flashlight is charged. Check if it is in lock mode (5 rapid clicks to unlock).
- **Intermittent operation:** Ensure the battery is sufficiently charged. Clean the charging port and ensure connections are secure.

- **Reduced brightness:** Recharge the battery. If the issue persists, contact customer support.

7. Specifications

Feature	Detail
Model Number	A8
Product Dimensions	6.05 x 6.05 x 1.55 cm; 65 g
ASIN	B08M3FHTY7
Special Features	Rechargeable
Color	Yellow (A8 Yellow variant)
Power Source	Rechargeable Battery
Light Source Type	LED (Luminus 6500K Cool White)
Material	Polycarbonate
Brightness	Up to 650 Lumens
Side Light Colors	Amber, Red, Blue
Charging Port	USB-C

8. Safety Information

- Do not shine the light directly into eyes, as it can cause temporary blindness or eye damage.
- Keep out of reach of children.
- Do not disassemble the flashlight, as this may void the warranty and cause damage.
- Avoid exposing the flashlight to extreme temperatures or direct sunlight for prolonged periods.
- Use only the recommended charging cables and adapters.

9. Warranty and Support

For warranty information and customer support, please refer to the official RovyVon website or contact your retailer. Keep your purchase receipt for warranty claims.