Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Roundhill Furniture C304

Roundhill Furniture Windvale Fabric Upholstered Dining Chair (Set of 2) Instruction Manual

Model: C304

Introduction Safety Information Package Contents Assembly Usage & Care Troubleshooting Specifications Support

1. Introduction

Thank you for purchasing the Roundhill Furniture Windvale Fabric Upholstered Dining Chair set. This manual provides essential information for the safe assembly, proper use, and maintenance of your new dining chairs. Please read these instructions thoroughly before assembly and retain them for future reference.



Image 1.1: Two assembled Windvale dining chairs.

2. Safety Information

WARNING: This product requires assembly. Always follow the instructions provided. This product is intended for indoor use only. Do not use outdoors or in wet environments. Always ensure the chair is stable and secure before use. Do not exceed the maximum weight capacity of 250 pounds.

- Keep all parts and packaging materials away from children.
- Ensure all bolts and screws are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair or use it as a step stool.
- Avoid placing hot items directly on the chair's upholstered seat.

3. Package Contents

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, do

not proceed with assembly. Contact customer support for assistance.
Your package should contain the following for a set of two chairs:

- Two (2) Chair Backrests
- Two (2) Seat Frames with Upholstery
- Four (4) Front Legs
- Four (4) Back Legs
- Hardware Pack (screws, washers, Allen wrench)
- Assembly Instructions Sheet

4. Assembly Instructions

Assembly is required for these dining chairs. Please follow the included assembly instructions sheet carefully. It is recommended to assemble the chairs on a soft, clean surface to prevent scratching.

General Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Identify each component against the parts list.
2. **Attach Legs to Seat Frame:** Secure the front and back legs to the underside of the upholstered seat frame using the provided screws and washers. Ensure all connections are firm but do not fully tighten yet.
3. **Attach Backrest:** Connect the chair backrest to the seat frame and the rear legs. Align the holes and insert the remaining screws.
4. **Final Tightening:** Once all parts are loosely assembled, place the chair upright on a flat surface. Apply gentle pressure to ensure all parts are aligned, then fully tighten all screws with the Allen wrench. Do not overtighten.
5. **Repeat for Second Chair:** Follow the same steps to assemble the second dining chair.



Image 4.1: Assembled chair dimensions.

5. Usage and Care

Operating Instructions:

These chairs are designed for dining room use. Sit centrally on the seat with your back against the backrest for optimal comfort and stability. Avoid leaning back excessively or rocking the chair, as this can compromise its stability and cause damage.

Maintenance:

- **Cleaning:** Wipe clean with a soft, damp cloth. For upholstered areas, spot clean with a mild fabric cleaner if necessary. Test on an inconspicuous area first.
- **Regular Checks:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain structural integrity.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric and wood finish.
- **Protect from Moisture:** Avoid placing chairs in areas with high humidity or direct contact with liquids.



Image 5.1: Close-up of the upholstered seat fabric.

6. Troubleshooting

Common Issues:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair feels wobbly	Loose screws or uneven assembly.	Ensure all screws are fully tightened. Place the chair on a flat surface and re-tighten screws while applying slight downward pressure to ensure evenness.
Squeaking noise	Loose joints or friction between wood parts.	Tighten all screws. If squeaking persists, disassemble and reassemble, ensuring all parts are correctly aligned. A small amount of furniture wax or lubricant at joints may help.
Damage during assembly	Incorrect tools or excessive force.	Always use the provided tools and follow instructions carefully. If a part is damaged, contact customer support for a replacement.

7. Specifications

Feature	Detail
Brand	Roundhill Furniture
Model Name	Windvale
Model Number	C304
Color	Black
Material	Solid Rubberwood Frame, Polyester Blend Upholstery (linen-feel)
Product Dimensions (D x W x H)	19"D x 20"W x 38"H
Seat Dimensions (W x D x H)	19"W x 17.5"D x 17.7"H
Item Weight	14.88 Pounds (per chair)
Maximum Weight Recommendation	250 Pounds
Assembly Required	Yes
Indoor/Outdoor Usage	Indoor Only

8. Warranty and Support

For warranty information, replacement parts, or any questions regarding your Roundhill Furniture Windvale dining chairs, please contact Roundhill Furniture customer service. Refer to your purchase documentation for specific warranty terms and contact details.
You can often find support information on the manufacturer's official website or through the retailer where the product was purchased.

© 2024 Roundhill Furniture. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08M5T347P

More documents and user manuals: **https://manuals.plus/**