Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEDKIA LIGHTING 71573-145209

LEDKIA LIGHTING 18W CCT Selectable LED Ceiling Lamp

Model: 71573-145209

Introduction

This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your LEDKIA LIGHTING 18W CCT Selectable LED Ceiling Lamp. Please read this manual thoroughly before installation and retain it for future reference.



Image: Front view of the LEDKIA LIGHTING 18W CCT Selectable LED Ceiling Lamp.

Safety Instructions

- Ensure the power supply is disconnected before installation, maintenance, or cleaning.
- Installation should be performed by a qualified electrician in accordance with local electrical codes.
- Do not modify the lamp or its components.
- This product is designed for indoor use only.
- Avoid direct eye exposure to the light source when the lamp is on.
- Keep packaging materials out of reach of children.

Package Contents

Verify that all components are present and undamaged before proceeding with installation.

- 1x LEDKIA LIGHTING 18W CCT Selectable LED Ceiling Lamp

- 1x Mounting Hardware Kit (screws, wall plugs)
- 1x User Manual (this document)

Specifications

Feature	Detail
Brand	LEDKIA LIGHTING
Model Number	71573-145209
Power Consumption	18W
Luminous Flux	1600 Lumen
Color Temperature (CCT)	Selectable (Warm to Cold White Light)
Diameter	Ø32 cm (320 mm)
Height	5 cm (50 mm)
Material	Wood, Metal
Room Type	Bedroom (suitable for various indoor spaces)
Usage	Indoor
Power Source	Corded Electric



Image: Dimensional drawing of the LED ceiling lamp.



Image: EU Energy Label for the product. For more details, refer to the EPREL database.

Setup and Installation

Follow these steps carefully for proper installation. It is recommended to have a qualified electrician perform the installation.

1. **Prepare the Installation Area:** Ensure the power supply to the installation area is turned off at the main circuit breaker. Mark the drilling points on the ceiling according to the lamp's mounting bracket.
2. **Mount the Bracket:** Drill holes at the marked points and insert appropriate wall plugs. Secure the mounting bracket to the ceiling using the provided screws.
3. **Electrical Connection:** Connect the lamp's electrical wires to the main power supply wires (Live, Neutral, Earth) according to local wiring regulations. Ensure all connections are secure.
4. **CCT Selection (Pre-installation):** Before fully mounting the lamp, locate the CCT (Correlated Color Temperature) selection switch on the back of the lamp. This switch allows you to choose between different light temperatures (e.g., warm white, neutral white, cool white). Select your desired color temperature. *Note: This switch is typically accessed before final mounting.*
5. **Attach the Lamp:** Carefully align the lamp with the mounted bracket and secure it in place. Ensure it is firmly attached to prevent accidental falls.
6. **Restore Power:** Once the lamp is securely installed and all connections are checked, restore power at the main circuit breaker.



Image: Internal view showing wiring connections and the CCT selection switch.



Image: Example of the lamp installed in a room, demonstrating its illumination.

Operating Instructions

The LEDKIA LIGHTING ceiling lamp is designed for simple operation.

- **Turning On/Off:** Use your standard wall switch to turn the lamp on or off.
- **CCT (Color Temperature) Selection:** The color temperature is set via a switch on the back of the lamp during installation. If you wish to change the CCT after installation, you will need to disconnect power, remove the lamp, adjust the switch, and then re-install.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your LED ceiling lamp.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth to wipe the lamp's surface. Do not use abrasive cleaners, solvents, or liquids that could damage the finish or electrical components.

- **Bulb Replacement:** This lamp uses integrated LED technology. The LED light source is not user-replaceable. If the LEDs fail, the entire fixture typically needs replacement.
- **Inspection:** Periodically check for any loose connections or visible damage. If any issues are found, disconnect power and consult a qualified technician.

Troubleshooting

If you encounter issues with your LEDKIA LIGHTING ceiling lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on	No power supply; Loose wiring connection; Faulty switch.	Check circuit breaker; Verify wiring connections (ensure power is off first); Test the wall switch.
Light flickers	Unstable power supply; Loose connection; Incompatible dimmer switch (if applicable).	Ensure stable power; Check wiring connections; This lamp is not specified as dimmable, avoid using with dimmer switches unless explicitly stated.
Incorrect color temperature	CCT switch set incorrectly.	Disconnect power, remove lamp, adjust CCT switch to desired setting, then re-install.

If the problem persists after attempting these solutions, contact customer support or a qualified electrician.

Warranty and Support

LEDKIA LIGHTING products are manufactured to high-quality standards. For warranty information or technical support, please refer to your purchase documentation or contact LEDKIA LIGHTING customer service directly.
Contact information for LEDKIA (seller):

- **Seller Name:** LEDKIA
- **Amazon Seller ID:** A291A4231MYKMV
- **Store Link:** LEDKIA LIGHTING Store

For general inquiries or support, please visit the official LEDKIA LIGHTING website or contact their customer service department.

© 2023 LEDKIA LIGHTING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08N9THB4G

More documents and user manuals: **https://manuals.plus/**