Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX DELUX-KM33

DELUX TKL 61 Keys Mechanical Wireless Keyboard User Manual

Model: DELUX-KM33

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your DELUX TKL 61 Keys Mechanical Wireless Keyboard (Model: DELUX-KM33). This compact 60% layout keyboard features Brown Switches, PBT keycaps, dual wired/wireless connectivity via Bluetooth 5.0, and RGB backlighting. It is designed for compatibility with Windows, Mac, iOS, and Android devices.



Figure 1: DELUX TKL 61 Keys Mechanical Wireless Keyboard. This image shows the full layout of the 61-key keyboard with its grey and white keycaps and RGB backlighting.

Package Contents

Before proceeding with setup, please ensure all items are present in the package:

- 1 x DELUX KM33 mechanical keyboard
- 1 x Detachable Type-C cable
- 1 x User manual (this document)

Setup

Initial Charging

For optimal performance, it is recommended to fully charge the keyboard before first use. Connect the provided Type-C cable to the keyboard's Type-C port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).



Figure 2: Dual Mode Connection. The image illustrates both the wired Type-C connection and the wireless Bluetooth 5.0 capability of the keyboard.

Connecting the Keyboard

The DELUX KM33 keyboard supports both wired and wireless (Bluetooth 5.0) connections.

Wired Mode

1. Connect the detachable Type-C cable to the keyboard's Type-C port.
2. Connect the USB-A end of the cable to an available USB port on your computer.
3. The keyboard will be automatically recognized and ready for use. The keyboard can be used in wired mode while charging.

Wireless (Bluetooth 5.0) Mode

The keyboard supports connection to up to 3 devices via Bluetooth. Ensure your device's Bluetooth is enabled.

1. Turn on the keyboard.
2. Press **FN + Q**, **FN + W**, or **FN + E** to select one of the three Bluetooth channels. The corresponding key (Q, W, or E) will blink, indicating pairing mode.
3. On your device (computer, tablet, smartphone), search for Bluetooth devices.
4. Select "DELUX KM33" from the list of available devices to pair.
5. Once paired, the Q/W/E key will stop blinking and remain steadily lit for a few seconds, indicating a successful connection.
6. To switch between paired devices, press **FN + Q**, **FN + W**, or **FN + E**.

Note: *Bluetooth 5.0 mode is not available on Windows 7 or lower versions. For Mac OS, the system version must be iOS 13 or above for full compatibility.*

Operating Instructions

Key Functions and Layout

The DELUX KM33 features a 61-key TKL (Tenkeyless) compact layout. Many functions are accessed via the **FN** key combination.



Figure 3: Compact 60% Layout. The image highlights the keyboard's dimensions (294mm L x 104mm W x 42mm H), emphasizing its space-saving design.

FN Key Combinations (Examples)

- **FN + Q/W/E:** Switch between Bluetooth devices (as described in Setup).
- **FN + F1-F12:** Access multimedia and function keys (e.g., volume control, media playback). Refer to the keycap legends for specific functions.
- **FN + Backspace:** Delete key.
- **FN + P:** Print Screen.
- **FN + [:** Home.
- **FN +]:** End.
- **FN + ;:** Page Up.
- **FN + ':** Page Down.
- **FN + Enter:** Right Shift.
- **FN + Right Ctrl:** Arrow keys (Up, Down, Left, Right).

RGB Backlighting

The keyboard features RGB backlighting with 17 available lighting effects.



Figure 4: RGB Backlit Keyboard. This image showcases the keyboard's customizable RGB lighting effects, illuminating the keys in various colors.

- **FN + \ |:** Cycle through different lighting effects.
- **FN + [{:** Decrease backlight brightness.
- **FN +]}:** Increase backlight brightness.
- **FN + ;:** Decrease backlight speed.
- **FN + ':** Increase backlight speed.

Battery Management

The keyboard is equipped with a built-in 2000 mAh rechargeable lithium battery, providing approximately 12 hours of use with backlighting on.



Figure 5: Built-in Rechargeable Battery. The image shows the keyboard and indicates the 2000 mAh battery capacity, along with a visual representation of the low battery alert where the FN key blinks.

- **Low Battery Alert:** When the battery is low, the **FN** key light will blink continuously to remind you to charge the keyboard.
- **Charging:** Connect the Type-C cable to charge. The keyboard can be used normally while charging.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your DELUX keyboard.

Cleaning

- Disconnect the keyboard from all power sources (wired or Bluetooth) before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keycaps and keyboard surface.
- For dust and debris between keys, use compressed air or a small brush.

- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the keyboard.

Storage

- Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to preserve battery health.

Troubleshooting

If you encounter issues with your keyboard, refer to the following common troubleshooting steps:

Problem	Possible Cause / Solution
Keyboard not responding in wired mode.	Ensure the Type-C cable is securely connected to both the keyboard and the computer. Try a different USB port on your computer. Test the cable with another device if possible to rule out a faulty cable.
Keyboard not connecting via Bluetooth.	Ensure the keyboard is charged. Verify Bluetooth is enabled on your device. Make sure you are selecting the correct Bluetooth channel (FN+Q/W/E) and it is blinking. Remove "DELUX KM33" from your device's Bluetooth list and attempt to re-pair. Ensure your device's operating system meets the compatibility requirements (e.g., Mac OS 13+). Restart both the keyboard and your device.
Keys are not registering or are sticky.	Clean the keyboard as described in the Maintenance section to remove debris. Ensure the keycaps are properly seated.
Backlighting is not working or is dim.	Check the battery level; low battery can affect backlighting. Adjust brightness using FN + [{ or FN +]}. Cycle through lighting effects using FN + \ |.
FN key blinking.	This indicates a low battery. Connect the keyboard to a power source using the Type-C cable to charge.

Specifications

Detailed technical specifications for the DELUX KM33 keyboard:

Feature	Detail
Model	DELUX-KM33
Dimensions (L x W x H)	294mm x 104mm x 43mm (11.57in x 4.09in x 1.65in)
Net Weight	Approximately 0.68 kg
Key Switch Type	Brown Switch
Operating Force	Approximately 60g

Feature	Detail
Key Numbers	61 Keys
Key Life	>50 million times
Keycap Type	PBT Double Shot Keycaps
Connectivity	Wired (Detachable Type-C), Wireless (Bluetooth 5.0)
Bluetooth Channels	3 channels (FN+Q/W/E)
Battery	Built-in 2000mAh Lithium Battery
Battery Life (Backlit On)	Up to 12 hours
Backlighting	RGB, 17 lighting effects
Operating System Compatibility	Windows 8/10, Mac, iOS (13+), Android



Figure 6: Brown Switch and PBT Keycap Detail. This image provides a close-up view of the keyboard's brown mechanical switches, known for their soft rebound and non-clicky feel, and the durable PBT double-shot keycaps.

Warranty and Support

All DELUX products include a **12-month warranty** and **free lifetime technical support**
For technical assistance or warranty claims, please contact DELUX customer support through the retailer where you purchased the product or visit the official DELUX website for contact information.
Note: *There is no specific driver software required for this product.*

© 2023 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08N9VLZW8

More documents and user manuals: **https://manuals.plus/**