Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-HLP-0009

NEBO Einstein 750 Lumen Headlamp User Manual

Model: NEB-HLP-0009 | Brand: NEBO

Introduction

Thank you for choosing the NEBO Einstein 750 Lumen Headlamp. This compact and durable headlamp is designed for outdoor enthusiasts, providing powerful illumination and versatile features for various activities. With its adjustable strap, multiple light modes, and water-resistant construction, the Einstein 750 is an essential tool for camping, hiking, and other adventures.

Key Features:

- **Compact Design:** Adjustable headlamp ideal for full visibility while taking on the great outdoors.
- **Durable Construction:** Resists water and protects your gear from the elements.
- **Easy-Tilt:** Allows you to get the perfect angle and focus on trailblazing.
- **Multiple Brightness Settings:** Features 750 lumens and a red light mode for versatile use.
- **Long Battery Life:** Up to 60 hours of battery life with replaceable AAA batteries.

Setup

Battery Installation:

The NEBO Einstein 750 Headlamp requires 4 AAA batteries (included).

1. Locate the battery compartment on the back of the headlamp strap.
2. Open the battery compartment cover.
3. Insert 4 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Adjusting the Head Strap:

The elastic head strap is adjustable to fit various head sizes.

- Place the headlamp on your head.
- Use the adjustable buckles on the strap to tighten or loosen it until it fits comfortably and securely.

Operating Instructions

Power Button and Mode Selection:

The power button is located on the top of the headlamp.

- **To Turn On/Off:** Press and hold the power button for approximately 1 second to turn the headlamp on or off.
- **To Cycle Modes:** While the headlamp is on, short press the power button to cycle through the different light modes:
  - High (750 Lumens - Turbo Mode)
  - Medium
  - Low
  - Red Light
- **Direct Red Light Access:** Some units may allow direct access to red light mode by pressing and holding the button from the OFF position for a longer duration (e.g., 2-3 seconds). Refer to specific packaging for details.

Easy-Tilt Feature:

The headlamp features an easy-tilt mechanism, allowing you to adjust the angle of the light beam.

- Gently tilt the headlamp body up or down to direct the light where needed.
- This feature is useful for focusing light on specific tasks or adjusting for different terrains.



Image: The NEBO Einstein 750 Headlamp in use, showcasing its powerful 750 lumen output for clear visibility in low-light conditions.



Image: Demonstrating the easy-tilt feature of the NEBO Einstein 750 Headlamp, allowing users to adjust the light beam angle for optimal illumination.

Maintenance

Cleaning:

To maintain the performance and longevity of your headlamp:

- Wipe the headlamp body with a soft, damp cloth to remove dirt or debris.
- Do not use abrasive cleaners or solvents, as these may damage the finish or internal components.
- Ensure the battery compartment is clean and dry before closing.

Water Resistance:

The NEBO Einstein 750 Headlamp is rated IPX4 water resistant, meaning it is protected against splashing water from any direction.

- It is suitable for use in rain or wet conditions.

- Do not submerge the headlamp in water.
- Ensure the battery compartment is properly sealed to maintain water resistance.



Image: The NEBO Einstein 750 Headlamp on a wet surface, highlighting its IPX4 water resistance, suitable for use in various weather conditions.

Battery Replacement:

Replace batteries when the light output becomes dim or the headlamp stops functioning. Always replace all 4 AAA batteries at the same time with new ones.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headlamp does not turn on.	Batteries are dead or incorrectly installed. Battery compartment not securely closed.	Replace all 4 AAA batteries with new ones, ensuring correct polarity. Ensure the battery compartment cover is fully closed and latched.
Light is dim or flickers.	Low battery power. Poor contact between batteries and terminals.	Replace all 4 AAA batteries. Clean battery contacts with a dry cloth or cotton swab.
Difficulty activating red light mode.	Incorrect button press sequence.	From the OFF position, press and hold the power button for a longer duration (e.g., 2-3 seconds) to directly access red light mode. Otherwise, cycle through white light modes until red light is reached.

Specifications

Feature	Detail
Model Name	NEB-HLP-0009
Brightness	750 Lumens (Turbo Mode)
Light Source Type	LED
Power Source	Battery (4 x AAA, included)
Battery Life (Runtime)	Up to 60 hours
Water Resistance Level	IPX4 (Water Resistant)
Material	Aluminum
Item Weight	0.44 Pounds (approx. 200g)
Product Dimensions	12"D x 5.9"W x 5.2"H (approx.)
Special Features	Adjustable, Durable, Easy-Tilt
UPC	645397937982

Warranty & Support

Warranty Information:

The NEBO Einstein 750 Headlamp comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty claims, or general inquiries, please contact NEBO customer support.

- Visit the official NEBO website for contact information and FAQs:www.nebo.acgbrands.com
- Refer to the product packaging for specific support details.

© 2024 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NZ1KRMZ

More documents and user manuals: **https://manuals.plus/**