Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-FLT-0021

NEBO DAVINCI 3500 Flashlight Instruction Manual

Model: NEB-FLT-0021

Introduction

Thank you for choosing the NEBO DAVINCI 3500 Flashlight. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before using the flashlight.
The DAVINCI 3500 is a high-performance, rechargeable flashlight designed for various applications, from everyday carry (EDC) to hiking and camping. It boasts exceptional brightness, multiple light modes, and the added functionality of a portable power bank.



Image: The NEBO DAVINCI 3500 Flashlight, a sleek grey cylindrical device with an orange accent ring near the head, showcasing its robust design.

Setup

Initial Charging

Before first use, it is recommended to fully charge your NEBO DAVINCI 3500 Flashlight. The flashlight is equipped with a 4500 mAh (7.4V) Lithium-ion rechargeable battery.

- Locate the Micro USB charging port on the flashlight. This is typically found by unscrewing or sliding a section of the barrel.
- Connect the included Micro USB charging cable to the flashlight's port.
- Connect the other end of the USB cable to a compatible USB power source (e.g., wall adapter, computer USB port).
- The charging indicator light will illuminate, typically red during charging and green when fully charged.
- A full charge can take approximately 7 to 14 hours, depending on the power source.



Image: The NEBO DAVINCI 3500 Flashlight connected to a Micro USB charging cable, illustrating the charging process.

Attaching the Lanyard

The flashlight includes a detachable lanyard for secure carrying. Attach the lanyard to the designated loop at the tail end of the flashlight.

Operating Instructions

Power On/Off and Mode Selection

The DAVINCI 3500 features a mode selector dial for easy operation.

- To turn the flashlight on or off, press the power button located at the tail cap.
- Rotate the mode selector dial, located near the head of the flashlight, to cycle through the available light modes:
    - **High (3,500 lumens):** For maximum brightness and illumination.
    - **Medium (700 lumens):** For balanced light output and extended runtime.
    - **Low (70 lumens):** For prolonged use, offering up to 20 hours of light.
    - **Strobe (3,500 lumens):** For emergency signaling or disorienting.



Image: Close-up of the NEBO DAVINCI 3500 flashlight, highlighting the intuitive mode select dial for easy light mode changes.

Zoom Function

The DAVINCI 3500 features a 3X zoom function to adjust the beam from a focused spotlight to a dispersed floodlight.

- To adjust the zoom, slide the head of the flashlight forward or backward.
- Sliding forward will narrow the beam for a more focused spotlight.
- Sliding backward will widen the beam for a broader floodlight.



Image: A person holding the NEBO DAVINCI 3500 Flashlight, illuminating a dark outdoor area with its brilliant white light, demonstrating its powerful output.

Power Bank Functionality

The DAVINCI 3500 can also serve as a portable power bank to charge your USB-powered devices.

- Unscrew the tail cap to reveal the USB-A output port.
- Connect your device's charging cable to the USB-A port on the flashlight.
- The flashlight will begin charging your device.
- Remember that using the power bank function will consume the flashlight's battery life.

Maintenance

Cleaning

- Wipe the flashlight body with a soft, damp cloth to remove dirt and debris.
- Do not use abrasive cleaners or solvents, as they may damage the anodized finish.
- Ensure the charging port cover is securely closed when not in use to maintain water resistance.

Water Resistance

The NEBO DAVINCI 3500 is IP67-rated, meaning it is waterproof for up to 30 minutes at a depth of 3.28 feet (1 meter). While designed to withstand water exposure, it is not intended for prolonged submersion or diving.




Image: The NEBO DAVINCI 3500 Flashlight partially submerged in water, illustrating its rugged and reliable waterproof design.

Storage

- Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, it is advisable to charge the battery periodically to maintain its health.

Troubleshooting

- **Flashlight not turning on:**
  - Ensure the battery is charged. Connect to a power source and allow it to charge.
  - Check if the tail cap is fully tightened. A loose tail cap can prevent electrical contact.
- **Light is dim or flickering:**
  - The battery may be low. Recharge the flashlight.
  - Ensure the lens is clean. Dirt or smudges can reduce light output.
- **Device not charging from power bank:**
  - Ensure the flashlight has sufficient charge.
  - Verify that the USB-A cable is properly connected to both the flashlight and your device.
  - Check if your device is compatible with USB-A charging.

Specifications

Feature	Specification
Model Name	NEB-FLT-0021
Lumens (High)	3500 Lumens
Lumens (Medium)	700 Lumens

Lumens (Low)	70 Lumens
Lumens (Strobe)	3500 Lumens
Runtime (Low)	Up to 20 hours
Battery	4500 mAh (7.4V) Lithium-ion rechargeable
Material	Anodized Aircraft Grade Aluminum
Water Resistance	IP67 (Waterproof 1 meter for 30 minutes)
Product Dimensions	8.125" Length, 1.875" Head Diameter, 1.375" Barrel
Item Weight	8 ounces
Included Components	Flashlight, Micro USB Charging Cord, Detachable Lanyard

Warranty

The NEBO DAVINCI 3500 Flashlight comes with a 1-year warranty. Please retain your proof of purchase for warranty claims. For detailed warranty information and terms, please refer to the official NEBO website or contact customer support.

Support

For further assistance, technical support, or inquiries regarding your NEBO DAVINCI 3500 Flashlight, please visit the official NEBO website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

© 2024 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08NZ1YB64

More documents and user manuals: **https://manuals.plus/**