Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FOCOIIK F1202

FOCOIIK Griddler Plates Replacement User Manual

Model: F1202

Introduction

Thank you for choosing FOCOIIK Griddler Plates. These replacement plates are designed to enhance your cooking experience with compatible Cuisinart Griddler models, offering versatility for grilling, griddling, and paninis. Crafted with quality materials and a non-stick coating, they aim to provide efficient and enjoyable meal preparation.

Product Overview

The FOCOIIK Griddler Plates are reversible, featuring a ribbed grill surface on one side and a flat griddle surface on the other. They are designed for easy installation and removal, making them convenient for various cooking needs and simple cleanup.



Image: A set of two FOCOIIK Griddler Plates, one showing the ribbed grill surface and the other showing the flat griddle surface.

- **Reversible Design:** Features both grill and griddle surfaces for diverse cooking.
- **Non-Stick Coating:** Double-layer Teflon sprayed oil coating for effortless food release.
- **Food Grade Material:** Made from aluminum alloy, BPA-free, ensuring safety for food contact.
- **Easy Installation:** Designed for quick and simple attachment and detachment from your Griddler machine.

Compatibility

These replacement plates are specifically designed to fit certain Cuisinart Griddler models. Please verify your model number to ensure proper fit and function.

Compatible Models:

- Cuisinart GR-4N
- Cuisinart GR-4N(TK)
- Cuisinart GR-5B
- Cuisinart GR-6
- Cuisinart GRID-8N Series

Incompatible Models:

- ✘ Old model GR-4
- ✘ Old model GRID-8
- ✘ GR-150
- ✘ GR150P1 Deluxe
- ✘ GR-300WSP1 Elite

Note: The "N" in model numbers like GR-4N indicates a newer generation of Cuisinart Griddler. Older models (e.g., GR-4 without "N") may have different plate attachment mechanisms or oil storage designs.



Image: Visual guide indicating compatibility with Cuisinart GR-4NP1, GR-4N(TK), GR-5B, and GRID-8N Series.

Cuisinart Model Number Matching Pitcures

Attention:Not for old model GR-4 & GRID-8
“N”means news generation of Cuisinart Griddler.



Fits GR-4N & GR-4N(TK)
& GRID-8N



Fits GR-5B & GR-6



(Deluxe)

Definitely not fit other
Griddler model GR-150



(Elite)

Definitely not fit other
Griddler model GR-300WSP1

Image: A chart showing various Cuisinart Griddler models and whether the plates fit, highlighting the "N" series.



Image: Detailed comparison of the GR-4 and GR-4N models, showing differences in oil storage and bottom plate design to help identify compatibility.

Installation & Usage

Installation:

1. Ensure your Cuisinart Griddler is unplugged and cool before handling.
2. Locate the plate release buttons or levers on your Griddler (refer to your Griddler's manual if unsure).
3. Align the FOCOllK replacement plate with the corresponding slots on the Griddler.
4. Gently press the plate into place until it clicks securely. Ensure both plates are firmly seated before use.

Usage:

These plates are versatile for various cooking applications:

- **Grill Side:** Ideal for grilling meats like chicken breast, steak, burgers, and vegetables. The ribbed surface creates appealing grill marks and helps drain fat.

- **Griddle Side:** Perfect for cooking breakfast items such as eggs, pancakes, bacon, or for making crepes and paninis. The flat surface provides even heat for delicate items.



Image: The reversible plates in use, showing grilled items on one side and fried eggs on the griddle side.

Care & Maintenance

Proper care will extend the life of your FOCOllK Griddler Plates and maintain their non-stick performance.

1. **Cool Down:** Always allow the plates to cool completely before cleaning.
2. **Removal:** Detach the plates from the Griddler machine for thorough cleaning.
3. **Hand Washing (Recommended):** For best results and to protect the non-stick coating long-term, hand wash the plates with warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners or scouring pads.
4. **Dishwasher Safe:** The plates are dishwasher safe for convenience. However, frequent dishwasher use may reduce the lifespan of the non-stick coating over time.
5. **Drying:** Dry the plates thoroughly before storing to prevent water spots or mineral buildup.
6. **Storage:** Store plates in a dry place to prevent damage.

Troubleshooting

Issue	Possible Cause	Solution
Plates do not fit the Griddler.	Incorrect Griddler model. These plates are not universally compatible.	Refer to the "Compatibility" section to ensure your Griddler model is listed as compatible. Contact customer support if you believe there is an error.
Food sticks to the non-stick surface.	Insufficient preheating, too high heat, or degradation of non-stick coating over time.	Ensure the Griddler is fully preheated before adding food. Use appropriate cooking temperatures. Avoid using metal utensils that can scratch the coating. For optimal non-stick performance, consider light oiling before cooking, especially for delicate foods.
Plates are difficult to clean.	Food residue has dried on, or abrasive cleaning methods were used.	Soak plates in warm, soapy water for a few minutes before cleaning. Use a soft sponge or cloth. Avoid harsh chemicals or metal scrubbers.

Specifications

Attribute	Detail
Brand	FOCOllK
Model Number	F1202
Material	Aluminum Alloy with Double-Layer Teflon Coating
Product Dimensions	11.52"L x 9.3"W x 0.5"Th
Item Weight	2.48 pounds (per set of 2)
Non-stick Coating	Yes
Dishwasher Safe	Yes (Hand wash recommended for longevity)
BPA Free	Yes

Warranty & Support

FOCOllK Griddler Plates come with a **1-Year Guarantee** from the date of purchase.
If you encounter any issues or have questions regarding your product, please do not hesitate to contact our customer support team. We are committed to providing assistance and ensuring your satisfaction.
For support, please refer to the contact information provided with your purchase or visit the FOCOllK brand store on Amazon: FOCOllK Store

© 2025 FOCOllK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08V4RYF9N

More documents and user manuals: **https://manuals.plus/**