Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Belkin AUD001btBL

Belkin SoundForm Mini Wireless Bluetooth Headphones for Kids

Model: AUD001btBL

INTRODUCTION

The Belkin SoundForm Mini Wireless Headphones are designed specifically for children, offering a safe and comfortable audio experience. These headphones are ideal for virtual classes, educational videos, music listening, and travel, providing clear audio with a built-in microphone for communication.



Image: Belkin SoundForm Mini Wireless Bluetooth Headphones in blue. These headphones feature a vibrant blue color and an on-ear design, suitable for children.

What's in the Box

Upon unboxing your Belkin SoundForm Mini Headphones, you should find the following components:

- One (1) Belkin SoundForm Mini Wireless Bluetooth Headphones
- One (1) Micro-USB Charging Cable
- One (1) 3.5mm Aux Cable
- One (1) Sheet of Fun Stickers for customization

Key Features

- **Bluetooth 5.0 Connectivity:** Provides a stable wireless connection up to 30 feet (9 meters) from the paired device.
- **Long Battery Life:** Enjoy up to 30 hours of audio playback on a single full charge.
- **85dB Safe Volume Limit:** Engineered with a volume cap of 85 decibels to protect children's sensitive hearing.



Image: A child wearing the Belkin SoundForm Mini headphones, illustrating the safe listening volume feature. The headphones are designed to protect young ears.

- **Built-in Microphone:** Enables clear voice communication for online classes, video calls, or gaming.



Image: A child interacting with a tablet while wearing the Belkin SoundForm Mini headphones, highlighting the built-in microphone for communication.

- **Comfortable and Kid-Sized Design:** Features soft cushion ear cups and an adjustable headband for a comfortable fit on smaller heads.



Image: A close-up view of the soft, cushioned earcups and adjustable headband of the Belkin SoundForm Mini headphones, emphasizing their comfortable design for children.

- **Easy-to-Use Controls:** Intuitive touch controls on the headphones allow for simple play/pause, volume adjustment, and Bluetooth pairing.



Image: A diagram illustrating the easy setup and control functions of the Belkin SoundForm Mini headphones, including button functions for volume, playback, and calls.

- **Optional Wired Connection:** Includes a 4-foot 3.5mm aux cable for wired use with any compatible audio jack.
- **Kid-Proof Durability:** Rigorously tested to withstand common spills and accidents, ensuring longevity.



Image: Belkin SoundForm Mini headphones resting on a surface with a small liquid spill, demonstrating their kid-proof durability against accidents.

- **Customizable with Stickers:** Comes with fun stickers, allowing children to personalize their headphones.



Image: A young girl wearing the Belkin SoundForm Mini headphones, with a sheet of colorful stickers beside her, illustrating the customization option.

Setup Guide

Charging the Headphones

Before first use, fully charge your Belkin SoundForm Mini headphones. Use the included Micro-USB charging cable.

1. Locate the Micro-USB charging port on the headphones.
2. Connect the Micro-USB end of the cable to the headphone port.

3. Connect the USB-A end of the cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. Once fully charged, the light will change or turn off (refer to the specific light behavior in the full user manual if available).

Bluetooth Pairing

Follow these steps to pair your headphones with a Bluetooth-enabled device:

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power/Bluetooth button on the headphones until the indicator light flashes blue, indicating pairing mode.
3. On your device (e.g., smartphone, tablet, computer), navigate to the Bluetooth settings.
4. Turn on Bluetooth and search for available devices.
5. Select "SOUNDFORM Mini" from the list of found devices.
6. Once connected, the indicator light on the headphones will turn solid blue or off, depending on the model.
7. Your headphones are now ready for use.



Image: Belkin SoundForm Mini headphones with the Bluetooth logo, illustrating the wireless connectivity feature.

Operating Instructions

Basic Controls

The Belkin SoundForm Mini headphones feature intuitive controls located on the earcup:

Function	Action
Power On/Off	Press and hold the Power button.
Play/Pause	Press the Play/Pause button once.
Volume Up	Press the '+' button.
Volume Down	Press the '-' button.
Next Track	Press and hold the '+' button for 2 seconds.

Function	Action
Previous Track	Press and hold the '-' button for 2 seconds.
Answer/End Call	Press the Call button once.
Reject Call	Press and hold the Call button for 1 second.

Wired Connection (Aux Mode)

To use the headphones with a wired connection, simply plug the included 3.5mm aux cable into the headphone's aux port and the other end into your device's audio jack. In wired mode, the headphone's battery is not used, and some controls on the headphones may be inactive, depending on the device.

Maintenance and Care

Proper care will extend the life of your Belkin SoundForm Mini headphones.

- **Cleaning:** Use a soft, dry cloth to clean the headphones. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the ports or speaker grilles. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Durability:** While designed to be kid-proof and withstand spills, avoid submerging the headphones in water. Handle with care to prevent damage to the headband and earcups.
- **Battery Care:** For optimal battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use.

Troubleshooting

If you encounter issues with your Belkin SoundForm Mini headphones, try the following solutions:

- **Headphones not turning on:** Ensure the headphones are fully charged. Connect them to a power source using the Micro-USB cable and allow them to charge for at least 30 minutes before attempting to power on again.
- **Cannot pair via Bluetooth:**
  - Ensure the headphones are in pairing mode (flashing blue light).
  - Make sure Bluetooth is enabled on your device and it is within 30 feet (9 meters) of the headphones.
  - Try turning Bluetooth off and on again on your device.
  - Forget the device from your device's Bluetooth settings and attempt to pair again.
  - Restart both the headphones and your device.
- **No sound or low volume:**
  - Check the volume level on both the headphones and your connected device.
  - Ensure the headphones are properly paired and connected.
  - If using the wired connection, ensure the 3.5mm aux cable is fully inserted into both the headphones and the audio source.
  - Remember the 85dB volume limit is a safety feature; the volume will not exceed this level.
- **Bluetooth disconnects randomly:**

- Ensure there are no significant obstacles (walls, large metal objects) between the headphones and the device.
- Move closer to the connected device to ensure you are within the 30-foot Bluetooth range.
- Minimize interference from other wireless devices operating on the same frequency (2.4 GHz).
- If the issue persists, consider using the included 3.5mm aux cable for a stable wired connection.

- **Microphone not working:**
  - Ensure the headphones are properly connected via Bluetooth.
  - Check your device's audio input settings to confirm the SoundForm Mini is selected as the microphone.
  - Test the microphone with different applications or devices.

Specifications

Feature	Detail
Model Name	SOUNDFORM Mini
Model Number	AUD001btBL
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	Up to 30 feet (9 meters)
Battery Life	Up to 30 hours
Charging Time	30 Hours
Volume Limit	85dB Safe Volume Limit
Headphones Jack	3.5 mm Jack (for wired connection)
Microphone	Built-in
Ear Placement	On Ear
Material	Plush
Item Weight	136 Grams (4.8 ounces)
Product Dimensions	7.6 x 6.5 x 3.07 inches
Manufacturer	Belkin
UPC	745883820443

Warranty and Support

Belkin products are designed for quality and durability. For specific warranty information and support, please refer to the official Belkin website or the documentation included with your product.

- **Official User Manual (PDF):** Download Here

- **Installation Manual (PDF):** Download Here
- **Instructions for Use (IFU) (PDF):** Download Here
- **Belkin Support:** Visit the official Belkin support page for FAQs, drivers, and contact information.

Image: Graphic indicating Belkin's product protection and commitment to quality, stating "Designed in California. Built for quality."

© 2025 Belkin International, Inc. All rights reserved.
Belkin and SoundForm are trademarks of Belkin International, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08V9FNDYD

More documents and user manuals: **https://manuals.plus/**