CUCKOO CR-0675FW

CUCKOO CR-0675FW Micom Rice Cooker User Manual

Model: CR-0675FW | Brand: CUCKOO

INTRODUCTION

Welcome to the user manual for your new CUCKOO CR-0675FW Micom Rice Cooker. This appliance is designed to simplify your cooking experience, offering perfectly cooked rice and various other grains with advanced technology and user-friendly features. Please read this manual thoroughly before operation to ensure safe and efficient use.

Image: The CUCKOO CR-0675FW Micom Rice Cooker, showcasing its compact and modern design.

KEY FEATURES

- **Micom Technology:** Utilizes Fuzzy Logic to automatically adjust cooking time and temperature for optimal results.

- **Versatile Capacity:** Cooks up to 6 cups of uncooked rice, yielding 12 cups of cooked rice, suitable for families and gatherings.

- **Nonstick Inner Pot:** Ensures easy food release and hassle-free cleaning.

- **13 Menu Modes:** Includes White, Quick, Multi Grain, GABA, Scorched, Multicook, Porridge, Baby Food,

Brown, Quinoa, Oatmeal, and Auto Clean.

- **LCD Display:** Provides clear visibility of settings and cooking progress.
- **Auto Clean Function:** Powerful steam sterilization for convenient and hygienic maintenance.
- **Timer Setting & Warming Mode:** Allows for delayed cooking and keeps rice warm for extended periods.
- **Removable Inner Lid:** Facilitates thorough cleaning.

Image: Designed for easy and convenient cooking, highlighting the 6-cup capacity and intelligent modes.

One Cooker, Countless Dishes

Satisfy Every Craving With a Range of Presets for Any Occasion

WHITE · GABA · MULTI GRAIN · PORRIDGE · MULTICOOK · BABY FOOD

Steamed Veggie

Brown Rice

White Rice

Braised Pork

Angel Cake

Steamed Mandu

Baby Food

Porridge

Quinoa Salad

Image: One cooker, countless dishes – illustrating the versatility for preparing various meals.

Image: Smart cooking made simple, detailing the Fuzzy Logic Technology process.

Image: Quick Mode for fast cooking and Rice Master options for customized rice texture.

SETUP

Unpacking and Initial Cleaning

1. Carefully remove all packaging materials and accessories from the box.

2. Inspect the rice cooker for any damage. Do not use if damaged.

3. Wash the nonstick inner pot, rice spatula, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely.

4. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.

5. Ensure the water collection container at the back is properly installed.

Compact Design, Big Flavor

Enjoy Delicious Food Without Taking up Valuable Counter Space

12.7 in (32.3 cm) 9.37 in (23.8 cm)

CUCKOO

8.46 in (21.5 cm)

Included Accessories

Rice Paddle   Measuring Cup   Inner Pot

Image: Compact design and included accessories for convenient use.

OPERATING INSTRUCTIONS

Basic Rice Cooking

1. Use the provided measuring cup to measure the desired amount of rice. Rinse the rice thoroughly until the water runs clear.

2. Place the rinsed rice into the nonstick inner pot.

3. Add water according to the measuring lines inside the inner pot, corresponding to the amount of rice. For example, for 2 cups of white rice, fill water to the '2' mark on the 'WHITE RICE' scale.

4. Place the inner pot into the main unit and close the lid securely.

5. Plug the power cord into a suitable electrical outlet. The LCD display will illuminate.

6. Use the **MENU SELECT** buttons (< and >) to navigate through the available cooking modes.

7. Once your desired mode (e.g., **WHITE**, **BROWN**) is selected, press the **START**/**QUICK** button twice to begin cooking.

8. The display will show
   Documents - CUCKOO – CR-0675FW

[Cuckoo CR-0675FW Multifunctional Rice Cooker User Manual](#)
Comprehensive user manual for the Cuckoo CR-0675FW 6-cup multifunctional micom rice cooker, detailing operation, features, and maintenance for optimal cooking.
lang: score:32 filesize: 24.27 M page_count: 30 document date: 2022-02-04