Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi CCL09000

Giochi Preziosi Coccolotti LoveKiss Interactive Bear Instruction Manual

Model: CCL09000

1. Introduction

The Giochi Preziosi Coccolotti LoveKiss is a charming interactive collectible bear designed to bring joy and companionship. Each bear features a luminous heart that changes color and comes with a small feeding bottle and a practical keychain, allowing you to take your Coccolotti everywhere. This manual provides essential information for the safe and enjoyable use of your Coccolotti LoveKiss bear.



Image 1.1: An assortment of Coccolotti LoveKiss bears, each in its individual blister packaging, showcasing various colors and the included accessories like the feeding bottle and heart-shaped keychain.

2. Safety Information

WARNING:

- Not suitable for children under 36 months due to small parts which can be ingested and/or inhaled. Choking hazard.
- Adult supervision is recommended during play.
- Keep packaging for future reference as it contains important information.



Image 2.1: The reverse side of the product packaging, displaying multi-language safety warnings, including the "0-3" symbol indicating unsuitability for children under three years, and other manufacturing details.

3. Package Contents

Each Coccolotti LoveKiss package contains:

- 1 x Coccolotti LoveKiss interactive bear (assorted color)
- 1 x Mini feeding bottle accessory
- 1 x Heart-shaped keychain attachment
- Batteries (pre-installed, non-replaceable)



Image 3.1: A white Coccolotti LoveKiss bear sealed in its clear blister packaging, clearly showing the bear, its small feeding bottle, and the attached heart-shaped keychain.

4. Setup

1. **Unboxing:** Carefully remove the Coccolotti LoveKiss bear and its accessories from the packaging. Retain the packaging for important information.
2. **Battery Activation:** The Coccolotti bear comes with pre-installed batteries. There is no user-replaceable battery compartment. The toy is ready for use immediately after unboxing.
3. **Keychain Attachment:** Attach the heart-shaped keychain to the loop on the bear's head if desired, to carry your Coccolotti with you.



Image 4.1: A white Coccolotti LoveKiss bear, removed from its packaging, showing its luminous heart glowing, along with its attached feeding bottle and keychain.

5. Operation

Your Coccolotti LoveKiss bear is designed to respond to your care and affection:

- **Activate the Heart:** To make the heart on the bear's tummy light up, gently **kiss** or **blow** on its tummy. The heart will illuminate.
- **Change Heart Color:** With another kiss or blow, the heart's color will change, indicating different moods or responses.
- **Feeding:** If your Coccolotti seems hungry, offer it the mini feeding bottle. While there's no interactive feeding mechanism, this action simulates care and nurturing.



Image 5.1: A pink Coccolotti LoveKiss bear with its heart glowing brightly, demonstrating the interactive light feature.

6. Care and Maintenance

- **Cleaning:** Wipe the bear with a soft, damp cloth. Do not immerse the bear in water, as this may damage the electronic components.
- **Storage:** Store the bear in a clean, dry place away from direct sunlight and extreme temperatures.
- **Battery Life:** The pre-installed batteries are designed for the product's lifespan. When the batteries are depleted, the interactive features will cease to function.

7. Troubleshooting

- **Heart not lighting up:**
  - Ensure you are gently kissing or blowing directly on the bear's tummy where the heart is located.
  - The batteries may be depleted. As batteries are non-replaceable, the interactive feature will no longer work once the battery life ends.
- **Bear appears dirty:**
  - Clean the bear as described in the "Care and Maintenance" section.

8. Specifications

Model Number:	CCL09000
Brand:	Giochi Preziosi
Dimensions (L x W x H):	6 x 15 x 18 cm (approximately 2.4 x 5.9 x 7.1 inches)
Weight:	110 grams (approximately 0.24 lbs)

Recommended Age:	3 years and up
Main Material:	Plastic
Batteries:	Included (pre-installed, non-replaceable)
Educational Value:	Social behavior development
UPC/EAN:	8056379110163

9. Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or contact Giochi Preziosi customer service directly. Specific warranty details are not provided in this manual.
For further assistance, please visit the official Giochi Preziosi website or contact their customer support channels.

© 2025 Giochi Preziosi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08XBF4DC1

More documents and user manuals: **https://manuals.plus/**