Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 81719648

Braun Silk-épil 9 SE9 Flex Epilator Head Instruction Manual

Model: 81719648

Introduction

This manual provides essential information for the proper use and maintenance of your Braun 81719648 Silk-épil 9 SE9 Flex Epilator Head. This is an Original Equipment Manufacturer (O.E.M.) authorized part, designed to ensure optimal performance and compatibility with specific Braun epilator models.

The epilator head is a crucial component for effective hair removal, featuring a design optimized for the Silk-épil 9 Flex series. It is specifically compatible with Epilators Type 5380 and models 9001, 9002, 9003, 9010, 9020, 9030, 9100, 9200, and 9300.



Image: The Braun Silk-épil 9 SE9 Flex Epilator Head, a white replacement head with gold accents, designed for precise hair removal.

Setup

Before attaching the epilator head, ensure your epilator device is clean and powered off. This replacement head is designed for easy attachment and detachment.

1. **Prepare the Epilator:** Ensure the main epilator unit is clean and free from hair or debris. Make sure it is powered off before proceeding.
2. **Align the Head:** Hold the epilator head with the epilating surface facing away from you. Align the connection points on the epilator head with the corresponding slots on the main epilator body.
3. **Attach the Head:** Gently push the epilator head onto the main unit until you hear a click, indicating it is securely fastened. Do not force the head into place.
4. **Verify Attachment:** Lightly tug on the epilator head to ensure it is firmly attached and does not wobble.

Operating Instructions

Once the epilator head is securely attached, you can begin using your Braun epilator. For best results, follow these general operating guidelines:

1. **Power On:** Turn on your Braun epilator device.
2. **Skin Preparation:** Ensure your skin is clean and dry. For optimal comfort, some users prefer to epilate after a warm shower or bath when pores are open.
3. **Positioning:** Hold the epilator at a 90-degree angle to your skin.
4. **Epilation Technique:** Gently glide the epilator head against the skin in the opposite direction of hair growth. Apply light pressure. The SensoSmart™ light on compatible models will guide you to apply the correct pressure.

5. **Slow and Steady:** Move the epilator slowly and steadily to ensure all hairs are captured. Avoid pressing too hard or moving too quickly.
6. **Post-Epilation Care:** After epilation, you may apply a soothing lotion or moisturizer to your skin.

Maintenance

Regular cleaning and maintenance of your epilator head will ensure its longevity and hygienic operation.

- **Daily Cleaning:** After each use, detach the epilator head from the main unit. Use the cleaning brush (if provided with your epilator) to brush away any trapped hairs from the epilator head.
- **Rinsing:** The epilator head can be rinsed under running water. Ensure the main epilator unit is not exposed to water unless it is specifically designed for wet & dry use. Allow the epilator head to air dry completely before reattaching or storing.
- **Deep Cleaning:** Periodically, you may use a mild soap solution to clean the epilator head. Rinse thoroughly with clean water.
- **Storage:** Store the epilator head in a clean, dry place, preferably in its original packaging or a protective pouch, away from dust and direct sunlight.
- **Replacement:** The epilator head is a consumable part. If you notice a decrease in performance, increased discomfort, or visible wear and tear on the tweezers, it is recommended to replace the head with a new O.E.M. part (Part number 81719648).

Troubleshooting

If you encounter issues with your epilator head, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Epilator head does not attach securely.	Incorrect alignment or incompatible model.	Ensure the head is aligned correctly. Verify your epilator is Type 5380 and one of the compatible models (9001, 9002, 9003, 9010, 9020, 9030, 9100, 9200, 9300).
Reduced epilation performance.	Epilator head is dirty or worn out.	Clean the epilator head thoroughly. If performance does not improve, the head may need replacement.
Increased discomfort during epilation.	Worn out tweezers or improper technique.	Ensure you are using the correct technique (90-degree angle, light pressure, against hair growth). Consider replacing the epilator head if discomfort persists.

Specifications

- **Part Number:** 81719648
- **Compatibility:** Braun Epilators Type 5380 ONLY
- **Compatible Models:** 9001, 9002, 9003, 9010, 9020, 9030, 9100, 9200, 9300
- **Brand:** Braun
- **Color:** White
- **Included Components:** Epilator Head

- **Water Resistance Level:** Not Water Resistant (for the head itself, refer to your epilator's manual for its water resistance)

Warranty & Support

This Braun O.E.M. authorized part is manufactured to high-quality standards. For specific warranty information regarding this replacement part, please refer to the warranty documentation that came with your original Braun epilator or contact Braun customer support directly.
For further assistance, technical support, or to inquire about other genuine Braun parts, please visit the official Braun website or contact their customer service line. Keep your product model number and part number handy when contacting support.
Braun Official Website: www.braun.com

© 2024 Braun. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08XKJX4RJ

More documents and user manuals: **https://manuals.plus/**