Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SHW OD-91A-M

SHW Electric Height Adjustable Standing Desk

Model: OD-91A-M

Welcome

Thank you for choosing the SHW 40-Inch Electric Height Adjustable Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Designed for modern professionals, this desk offers seamless transitions between sitting and standing positions, promoting a healthier and more productive workspace.



The SHW 40-Inch Electric Height Adjustable Standing Desk, featuring a maple desktop and white frame, designed for ergonomic comfort and productivity.

Important Safety Instructions

Please read all instructions carefully before assembly and use.

- Always follow assembly instructions carefully.
- Do not exceed the weight limit of 110 pounds.
- Ensure the desk is properly anchored to the floor to prevent tipping.
- Keep the work area clear of obstacles to prevent accidents.
- This product is not UL listed, so please use with caution.

Product Overview

Key Features:

- **Smooth Electric Height Adjustment:** Transition seamlessly between sitting and standing with the touch of a button. The quiet motorized lift system ensures stable and ergonomic positioning throughout the workday.
- **Programmable Digital Controller:** Features an intuitive LED handset with four memory presets, allowing quick access to your preferred height settings for improved workflow and comfort.
- **Optimized for Office Productivity:** Designed with the modern professional in mind, the compact 40-inch surface fits effortlessly in home offices or collaborative workspaces while supporting essential tech setups.
- **Integrated Cable Management and Hooks:** Includes a built-in cable tray to neatly organize cords and reduce desktop clutter, maintaining a clean and professional workspace.

Dimensions and Capacity:

- **Product Dimensions:** 24"D x 40"W x 28"H
- **Adjustable Height Range:** 28 inches (minimum) to 45 inches (maximum)
- **Maximum Weight Capacity:** 110 pounds



Detailed dimensions and adjustable height range of the SHW standing desk.

Setup and Assembly Guide

Unpacking:

Carefully remove all components from the packaging. Inspect all parts for any damage. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Component Checklist:

Ensure all necessary components are present before beginning assembly. Refer to the diagram below for visual identification of parts.



Assembly components and tools provided for easy setup.

Assembly Steps:

1. Attach the desk legs to the desktop using the provided screws and Allen wrench. Ensure all connections are secure.
2. Install the control panel to the underside of the desktop in the designated area.
3. Connect the motor cables to the control panel and power supply unit as per the instructions.
4. Mount the cable management tray and headphone hooks to the underside of the desk.
5. Carefully place the assembled desk in its desired location.

Operating Your Standing Desk

Height Adjustment:

To adjust the desk height, use the up (^) and down (v) arrow buttons on the digital controller. The quiet motorized system allows for smooth and stable transitions between 28 and 45 inches.



The digital control panel for easy height adjustment.

Memory Presets:

The desk features four programmable memory presets (1, 2, 3, 4) for quick access to your preferred sitting and standing heights.

- **To Set a Preset:** Adjust the desk to your desired height using the arrow buttons. Press and hold the desired preset number button (1-4) until the display beeps or flashes, indicating the height has been saved.
- **To Use a Preset:** Double-tap the corresponding preset number button (1-4). The desk will automatically move to the saved height.



The intuitive LED handset with memory preset buttons.

Cable Management:

Utilize the integrated cable management tray and hooks to keep your workspace tidy and organized.

- **Cable Tray:** Route power cords and data cables through the wire basket located underneath the desktop to reduce clutter.

- **Headphone Hooks:** Hang your headphones or other accessories on the side hooks for easy access and a clean desktop.



The cable management basket helps keep your cords organized.



Convenient hooks for hanging headphones or bags.

Care and Maintenance

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Use a mild, non-abrasive cleaner if necessary. Avoid harsh chemicals that may damage the finish.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Inspect power cords and connections for any signs of wear or damage.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent strain on the motor and frame.

Troubleshooting Common Issues

Problem	Possible Cause	Solution
Desk does not move.	Power cord disconnected or motor overload.	Check all power connections. Reduce weight on the desk if overloaded.

Problem	Possible Cause	Solution
Uneven movement or shaking.	Obstruction in the lifting mechanism or uneven weight distribution.	Clear any obstructions. Redistribute weight evenly. Ensure desk is on a flat surface.
Memory presets not working.	Incorrect programming or temporary glitch.	Re-program the desired height for the preset button. Unplug and replug the desk to reset.

Product Specifications

Attribute	Value
Brand	SHW
Model Number	OD-91A-M
Product Dimensions	24"D x 40"W x 28"H
Adjustable Height Range	28 Inches - 45 Inches
Maximum Weight Capacity	110 Pounds
Top Material Type	Oak Wood (Laminated)
Base Material	Metal

Warranty and Customer Support

Warranty Information:

This product is covered by a limited warranty. Please refer to your original purchase documentation or the SHW official website for specific warranty terms and conditions.

Customer Support:

For further assistance, technical support, or inquiries regarding your SHW Electric Height Adjustable Standing Desk, please contact SHW customer support via their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08YWBM5XG

More documents and user manuals: **https://manuals.plus/**