Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-FLT-1041

NEBO Big Larry 3 Work Light Instruction Manual

Model: NEB-FLT-1041 | Brand: NEBO

Introduction

This manual provides essential information for the safe and effective use of your NEBO Big Larry 3 Work Light. Please read this manual thoroughly before operating the device and retain it for future reference.





Image: The NEBO Big Larry 3 Work Light, a versatile flashlight and work light with a magnetic base and pocket clip.

Setup and Initial Use

Battery Installation

The NEBO Big Larry 3 requires 3 AA alkaline batteries for operation. These batteries are included with your purchase.

1. Unscrew the tail cap of the Big Larry 3 by turning it counter-clockwise.
2. Insert the 3 AA batteries according to the polarity indicators (+/-) inside the battery compartment. Ensure correct orientation to prevent damage.
3. Screw the tail cap back on clockwise until it is securely tightened.



Image: A hand demonstrating the insertion of AA batteries into the Big Larry 3 flashlight.

Disabling Demo Mode

The Big Larry 3 comes pre-set in an OEM Demo Mode. To permanently deactivate this mode and enable normal operation:

- Remove the 3 AA batteries from the device.
- Wait for at least 10 seconds.
- Reinstall the batteries as described above. Your light is now ready for normal use.

Operating Instructions

The NEBO Big Larry 3 features a versatile 3-in-1 design, functioning as a powerful work light, a focused flashlight, and a red task light. It is equipped with a push-button mode selector for easy cycling through its various light modes.



Image: A mechanic working under a vehicle, utilizing the Big Larry 3's magnetic base to illuminate the workspace.

Light Modes and Operation

Press the power button to cycle through the available light modes. The Big Larry 3 offers 7 distinct light modes, including dimmable options for both flashlight and work light functions, and a red light for night vision or signaling.

PUSH BUTTON SELECTOR

Simple and intuitive, the push button mode selector allows you to quickly cycle through light modes.



Image: A user holding the Big Larry 3, highlighting the accessible push-button selector for changing modes.

Light Mode Specifications

Mode	Lumens	Run Time	Beam Distance (Meters)
Flashlight High	220	8h	82
Flashlight Low	60	24h	50
Work Light High	600	2.5h	33
Work Light Low	150	14.5h	18
Red High	40	20h	7
Red Low	12	32h	1
Red Strobe	40	40h	7

Table: Detailed specifications for each light mode, including lumens, run time, and beam distance.



Image: The Big Larry 3 displaying its red light mode, suitable for preserving night vision.

Magnetic Base and Pocket Clip

The Big Larry 3 features a powerful magnetic base and a steel pocket clip/hanging hole, allowing for hands-free operation and versatile mounting options.

- **Magnetic Base:** Attach the light to any ferrous metal surface for stable, directed illumination. This is ideal for automotive repairs, working in tight spaces, or general hands-free tasks.
- **Pocket Clip:** Use the integrated clip to secure the light to a pocket, belt, or other gear for easy access. The clip also functions as a hanging point.



Image: The Big Larry 3 magnetically attached to the underside of a vehicle, providing hands-free lighting.

Maintenance

General Care and Cleaning

To ensure the longevity and optimal performance of your Big Larry 3 Work Light:

- Wipe the exterior of the light with a soft, damp cloth to remove dirt or debris. Avoid using abrasive cleaners or solvents.
- Ensure the tail cap is securely tightened to maintain the light's water resistance (IPX4 rated).
- Store the light in a cool, dry place when not in use.

Battery Care

- Replace all three AA batteries simultaneously when they are depleted. Do not mix old and new batteries, or different

types of batteries.

- If the light will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the device.

Troubleshooting

If you encounter issues with your NEBO Big Larry 3, refer to the following common solutions:

Common Issues and Solutions

Problem	Possible Cause	Solution
Light does not turn on or is dim.	Depleted batteries, incorrect battery installation, demo mode active.	Replace batteries with fresh AA alkaline batteries, ensure correct polarity, or disable demo mode as per 'Setup' section.
Light turns off abruptly.	Batteries are low. The light is designed to operate at full power or shut off when batteries are low, rather than dimming gradually.	Replace batteries.
Light becomes warm during prolonged use.	Normal operation, especially on higher lumen settings.	This is expected. If it becomes excessively hot or emits smoke, discontinue use immediately and contact support.
Cannot cycle through modes.	Button malfunction or low battery.	Ensure batteries are fresh. If the issue persists, contact customer support.

Table: A guide to common operational issues and their respective solutions for the Big Larry 3.

Specifications

Detailed technical specifications for the NEBO Big Larry 3 Work Light:

Model Number: NEB-FLT-1041

Dimensions: 7.76 x 0.9 x 1.18 inches (Product Dimensions: 3"D x 3"W x 10"H)

Weight: 0.42 lbs (7.2 ounces)

Power Source: Battery Powered

Battery Type: 3 x AA Alkaline Batteries (included)

Light Source Type: LED (COB)

Brightness: Up to 600 Lumens (Work Light High)

Beam Distance: Up to 82 meters (Flashlight High)

Run Time: Up to 24 hours (Flashlight Low)

Material: Aluminum

Color: Black, Gray, Orange

Special Features: Durable, Magnetic Mount, Pocket Clip, Water Resistant (IPX4)

Manufacturer: NEBO Store

UPC: 645397939658



Image: A visual representation of the Big Larry 3's key product specifications, including dimensions, weight, battery type, range, lumens, and run time.

Warranty Information

The NEBO Big Larry 3 Work Light is covered by a**1-year manufacturer's general warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
Please retain your proof of purchase for any warranty claims. The warranty does not cover damage resulting from misuse, accident, modification, unauthorized repair, or neglect.

Support and Contact

For further assistance, technical support, or warranty inquiries regarding your NEBO Big Larry 3 Work Light, please visit the official NEBO website or contact their customer service department. Specific contact details can typically be found on the manufacturer's website or product packaging.
Manufacturer: NEBO Store
While no official product videos were available from the seller for direct embedding, you may find additional product information and demonstrations on the manufacturer's official website or authorized retail channels.

© 2024 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z326WVK

More documents and user manuals: **https://manuals.plus/**