Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-TL7

Joyroom JR-TL7 TWS Wireless Earbuds

User Manual

1. Introduction

Thank you for choosing the Joyroom JR-TL7 True Wireless Stereo Earbuds. This manual provides essential information on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

2. Product Features

- **Advanced Sound:** Dual speaker, four units, powerful bass, clear treble, and real-time frequency division for comprehensive music restoration.
- **Bluetooth 5.0:** New upgrade for high-efficiency transmission and low power consumption, ensuring stable connection.
- **Automatic Pairing:** Simply pick up the earbuds from the case for instant, automatic pairing.
- **Flexible Modes:** Easy switching between single earbud mode and dual earbud mode.
- **Comfortable & Secure Fit:** Painless to wear, anti-drop design, comfortable for extended use and exercise.
- **IPX5 Water Resistance:** Resistant to water and sweat, suitable for various activities.
- **Smart Noise Reduction:** Passive sound isolation and smart call noise reduction technology for clear high-definition calls.
- **Intuitive Control:** Smart and simple touch control for easy operation.

3. Package Contents

Please check the package for the following items:

- 1 x Pair of Joyroom JR-TL7 True Wireless Earbuds
- 1 x Charging Case
- 1 x USB Type-C Charging Cable (not explicitly listed but implied by Type C charging)
- 1 x English User Manual

4. Product Overview



Figure 1: Joyroom JR-TL7 Earbuds and Charging Case. The image shows the black earbuds resting in their open charging case, with one earbud slightly elevated to show its internal components.



Figure 2: Close-up of the Joyroom JR-TL7 Earbuds in their charging case. The case is open, revealing the two earbuds nestled inside, with LED indicators visible on the front of the case.



Figure 3: Exploded view illustrating the internal sound components of the Joyroom JR-TL7 earbuds, highlighting the dual speakers and four units responsible for audio output.

5. Setup and Initial Use

5.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- Place the earbuds into the charging case. Ensure they are correctly seated.
- Connect the charging case to a power source using a USB Type-C cable.
- The LED indicators on the case will show the charging status. Once fully charged, the indicators will typically turn solid or turn off.
- Earbud battery capacity: 50mAh. Charging case battery capacity: 300mAh. Full charge time: approximately 1.5 hours.

5.2 Bluetooth Pairing

The JR-TL7 earbuds feature automatic pairing for convenience.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "JR-TL7" from the list.
5. Once connected, you will hear a confirmation prompt, and the earbud indicator lights will change.



Figure 4: Illustrates the 'pick and connect' feature, showing hands removing the earbuds from the charging case, signifying automatic pairing upon removal.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch area on both earbuds for a few seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically disconnect and power off. Alternatively, disconnect Bluetooth and the earbuds will power off after a few minutes of inactivity.

6.2 Touch Controls

The JR-TL7 earbuds feature intuitive touch controls on each earbud. Specific functions may vary slightly based on your device and application.



Figure 5: A user demonstrating the touch control feature on the earbud, highlighting the ease of operation.

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Long Press (Left/Right Earbud)	Reject Call, Activate Voice Assistant (if supported)

6.3 Single/Twin Earbud Mode

You can use either earbud independently or both together.

- **Single Earbud Mode:** Simply take one earbud out of the case. It will automatically connect to your device. The other earbud can remain in the case or be powered off.
- **Twin Earbud Mode:** Take both earbuds out of the case. They will automatically connect to each other and then to your device.

7. Maintenance and Care

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX5 water and sweat resistant. This means they can withstand splashes and sweat, but they are not designed for submersion in water. Do not wear them while swimming or showering.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

- **Avoid Drops:** While designed to be anti-drop, avoid unnecessary drops or impacts to prevent damage.



Figure 6: Demonstrates the IPX5 waterproof and sweat-resistant capabilities of the earbuds, showing water droplets on the surface.

8. Troubleshooting

If you encounter issues with your JR-TL7 earbuds, try the following solutions:

- **Earbuds not pairing with device:**
  - Ensure earbuds are charged.
  - Turn off and on Bluetooth on your device.
  - Forget/delete "JR-TL7" from your device's Bluetooth list and try pairing again.
  - Place earbuds back in the case, close the lid, wait a few seconds, then open and try again.
- **Only one earbud working:**

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, and then take them out together. They should automatically re-sync.

- **Poor sound quality:**
  - Ensure earbuds are clean and free of debris.
  - Check the audio source quality.
  - Move closer to your device to avoid interference.
- **Earbuds not charging:**
  - Ensure the charging cable is securely connected to both the case and the power source.
  - Try a different charging cable or power adapter.
  - Ensure the charging contacts on the earbuds and inside the case are clean.

9. Specifications

Feature	Detail
Product Dimensions	21.1 x 16.7 x 3.3 cm; 140 grams
Model Number	JR-TL7
Brand	Joyroom
Color	Black
Ear Placement	In-Ear
Headphones Form Factor	In-Ear
Sensitivity	97.5 dB
Headphone Jack	USB
Model Name	True Wireless
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Included Components	Wireless Charging Case
Bluetooth Protocol	HFP, A2DP, AVRCP
Frequency Response Range	20Hz-20KHz
Microphone Sensitivity	38dB+/-3
Headphone Battery Capacity	50mAh
Rated Power	2mW

Feature	Detail
Charging Case Battery Capacity	300mAh
Music/Talk Time	6 hours
Charging Time	1.5 hours
Standby Time	20 hours
Bluetooth Version	5.0
Average Battery Life	Less than 8 hours
Charging Type	Type C

10. Warranty and Support

Joyroom products are manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included in your product packaging or visit the official Joyroom website.

If you experience any issues or have questions regarding your JR-TL7 earbuds, please contact Joyroom customer support through their official channels. Provide your product model number (JR-TL7) and purchase details for faster assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z49SJWN

More documents and user manuals: **https://manuals.plus/**