Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NATERIAL AVEA 82232801

NATERIAL AVEA Offset Parasol Instruction Manual

Model: AVEA 82232801

Introduction

Thank you for choosing the NATERIAL AVEA Offset Parasol. This manual provides essential information for the safe assembly, operation, and maintenance of your parasol. Please read these instructions carefully before use and retain them for future reference.

Safety Information

- Always ensure the parasol base is adequately weighted to prevent tipping, especially in windy conditions.
- Do not use the parasol during strong winds, heavy rain, or storms. Close and secure the parasol to prevent damage or injury.
- Keep children and pets away from the parasol during opening and closing operations.
- Regularly inspect all components for wear, damage, or loose connections. Do not use if any part is damaged.
- Avoid placing the parasol near open flames or heat sources.
- Ensure sufficient clearance around the parasol when opening and rotating to avoid obstructions.

Package Contents

Verify that all components are present before beginning assembly:

- Parasol Canopy with Frame
- Main Pole
- Cross Base
- Crank Handle
- Assembly Hardware (screws, bolts, etc. - specific details not provided, assume standard)



Image: The NATERIAL AVEA Offset Parasol in its closed, upright position. Accompanying icons illustrate the crank lift mechanism, the easy-grip handle for adjustments, and the necessity of a weighted base for stability.

Setup Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble the Base:** Attach the main pole to the cross base using the provided hardware. Ensure all connections are secure.
3. **Weight the Base:** It is crucial to weigh down the cross base with appropriate parasol base weights (not included) to ensure stability. Refer to the parasol's weight specifications for guidance.
4. **Attach the Canopy:** Carefully lift the parasol canopy and frame assembly and insert it into the top of the main pole. Secure it according to the specific design (e.g., locking pin or screw).
5. **Initial Check:** Before first use, ensure all parts are correctly assembled and tightened.

Operating Instructions

1. **Opening the Parasol:** Turn the crank handle clockwise to extend the canopy until it is fully open. Do not force the crank if resistance is met.
2. **Closing the Parasol:** Turn the crank handle counter-clockwise to retract the canopy until it is fully closed. Secure the canopy with any integrated ties or straps.
3. **Tilting the Canopy:** The parasol features a manual tilt mechanism. Locate the tilt lever or button on the pole and adjust the canopy angle as desired to block the sun. Release the lever/button to lock the tilt position.
4. **Rotating the Parasol:** The parasol can rotate 360 degrees. Unlock the rotation mechanism (if present, typically a foot pedal or lever at the base) and gently rotate the canopy to the desired position. Lock the mechanism once positioned.



Image: A detailed view of the NATERIAL AVEA parasol canopy, highlighting its water-repellent polyester fabric and the robust steel ribs that support its hexagonal shape.

Maintenance

- **After Use:** Always close the parasol using the lateral handle and crank. Secure it to prevent accidental opening or wind damage.
- **Cleaning the Canopy:** Wipe the canopy with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Ensure the canopy is completely dry before closing or storing to prevent mildew.
- **Frame Care:** Regularly inspect the aluminum frame and steel ribs for any signs of damage, rust, or corrosion. Clean the frame with a dry cloth. If necessary, use a mild detergent and dry immediately.
- **Storage:** During off-season or prolonged periods of non-use, store the parasol in a dry, protected area. Consider using a protective cover to extend its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Parasol does not open/close smoothly.	Mechanism is dirty or obstructed.	Clean the crank mechanism and pole. Check for any debris or obstructions. Apply a silicone-based lubricant if necessary.
Parasol is unstable or tips over.	Base is not adequately weighted.	Ensure the cross base is weighted with appropriate parasol base weights (e.g., sandbags, water-filled bases). Do not use in high winds.
Canopy fabric appears stained or dirty.	Exposure to elements, dirt accumulation.	Clean the canopy with a damp cloth and mild soap solution. Rinse thoroughly and allow to air dry completely.
Frame components show signs of rust.	Prolonged exposure to moisture without proper drying.	Clean affected areas with a wire brush (for steel) or fine-grit sandpaper (for aluminum corrosion). Apply rust-inhibiting paint or a protective coating. Ensure regular drying after rain.

Specifications

Model: AVEA 82232801

Brand: NATERIAL

Dimensions (L x W x H): 289 x 289 x 251 cm

Canopy Diameter: 290 cm

Weight: 17 kg

Canopy Shape: Hexagonal

Canopy Material: Polyester (200 g/m²)

UV Protection: 95%

Pole Material: Aluminum

Frame Material: Steel ribs

Opening Mechanism: Crank Lift

Tilt Mechanism: Manual Tilt

Rotation: 360° (Offset design)

Special Feature: Illuminated (as per product specifications, details not provided)

Intended Use: Outdoor Sun Protection

Components Included: Parasol, Cross Base, Crank Handle



Image: A diagram illustrating the key dimensions of the NATERIAL AVEA Offset Parasol, including its width, depth, and height when fully open.

Warranty and Support

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official NATERIAL website. Please have your model number (AVEA 82232801) and proof of purchase available when contacting support.

© 2023 NATERIAL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZYQRRDS

More documents and user manuals: **https://manuals.plus/**