Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO NEB-FLT-0014-G

NEBO Newton 500 Lumens LED Flashlight User Manual

Model: NEB-FLT-0014-G

Introduction

Thank you for choosing the NEBO Newton 500 Lumens LED Flashlight. This manual provides detailed instructions for the proper setup, operation, and maintenance of your device. Please read this manual thoroughly before use to ensure optimal performance and longevity of your flashlight.



Image: The NEBO Newton 500 Lumens LED Flashlight, showcasing its sleek black design and compact form factor.

Product Features

- **Ultra Brightness:** Delivers up to 500 lumens for clear illumination.
- **Easy Operation:** Features an easy-touch power button and a mode selection dial.
- **Durable Design:** Constructed from anodized aircraft-grade aluminum, IP67 waterproof, and impact resistant up to 1 meter.
- **Versatile Zoom:** Equipped with a 3x zoom function for adjustable beam focus.
- **Magnetic Base:** Integrated magnetic base for hands-free operation.
- **Power Saving:** Advanced dimming technology to extend battery life.



Image: An illustration highlighting the key features of the NEBO Newton 500 flashlight: Magnetic Base, Integrated Zoom, Easy-Touch Technology, and IP67 Waterproof rating.

Setup

Battery Installation

The NEBO Newton 500 Lumens flashlight requires 3 AAA alkaline batteries (included). Follow these steps to install or replace batteries:

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert 3 AAA batteries into the battery compartment, ensuring the correct polarity (+/-) as indicated inside the compartment.
3. Screw the tail cap back on clockwise until it is securely tightened. Do not overtighten.

Operating Instructions

Power On/Off and Mode Selection

The flashlight features an easy-touch power button and a mode selection dial for seamless operation.

- **To Power On/Off:** Press the power button located on the tail cap.
- **To Change Modes:** With the flashlight on, rotate the mode selection dial located near the head of the flashlight to cycle through the available light modes: High, Medium, Low, and Strobe.

Zoom Function

The 3x zoom function allows you to adjust the beam from a wide floodlight to a focused spotlight.

- To adjust the zoom, gently slide the head of the flashlight forward or backward.
- Slide forward for a more focused, narrower beam.
- Slide backward for a wider, floodlight beam.



Image: A close-up view of the NEBO Newton flashlight, illustrating the integrated zoom mechanism and emphasizing its ultra-bright light output.



Image: A graphic detailing the four light modes of the NEBO Newton 500: High (500 Lumens, 2 hours, 146 meters), Medium (300 Lumens, 5 hours, 37 meters), Low (30 Lumens, 20 hours, 14 meters), and Strobe (500 Lumens, 2 hours, 46 meters).



Image: A visual depiction of the four distinct light modes (High, Medium, Low, Strobe) emitted by the NEBO Newton flashlight.

Maintenance

Cleaning

To maintain the performance and appearance of your flashlight:

- Wipe the exterior with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Keep the lens clean for optimal light output.

Battery Care

- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Replace all batteries at the same time with new ones of the same type.

Durability and Water Resistance

The NEBO Newton 500 is constructed from anodized aircraft-grade aluminum, making it highly durable. It is IP67 waterproof, meaning it is protected from immersion in water up to 1 meter for 30 minutes. While durable, avoid unnecessary impacts or submersion beyond specified limits.



Image: A close-up of the NEBO Newton flashlight, emphasizing its construction from anodized aircraft-grade aluminum, which contributes to its robust and long-lasting design.

Troubleshooting

If you encounter issues with your NEBO Newton 500 flashlight, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.
Light is dim or flickers.	Low battery power. Loose tail cap.	Replace batteries. Ensure tail cap is securely tightened.

Problem	Possible Cause	Solution
Cannot change light modes.	Mode selection dial obstructed or damaged.	Ensure dial is free of debris. If issue persists, contact customer support.
Zoom function is stiff.	Dirt or debris in the sliding mechanism.	Gently clean the sliding parts. Avoid forcing the mechanism.

Specifications

Feature	Specification
Model Number	NEB-FLT-0014-G
Brightness	500 Lumens (Max)
Light Source Type	LED
Power Source	Battery Powered
Battery Type	3 x AAA Alkaline batteries (included)
Runtime (Max)	Up to 20 hours (Low mode)
Light Path Distance (Max)	146 Meters (High mode)
Material	Anodized Aircraft-Grade Aluminum
Water Resistance Level	IP67 Waterproof
Impact Resistance	Up to 1 meter
Product Dimensions	1.34"D x 1.34"W x 5.24"H
Item Weight	5.4 ounces (154 grams)
Special Features	3x Zoom, Magnetic Base

Warranty and Support

NEBO products are designed for durability and performance. This product comes with a manufacturer's guarantee. For specific warranty details, claims, or technical support, please visit the official NEBO website or contact their customer service department. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the NEBO Store on Amazon.

© 2025 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091C4PFYT

More documents and user manuals: **https://manuals.plus/**