Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFMIS567_AMZ

Frigidaire EFMIS567_AMZ Retro Mini Drink Fridge Instruction Manual

Model: EFMIS567_AMZ | Brand: Frigidaire

Introduction

This manual provides essential information for the safe and efficient operation of your Frigidaire EFMIS567_AMZ Retro Mini Drink Fridge. Please read these instructions thoroughly before use and retain them for future reference.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.

- Ensure the unit is placed on a stable, level surface.
- Do not block ventilation openings. Allow at least 2 inches of clearance from the back and sides for proper air circulation.
- Do not use near water or in excessively humid environments.
- Unplug the unit before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Product Features

- **Capacity:** 12 Liters, accommodating up to 18 standard 12-oz cans or 4 wine bottles.
- **Cooling/Warming Function:** Thermoelectric system allows for cooling down to 38°F or warming.
- **Adjustable Temperature Control:** Digital display for precise temperature settings.
- **Eco-Friendly:** 100% Freon-Free, no harsh chemicals, and no compressor for quiet, vibration-free operation.
- **Versatile Power Options:** Includes adapters for both home (110V AC) and car (12V DC) outlets.
- **Design:** Sleek stainless steel finish with a tempered glass front and a convenient carrying handle.
- **Removable Shelving:** Allows for flexible storage configurations.

Setup

1. **Unpacking:** Carefully remove all packaging materials. Inspect the unit for any damage.
2. **Placement:** Position the mini fridge on a firm, level surface. Ensure adequate ventilation by leaving at least 2 inches of space around the back and sides.
3. **Initial Power-Up:** Connect the appropriate power adapter (AC for home, DC for car) to the unit and then to the power source. Allow the unit to stand upright for at least 2 hours before plugging it in to allow any refrigerant to settle.
4. **Pre-Cooling:** For optimal performance, allow the unit to operate empty for at least 2 hours to reach the desired temperature before loading items.


FRIGIDAIRE

Image: The Frigidaire EFMIS567_AMZ Retro Mini Drink Fridge in stainless steel finish.

Operating Instructions

Powering On/Off and Mode Selection

- Locate the COLD/OFF/HOT switch on the back of the unit.
- To cool, slide the switch to the "COLD" position.
- To warm, slide the switch to the "HOT" position.
- To turn off the unit, slide the switch to the "OFF" position.

Temperature Adjustment

- The digital display on the front of the unit shows the current temperature.
- Use the up (▲) and down (▼) arrow buttons to adjust the desired temperature. The unit can cool down to 38°F.
- Note: The displayed temperature may not always reflect the exact internal temperature, especially during initial cooling or when frequently opened.

Loading Beverages

- The unit features removable shelves for flexible storage. Gently slide shelves out to remove or adjust.
- Arrange items to allow for proper air circulation for efficient cooling. Avoid overfilling.
- The unit can hold up to 18 standard 12-oz cans or 4 wine bottles.

Compact Yet Spacious

18 Can/ 4 Bottle Storage Capacity



Image: The mini fridge interior showing capacity for 18 cans.



Image: The mini fridge interior with wine bottles and highlighting removable shelving and versatile power options.

Maintenance

Cleaning

- Always unplug the unit before cleaning.
- Wipe the interior and exterior surfaces with a soft cloth and mild detergent. Do not use abrasive cleaners or harsh chemicals.
- Ensure the unit is completely dry before plugging it back in.

Drip Tray

- The unit may accumulate condensation in the drip tray located at the bottom.
- Periodically check and empty the drip tray to prevent overflow.

Troubleshooting

Problem	Possible Cause	Solution
Unit not cooling/warming	Not plugged in; power switch in OFF position; ventilation blocked.	Ensure unit is plugged in and switch is in COLD/HOT position. Check for obstructions around vents.
Temperature not reaching desired level	Ambient temperature too high; door opened frequently; unit overfilled.	Place unit in a cooler environment. Minimize door openings. Do not overfill.
Excessive condensation	High humidity; door not sealed properly.	Ensure door is closed tightly. Check door seal for damage. Empty drip tray regularly.

Specifications

Feature	Detail
Brand	Frigidaire
Model Number	EFMIS567_AMZ
Capacity	12 Liters
Cooling Method	Thermoelectric
Temperature Range	Cools down to 38°F
Power Input	110 Volts AC, 12 Volts DC
Dimensions (D x W x H)	11 x 11.5 x 20 inches
Item Weight	13.1 pounds
Defrost System	Automatic

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or visit the official Frigidaire website. Keep your purchase receipt for warranty claims.

Official Product Videos

▶ **Watch video online**
Product Overview Video

Video: A brief overview of the Frigidaire EFMIS567_AMZ Mini Drink Fridge, showcasing its design and features.

▶ **Watch video online**
FRIGIDAIRE Beverage Fridge

Video: Demonstrates the Frigidaire Beverage Fridge, highlighting its capacity and ease of use.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B091FYKBP5

More documents and user manuals: **https://manuals.plus/**