Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Biolomix T5200

BioloMix Professional Countertop Blender User Manual

Model: T5200

1. Safety Information

Please read all instructions carefully before using your BioloMix Professional Countertop Blender. Retain this manual for future reference.

General Safety Precautions

- Always ensure the blender is unplugged before cleaning or when not in use.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender.
- Supervise children closely when the appliance is in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

Blender Specific Safety

- The blades are extremely sharp. Handle with care.
- Never operate the blender without the lid securely in place.
- Do not overfill the container. Ensure ingredients are below the maximum fill line.
- The blender features a **Jar Safety Switch**. The motor will not operate unless the blending container is correctly seated on the motor base.

For visual reference on the safety switch:



Image: Safety lock switch design. If the jar tilts during operation, the motor power will be cut off immediately.

2. Product Overview

Components

Your BioloMix Professional Countertop Blender package includes the following components:

- Motor Base
- 2L Blending Container with Lid
- Tamper Stick
- Full Extra Parts (as specified in your purchase)
- User Manual (this document)



Image: Exploded view of the BioloMix Blender components: Main unit, Jar, Lid with inserter, Stirring stick, Replacement blades, drive socket and tool, and Instruction manual.

Key Features

- **High Power Motor:** Equipped with a Max 2200W power, 3 peak horsepower motor for efficient blending.
- **Durable Blades:** Features hardened Japan stainless steel six-wave action blades for superior crushing and blending.
- **Variable Speed Control:** Allows for precise control to achieve a variety of textures, from slow to high speed.
- **Pulse Function:** Provides instant maximum speed for quick bursts of power, ideal for chopping or

refreshing ingredients.

- **Integrated Timer:** Set blending times from 1 to 5 minutes, with automatic stop for convenience and safety.
- **Large Capacity:** 2-liter (68 oz) BPA-free blending container, suitable for family-sized portions.
- **Multi-functional:** Capable of ice crushing, smoothies, frozen desserts, soups, nuts, sauces, hummus, dips, shakes, juices, salsas, and hot soups.
- **Easy Cleaning:** One-button switch for thorough cleaning, or use the pulse function with water for quick self-cleaning.

Product Details



Image: Product details highlighting high-speed turbo blending, 6 pieces 304 stainless steel blades, and a powerful motor.



Image: Key features of the blender, including the rubber seal lid, safety switch buttons, ON/OFF switch, speed control, pulse function, and 1-5 minutes timer.




Image: Detailed view of the control panel, showing the variable speed dial, 1-5 minutes timer, START/STOP button, and PULSE button.



Image: Close-up of the 6 stainless steel cutting blades, demonstrating their effectiveness with various ingredients like fruits, vegetables, and ice.

3. Setup

Before first use, unpack all components and wash the blending container, lid, and tamper stick with warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.

Assembly

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the blending container is empty and clean.
3. Carefully place the blending container onto the motor base, aligning it correctly until it clicks into place. The safety switch will engage when properly seated.
4. Add your desired ingredients to the container.

5. Secure the lid firmly onto the container. Ensure the lid plug is also in place.
6. Plug the blender into a suitable power outlet.

4. Operating Instructions

The BioloMix Professional Countertop Blender offers versatile blending options. Always start with the lowest speed and gradually increase as needed.

Basic Blending

1. Prepare ingredients and place them into the blending container. For best results, add liquids first, then soft ingredients, followed by hard ingredients and ice.
2. Secure the lid and lid plug.
3. Turn the ON/OFF switch to the 'ON' position.
4. Select your desired blending time using the timer dial (1-5 minutes) or turn the dial to 'START' for continuous operation.
5. Adjust the speed control dial to your desired blending intensity.
6. For quick bursts of power, use the **PULSE** button. Hold for desired duration, then release.
7. If ingredients get stuck, use the tamper stick through the lid plug opening to push them towards the blades. **Only use the tamper stick when the blender is running and the lid is securely in place.**
8. Once blending is complete, turn the ON/OFF switch to 'OFF' and unplug the blender.

Demonstration Video: Blender for Kitchen with 2200-Watt Motor

▶ **Watch video online**
Blender for Kitchen with 2200-Watt Motor

Video: This official product video demonstrates the BioloMix blender's capabilities, including making green smoothies, milkshakes, dry grinding, hot drinks, and peanut butter. It showcases the control panel and blending process for various ingredients.

Applications

The BioloMix blender is designed for a wide range of culinary tasks:

- **Smoothies & Juices:** Blend fruits, vegetables, and ice for refreshing drinks.
- **Hot Soups:** The high-speed friction can heat ingredients, allowing you to make hot soups directly in the blender.
- **Nut Butters:** Create homemade peanut butter, almond butter, and other nut spreads.
- **Dry Grinding:** Grind coffee beans, grains, or spices into fine powders.
- **Frozen Desserts:** Make ice cream, sorbets, and frozen yogurts.
- **Sauces & Dips:** Prepare salsas, hummus, and other creamy sauces.

DIY Vegetables and Fruits Drinks



Image: Examples of DIY vegetable and fruit drinks that can be made with the blender, including orange juice and watermelon slush.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your BioloMix blender.

Automatic Cleaning

For quick and easy cleaning after blending, especially for liquid mixtures:

1. Fill the container halfway with warm water and add a few drops of dish soap.
2. Secure the lid.
3. Turn the ON/OFF switch to 'ON'.
4. Press and hold the **PULSE** button for 30-60 seconds, or until clean.
5. Rinse the container thoroughly with clean water.



Image: Demonstration of the one-click automatic cleaning feature, showing the PULSE button being pressed and the container cleaning itself.

Manual Cleaning

- **Container and Lid:** For more thorough cleaning, disassemble the container and lid. Wash with warm, soapy water using a soft brush for hard-to-reach areas. Rinse and dry completely.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not use abrasive cleaners or immerse in water.
- **Blades:** Exercise extreme caution when cleaning the blades as they are very sharp. Use a brush to clean around the blades.

Storage

Store the blender in a clean, dry place. Ensure the container is completely dry before storing to prevent mold or odors. Do not store the tamper stick inside the container with the lid on, as this may damage the lid or blades.

6. Troubleshooting

If you encounter issues with your BioloMix blender, refer to the common problems and solutions below:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Jar not correctly seated; Overload protection activated.	Ensure power cord is securely plugged in. Check if the container is properly seated on the motor base. If motor overheats, the **Overload Reset Switch** on the bottom of the unit may have tripped. Press to reset.
Ingredients are not blending smoothly or getting stuck.	Too little liquid; Too many ingredients; Ingredients are too large or dense.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the tamper stick to push ingredients towards the blades. Increase speed.
Burning smell from motor.	Overloading the motor; Prolonged continuous operation.	Turn off the blender immediately and unplug. Reduce ingredients or add more liquid. Allow the motor to cool down for at least 15-20 minutes. The blender has a powerful cooling system and overheating protection.
Loud noise during operation.	Improper assembly; Hard ingredients; Air pocket around blades.	Ensure the container is correctly seated. This is normal when blending very hard ingredients or ice. Use the tamper to break up air pockets.

For visual reference on the cooling system and overload protection:



Image: Diagram illustrating the powerful cooling fan and the location of the Overload Reset Switch on the bottom of the motor base.

7. Specifications

Feature	Specification
Brand	Biolomix
Model Number	T5200
Power	Max 2200W (3 Peak Horsepower)

Feature	Specification
Voltage	110 Volts
Capacity	2 Liters (68 oz)
Blades	Hardened Japan Stainless Steel Six-Wave Action Blades
RPM	Up to 30,000 RPM
Special Feature	Timer Controlling (1-5 minutes)
Controls Type	Knob (Variable Speed, Timer)
Material Type Free	BPA Free
Product Dimensions	9"D x 7.9"W x 19.6"H
Item Weight	9.9 pounds
UPC	786562843605

8. Warranty and Support

Your BioloMix Professional Countertop Blender is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your product for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact BioloMix customer service through the retailer where you purchased the product or visit the official BioloMix website for contact information.

Note: Keep your purchase receipt as proof of purchase for warranty purposes.

© 2024 BioloMix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093BXDPC7

More documents and user manuals: **https://manuals.plus/**