Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VIKICON B093Q22VTB

VIKICON B093Q22VTB All-in-One Grooming Kit Instruction Manual

Model: B093Q22VTB

Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Setup

Before first use, ensure all components are present and the device is fully charged.

1.1 Unboxing and Components

The VIKICON All-in-One Grooming Kit includes the following items:

- Grooming Device Handle
- 6 Interchangeable Trimmer Heads: Hair Trimmer, Hair Clipper, Nose/Ear Trimmer, Design Trimmer, Electric Shaver, Body Razor
- 5 Guide Combs for various trimming lengths
- Cleaning Brush
- Blade Oil
- USB Charging Cable
- Travel Case



Figure 1: All components of the VIKICON Grooming Kit, including the main device, various trimmer heads, guide combs, cleaning brush, oil, USB cable, and travel case.

1.2 Initial Charging

Fully charge the grooming device before its first use to ensure optimal battery performance. The device features an LED display to indicate battery life and charging status.

- Connect the USB charging cable to the device and a compatible USB power source (e.g., computer, USB wall adapter).
- A full charge takes approximately 1.5 hours and provides up to 90 minutes of cordless use.



Figure 2: The grooming device connected to a USB power source for charging. The LED display shows charging progress.

1.3 Attaching and Detaching Trimmer Heads

To change trimmer heads:

1. Ensure the device is turned off.
2. Gently pull the currently attached head upwards to detach it from the main body.
3. Align the desired trimmer head with the device body and press down firmly until it clicks into place.

Your browser does not support the video tag.

Video 1: Demonstration of attaching and detaching various trimmer heads from the VIKICON grooming device. This video illustrates the simple click-on/click-off mechanism for changing heads.

2. Operating Instructions

The VIKICON Grooming Kit offers versatile functionality for various grooming needs.

2.1 Power On/Off and Speed Adjustment

- To turn the device on or off, press the power button located on the front.
- The device features two speed modes: 7200 RPM for everyday use and 8800 RPM for thicker hair. Press the power button briefly while the device is on to switch between speeds.
- The LED display will show the current speed setting.

2.2 Travel Lock and Child Safety Lock

To prevent accidental activation, the device includes a travel lock feature:

- To activate the travel lock, press and hold the power button for 3 seconds until a lock icon appears on the LED display.
- To deactivate the travel lock, press and hold the power button for 3 seconds again until the lock icon disappears.

2.3 Using Trimmer Heads and Guide Combs

Select the appropriate trimmer head and guide comb for your desired grooming task:

- **Hair Trimmer/Clipper:** Use with 3mm, 6mm, 9mm, or 12mm guide combs for hair cutting and beard trimming.
- **Beard Trimmer:** Use with the adjustable comb (1-4mm) for precise beard styling and maintenance.
- **Nose/Ear Trimmer:** Designed for safe and comfortable removal of unwanted nose and ear hair.
- **Design Trimmer:** For creating sharp lines and intricate designs in hair.
- **Electric Shaver:** For a close, smooth shave on face or body.
- **Body Razor:** Use with 3mm or 5mm guide combs for body grooming.



Figure 3: The VIKICON grooming device being used for beard trimming, demonstrating its ergonomic design and ease of use.




Figure 4: Illustration of different guide comb lengths (3mm, 6mm, 9mm, 12mm) for the full-size trimmer and adjustable comb (1-4mm) for the precision trimmer.

Your browser does not support the video tag.

Video 2: An overview of the VIKICON All-in-One Grooming Kit, showcasing its various heads and their applications for beard, hair, ear, nose, and body grooming.

3. Maintenance

Proper maintenance ensures the longevity and performance of your grooming kit.

3.1 Cleaning

- The device is IPX7 waterproof, allowing for easy cleaning under running water.
- Detach the trimmer head and rinse it thoroughly under warm water after each use.
- Use the provided cleaning brush to remove any trapped hairs from the blades and inside the trimmer head.
- Ensure all parts are completely dry before reattaching or storing the device.



Figure 5: The waterproof design of the VIKICON grooming device allows for easy cleaning by rinsing the detachable blade under running water.

3.2 Blade Lubrication

- Regularly apply a small drop of the provided blade oil to the trimmer blades.
- Turn on the device for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

4. Troubleshooting

If you encounter issues with your VIKICON Grooming Kit, refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Check if the travel lock is activated (a lock icon on the LED display). Deactivate by pressing and holding the power button for 3 seconds.
- **Poor trimming performance:** Clean the blades and trimmer head thoroughly to remove any hair buildup. Apply blade oil to lubricate the blades. Ensure the correct guide comb is securely attached.

- **Device not charging:** Verify that the USB cable is correctly connected to both the device and the power source. Try a different USB cable or power adapter.

Your browser does not support the video tag.

Video 3: A short video demonstrating a common issue where the device is not charging. This can help users identify if their device is experiencing a similar problem.

5. Specifications

Feature	Detail
Brand	VIKICON
Model	B093Q22VTB
Waterproof Rating	IPX7
Battery Type	Lithium Ion (1 included)
Charging Time	1.5 hours
Cordless Use Time	90 minutes
Motor Speed Modes	7200 RPM (standard), 8800 RPM (high)
Included Components	5 Guide Combs, 6 Interchangeable Trimmer Heads, Beard Trimmer, Cleaning Brush, Travel Case
Package Dimensions	8.78 x 7.13 x 3.31 inches
Weight	1.39 Pounds

6. Warranty & Support

6.1 Warranty Information

The VIKICON B093Q22VTB All-in-One Grooming Kit comes with a two-year warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

6.2 Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact VIKICON customer support through the official channels provided at the time of purchase or on the product packaging. You may also visit the **VIKICON Store on Amazon** for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093Q22VTB

More documents and user manuals: **https://manuals.plus/**