Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP DOE5500BTU

ZOKOP Portable Air Conditioner User Manual

Model: DOE5500BTU (YPO2-09C)

1. Introduction

Thank you for purchasing the ZOKOP Portable Air Conditioner. This manual provides important information for the proper installation, operation, and maintenance of your air conditioner. Please read this manual thoroughly before using the appliance to ensure safe and efficient operation. Keep this manual for future reference.

2. Safety Instructions

To prevent injury to the user or other people and property damage, the following instructions must be followed. Incorrect operation due to ignoring instructions may cause harm or damage.

- Always operate the unit on a grounded power outlet.
- Do not operate the unit with wet hands.
- Do not block the air inlets or outlets.
- Do not allow children to play with the air conditioner.
- Unplug the unit before cleaning or servicing.
- Ensure the unit is placed on a flat, stable surface to prevent tipping.
- Do not use chemical solvents to clean the unit.

3. Product Overview

3.1 Components and Features

The ZOKOP Portable Air Conditioner is designed for efficient cooling, dehumidifying, and fan-only operation. It features a compact design with casters for easy mobility, a remote control for convenient operation, and a washable filter for easy maintenance.



Image: The ZOKOP portable air conditioner unit, shown with its remote control and visual representation of cool air being expelled, highlighting its primary function.



Image: An infographic illustrating the main features of the air conditioner, such as portability, powerful cooling, low noise operation, smart memory, remote control capability, water circulation system, two-way timing, child lock function, and a user-friendly display panel.

3.2 Included Accessories



Image: A visual representation of all components included in the product package: AAA batteries, remote control, exhaust hose, exhaust hose connector, fixing screws, drain pipe, and the window seal-plate kit.

- Portable Air Conditioner Unit
- Remote Control (requires AAA batteries, included)
- Exhaust Hose
- Exhaust Hose Connector
- Window Seal-Plate Kit
- Drain Pipe
- Fixing Screws

4. Setup and Installation

4.1 Choosing a Location

Place the air conditioner on a flat, stable surface near a window or opening where the exhaust hose can be vented.

Ensure there is at least 20 inches (50 cm) of space around the unit for proper air circulation.

4.2 Window Kit Installation

1. Assemble the window seal-plate kit according to your window type (sliding or casement).
2. Extend the exhaust hose and attach one end to the exhaust hose connector.
3. Attach the other end of the exhaust hose connector to the exhaust outlet on the back of the air conditioner unit.
4. Insert the window kit into the window opening and secure it.
5. Connect the exhaust hose to the opening in the window kit, ensuring a tight seal to prevent hot air from re-entering the room.

4.3 Drain Pipe Connection (Dehumidifying Mode)

For continuous drainage in dehumidifying mode, connect the provided drain pipe to the continuous drain port on the back of the unit. Route the pipe to a suitable drain or container, ensuring it is lower than the drain port for gravity flow.

5. Operating Instructions

5.1 Control Panel



Image: A detailed view of the unit's top control panel, showing the digital display, power button, mode selection, fan speed, timer, and temperature adjustment buttons, along with indicator lights for different operational states.

- **POWER Button:** Turns the unit ON or OFF.

- **MODE Button:** Cycles through operating modes: Cool, Fan, Dry (Dehumidify), Sleep.
- **FAN Button:** Adjusts fan speed (Low, High).
- **TIMER Button:** Sets the auto-on or auto-off timer.
- **Temperature Adjustment Buttons (Up/Down Arrows):** Adjusts the desired temperature in Cool mode.
- **Indicator Lights:** Show current mode (Cool, Fan, Dry, Sleep), fan speed (Low, High), and timer status. A 'Full Water' indicator will light up when the internal water tank is full and needs draining.

5.2 Remote Control



Image: The portable air conditioner unit positioned next to its remote control, emphasizing the convenience of remote operation.

The remote control duplicates most functions of the control panel, allowing for convenient operation from a distance. Ensure the remote control is pointed towards the unit's receiver when pressing buttons.

5.3 Operating Modes

- **Cool Mode:** Provides cooling. Set desired temperature using the Up/Down arrows.
- **Fan Mode:** Circulates air without cooling. Fan speed can be adjusted.
- **Dry (Dehumidify) Mode:** Removes moisture from the air. The fan speed is fixed to low in this mode. Continuous drainage is recommended.
- **Sleep Mode:** Increases the set temperature by 1°F after 30 minutes, and by another 1°F after another 30 minutes. This temperature is maintained for 7 hours before returning to the original setting. This mode is designed for comfortable sleep and energy saving.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

6.1 Air Filter Cleaning

The air filter should be cleaned every two weeks or more frequently depending on usage and air quality.

1. Unplug the unit from the power outlet.
2. Remove the air filter from the back of the unit.
3. Wash the filter with lukewarm water and a mild detergent. Rinse thoroughly.
4. Allow the filter to air dry completely before reinstalling. Do not expose to direct sunlight.

6.2 Draining Water

The unit has an internal water tank that collects condensed water. When the tank is full, the 'Full Water' indicator will light up, and the unit will stop operating. You must drain the water.

1. Turn off the unit and unplug it.
2. Place a shallow pan or tray under the drain port at the bottom rear of the unit.
3. Remove the drain plug to allow water to flow out.
4. Once drained, replace the drain plug securely.

6.3 Unit Cleaning and Storage

- Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasives.
- Before long-term storage, drain all water from the unit and clean the air filter.
- Store the unit in a cool, dry place, covered to protect it from dust.

7. Troubleshooting

If you encounter issues with your air conditioner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply. Full water tank.	Check power cord and outlet. Drain the water tank.

Problem	Possible Cause	Solution
Unit does not cool.	Air filter clogged. Room temperature too low. Exhaust hose not properly installed. Windows/doors open.	Clean the air filter. Ensure set temperature is lower than room temperature. Check exhaust hose connection and window kit seal. Close all windows and doors.
Unit is noisy.	Unit not on a flat surface. Air filter clogged.	Place unit on a flat, stable surface. Clean the air filter.
Water leakage.	Drain plug loose. Unit tilted.	Securely fasten the drain plug. Ensure unit is level.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications



Cooling Capacity: 8000BTU/H	Power Supply: 115V/60Hz
AC Coverage Area (Sq. Ft.): 300Sq. Ft.	Temperature Range: 62.5°F-86°F
Product Weight: 57.32lbs	Product Dimension: 11.81" x 29.76" x 13.86"

Image: A diagram detailing the physical dimensions of the air conditioner and a summary of its key performance specifications.

Specification	Value
Model Number	DOE5500BTU (YPO2-09C)
Cooling Capacity	8000 BTU/H (DOE 5500 BTU)
Power Supply	115V / 60Hz
Rated Current	8.4A
Rated Input Power	970W
Refrigerant	R410A
Coverage Area	Up to 300 Sq. Ft.
Temperature Range	62.5°F - 86°F
Product Dimensions (W x D x H)	11.81" x 13.86" x 29.76" (30cm x 35.2cm x 75.6cm)
Product Weight	57.32 lbs
Material	ABS Plastic
Filter Type	Washable

9. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact the seller/manufacturer directly. Keep your proof of purchase for any warranty claims.
For further assistance, please visit the ZOKOP official website or contact their customer service department.

© 2024 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B093SQ2KBR

More documents and user manuals: **https://manuals.plus/**