Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DAVITU OS-757IV, OS-777

DAVITU Remote Control User Manual

For OSIM iMedic Chair Massage Models OS-757IV and OS-777

Introduction

This manual provides comprehensive instructions for the proper use, setup, operation, and maintenance of your DAVITU remote control for OSIM iMedic Chair Massage models OS-757IV and OS-777. Please read this manual thoroughly before operating the device to ensure safe and effective use.

Product Overview



Figure 1: Front View of Remote Control (Closed)

This image displays the front of the DAVITU remote control in its closed state. Key features visible include the digital display, the 'POWER' button, 'MASSAGE' and 'SHOULDER POSITION ADJUSTMENT' controls, 'FOOTREST' and 'RECLINING' adjustments, and dedicated buttons for 'HEALTHCARE PROGRAMS' (1-5) and 'WELL-BEING PROGRAMS' (Morning, Nighttime, Seat). The wired connection is also visible on the right side.



Figure 2: Front View of Remote Control (Open)

This image shows the DAVITU remote control with its side panel opened, revealing additional manual selection mode buttons. These include controls for 'KNEADING', 'HUMAN ROLLER', 'TAPPING', 'RHYTHM ACUPRESSURE', 'WIDTH ADJUSTMENT', 'LOWER BODY STRENGTH ADJUSTMENT', and specific controls for 'LEGS', 'SEAT', and 'LEGS & SEAT' massage areas. The 'BACK VIBRATION ON/OFF' button is also visible.



Figure 3: Back View of Remote Control
This image displays the back of the DAVITU remote control. A white sticker with the number "02005877" is visible, likely a serial or part number. The inscription "MADE IN JAPAN" is also present at the bottom of the remote's casing.

Setup

1. **Unpacking:** Carefully remove the remote control from its packaging. Inspect for any signs of damage.

2. **Connection:** Locate the dedicated remote control port on your OSIM iMedic Chair Massage (models OS-757IV or OS-777). Insert the remote control's cable connector firmly into this port. Ensure the connection is secure to prevent intermittent operation.
3. **Initial Power-Up:** Once connected, the remote control should receive power from the massage chair. The display may illuminate, indicating it is ready for use.

Operating Instructions

General Controls

- **POWER Button:** Press the **POWER** button (yellow, located top-left) to turn the massage chair on or off.
- **Shoulder Position Adjustment:** Use the **UP** and **DOWN** arrow buttons (red, top-right) to adjust the shoulder massage position vertically.
- **Footrest Adjustment:** Use the **UP** and **DOWN** arrow buttons under 'FOOTREST' to adjust the footrest position.
- **Reclining Adjustment:** Use the **UP** and **DOWN** arrow buttons under 'RECLINING' to adjust the chair's recline angle.

Healthcare Programs

Select from the following pre-programmed healthcare routines by pressing the corresponding numbered button:

1. **1: Fullbody Relief:** A comprehensive massage targeting the entire body.
2. **2: Stiff Shoulders:** Focuses on relieving tension in the shoulder area.
3. **3: Lower Back Tension:** Designed to alleviate discomfort in the lower back.
4. **4: Legs & Hips Fatigue:** Targets fatigue in the legs and hip regions.
5. **5: Acupressure:** Applies pressure to specific points for therapeutic benefits.

Well-being Programs

Choose a program tailored to specific times of day or areas:

- **Morning:** A revitalizing massage program.
- **Nighttime:** A relaxing program to aid in winding down.
- **Seat:** Focuses massage specifically on the seat area.

Manual Selection Mode (Refer to Figure 2)

Open the side panel of the remote control to access advanced manual settings:

- **Massage Techniques:**
  - **Kneading:** Simulates the action of hands kneading muscles.
  - **Human Roller:** Mimics the feel of human thumbs rolling along the back.
  - **Tapping:** Provides a rapid, percussive massage.
  - **Rhythm Acupressure:** Combines rhythmic tapping with acupressure.
- **Width Adjustment:** Use the **NARROW**, **MEDIUM**, and **WIDE** buttons to adjust the width of the massage rollers.
- **Lower Body Strength Adjustment:** Use the **LOW**, **MEDIUM**, and **HIGH** buttons to control the intensity of the lower body massage.
- **Specific Area Massage:** Buttons for **LEGS**, **SEAT**, and **LEGS & SEAT** allow you to target specific lower body areas.
- **Cancellation of Back Vibration:** Press the dedicated button to turn off the back vibration function.

Maintenance

- **Cleaning:**

  To clean the remote control, gently wipe the surface with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

- **Storage:**

  When not in use, store the remote control in a clean, dry place away from direct sunlight, extreme temperatures, and high humidity. Avoid placing heavy objects on the remote or tangling its cable.

- **Cable Care:**

  Regularly inspect the remote control cable for any signs of wear, fraying, or damage. If any damage is observed, discontinue use and contact customer support for assistance.

Troubleshooting

If you encounter issues with your DAVITU remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote control is unresponsive.	Loose cable connection.	Ensure the remote control cable is securely plugged into the massage chair's port.
Display is blank or flickering.	Insufficient power from the chair; faulty connection.	Check the chair's power supply. Re-seat the remote control cable. If the issue persists, contact support.
Specific buttons do not work.	Button malfunction; internal wiring issue.	Ensure no debris is lodged around the button. If the issue persists, the remote may require professional inspection or replacement.
Massage chair does not respond to remote commands.	Remote not properly connected; chair power off.	Verify the remote is fully connected and the massage chair is powered on.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Product Name	DAVITU Remote Control
Compatible Models	OSIM iMedic Chair Massage OS-757IV, OS-777
Use	Universal (for specified OSIM models)
Wireless Communication	RF (Radio Frequency)
Support App	No
Channel	1

Feature	Detail
Frequency	433 MHz
Material	Other (as per manufacturer)
Number of Pieces	1
Manufacturer	DAVITU
Part Number	DVT-6633DADC1313872EC3CCFA61D2123252

Warranty and Support

Specific warranty information for this DAVITU remote control is not provided in the product details. Please refer to the original purchase documentation or contact your retailer for warranty terms and conditions.

For technical support or inquiries regarding your DAVITU remote control, please contact the seller or manufacturer directly. Contact information may be available on your purchase receipt or the product packaging.

© 2023 DAVITU. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0957STL3L

More documents and user manuals: **https://manuals.plus/**