Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Giochi Preziosi MCN182

Mickey & Minnie Scooter with Side-Car Instruction Manual

Model: MCN182 | Brand: Giochi Preziosi

Introduction

Welcome to the world of Mickey & Minnie adventures! This set includes a vibrant scooter with a detachable side-car, an articulated Minnie figure, and an accessory. Designed for imaginative play, this toy allows children to create their own exciting stories with Minnie and Figaro.
This manual provides essential information for the safe and proper use of your new toy. Please read it carefully and retain it for future reference.

Important Safety Information

WARNING:

- Not suitable for children under 36 months (3 years) due to small parts.
- Contains small parts that may be ingested or inhaled. Choking hazard.
- Colors and details of the contents may vary from those shown on the packaging.
- Before giving the toy to a child, remove all unnecessary elements such as packaging, ties, and fasteners.
- Always supervise children during play.

Product Overview

The Mickey & Minnie Scooter with Side-Car set includes the following components:

- 1 x Minnie Scooter
- 1 x Detachable Side-Car
- 1 x Articulated Minnie Figure (approx. 7.5 cm tall with 4 points of articulation)
- 1 x Figaro Figure (included as an accessory within the side-car)



Image: The complete Minnie Scooter with Side-Car set, including the packaging, Minnie figure on the scooter, and Figaro in the side-car.



Image: The product as it appears in its retail packaging, showcasing the scooter, side-car, and figures.

Setup

This toy requires no assembly. It is ready for play right out of the box after removing all packaging materials.

1. Carefully remove the toy from its packaging.
2. Dispose of all packaging materials, including plastic ties and cardboard inserts, safely and responsibly.
3. Ensure all small parts are accounted for and not left within reach of very young children.

Operating Instructions

Using the Scooter and Side-Car:

- Place the Minnie figure onto the scooter. Her hands can grip the handlebars for a secure fit.
- The side-car can be easily attached to and detached from the scooter. Simply align the connection points and push or pull gently.
- Place the Figaro figure inside the side-car for joint adventures with Minnie.
- Push the scooter and side-car along smooth surfaces for imaginative play.



Image: Minnie figure positioned on the scooter with Figaro in the attached side-car, ready for play.

Image: Illustration demonstrating how the side-car can be detached and showing a small storage compartment.

Articulated Figure:

- The Minnie figure has 4 points of articulation, allowing for various poses and interactive play. Gently move her arms and legs to position her as desired.



Image: A detailed close-up of the Minnie figure, highlighting her articulated features and design.



Image: A detailed close-up of the Figaro figure, showing his design and how he fits into the side-car.

Maintenance

- To clean the toy, wipe it with a damp cloth and mild soap. Do not immerse in water.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the plastic.
- Store the toy in a clean, dry place away from direct sunlight and extreme temperatures to prevent fading or warping.

Troubleshooting

If you encounter any issues with your Mickey & Minnie Scooter with Side-Car, please consider the following:

- **Figures not fitting:** Ensure the figures are correctly oriented and gently pushed into their designated spots on the scooter or side-car.
- **Side-car detachment issues:** Check for any obstructions or debris in the connection mechanism. Ensure you are applying gentle, even pressure when attaching or detaching.
- **General wear and tear:** This is a toy designed for active play. Minor scuffs or scratches are normal over time.

For further assistance, please contact Giochi Preziosi customer support.

Specifications

Feature	Detail
Model Number	MCN182
Brand	Giochi Preziosi
Product Dimensions (L x W x H)	21.6 x 11.4 x 19.1 cm (8.5 x 4.5 x 7.5 inches)
Weight	310 grams (0.68 lbs)
Manufacturer Recommended Age	3 years and up
Main Material	Plastic
Assembly Required	No
Batteries Required	No
Components Included	Minnie Vehicle & 7.5 cm Articulated Figure
Number of Pieces	1 (set includes multiple items, but counted as 1 unit)



Image: Diagram illustrating the product dimensions (length and height) of the packaged toy.

Warranty and Support

For information regarding warranty, returns, or customer support, please refer to the contact details provided on the product packaging or visit the official Giochi Preziosi website. Keep your purchase receipt as proof of purchase.

© 2024 Giochi Preziosi. All rights reserved. Disney characters are trademarks of Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B096V6RMJF

More documents and user manuals: **https://manuals.plus/**