Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic FV-0511VF1

Panasonic WhisperFit FV-0511VF1 Bathroom Exhaust Fan User Manual

Model: FV-0511VF1 | Brand: Panasonic

1. Safety Information

Read and understand all instructions before beginning installation. Failure to follow these instructions may result in electrical shock, fire, property damage, or personal injury.

- Always disconnect power at the service panel before working on the fan.
- Installation must comply with all local electrical codes and standards.
- This fan is intended for general ventilating use only. Do not use to exhaust hazardous or explosive materials and vapors.
- Ensure wiring connections are secure and properly insulated.
- Wear safety glasses and gloves during installation.
- Do not install this fan in a ceiling with less than 5-5/8 inches of clearance.

2. Product Overview

The Panasonic WhisperFit FV-0511VF1 is a retrofit ceiling mount bathroom exhaust fan designed for quiet and efficient ventilation. It features a DC/ECM motor and SmartFlow technology for optimal performance.

Key Features:

- **Pick-A-Flow™ Speed Selector:** Allows selection of 50, 80, or 110 CFM (Cubic Feet per Minute) airflow.
- **Quiet Operation:** Engineered for low noise levels, as low as 0.8 Sones.
- **Flex-Z Fast™ Bracket:** Simplifies installation from below the ceiling.
- **Low Profile Housing:** 5-5/8 inch depth fits in 2x6 joist size or larger.
- **Energy Star Certified:** High efficiency for reduced energy consumption.

Product Dimensions:



Image: The fan unit with key dimensions labeled. The face measures 13 inches by 13 inches. The housing is 10.25 inches by 10.25 inches with a depth of 5.62 inches. A duct adapter is shown, compatible with 4-inch or 3-inch ducts. The unit weighs 9.5 lbs.

3. Installation Instructions

The WhisperFit FV-0511VF1 is designed for easy retrofit installation from below the ceiling. Always ensure power is disconnected before starting.

3.1 Prepare the Opening

1. Locate the desired installation area in the ceiling. Ensure there is sufficient clearance (minimum 5-5/8 inches depth) and no obstructions.
2. Cut an opening in the ceiling drywall to match the fan's housing dimensions (approximately 10.25 inches x 10.25 inches).

3.2 Install Flex-Z Fast™ Bracket



Image: A pair of gloved hands installing the Flex-Z Fast bracket into a rectangular opening in a ceiling. The bracket is designed to expand and secure the fan housing from below the ceiling, simplifying installation without attic access.

3. Insert the Flex-Z Fast bracket through the ceiling opening.
4. Extend the bracket arms and secure them to the ceiling joists using appropriate fasteners. The bracket is designed to fit between joists and provide a stable mounting point.

3.3 Ducting and Electrical Connections

5. Connect the appropriate ductwork (4-inch or 3-inch with adapter) to the fan's exhaust port. Ensure a tight seal to prevent air leakage.
6. Route electrical wiring to the fan's junction box. Make all electrical connections according to the wiring diagram provided in the full manual and local electrical codes.
7. Secure the fan housing to the Flex-Z Fast bracket.

3.4 Install Grille

8. Attach the fan grille to the housing. Ensure it is securely fastened and flush with the ceiling.

4. Operating Instructions

4.1 Pick-A-Flow™ CFM Selection

The FV-0511VF1 features a Pick-A-Flow™ switch, allowing you to select the desired airflow (CFM) for your bathroom size. This switch is located inside the fan housing and should be set during installation or maintenance.

- **50 CFM:** Suitable for smaller bathrooms (50-79 sq. ft.).
- **80 CFM:** Ideal for medium-sized bathrooms (80-99 sq. ft.).
- **110 CFM:** Recommended for larger bathrooms (100+ sq. ft.).



Image: A chart illustrating the relationship between CFM (Cubic Feet per Minute) and room size. It recommends 50-79 CFM for small rooms, 80-99 CFM for medium rooms, and 100+ CFM for large rooms.

4.2 Fan Operation

Once installed and the CFM setting is selected, the fan operates via a standard wall switch (not included). Turn the switch ON to activate the fan and OFF to deactivate it.

4.3 Noise Level (Sones)

The WhisperFit FV-0511VF1 is designed for quiet operation. The noise level varies with the selected CFM:

- **50 CFM:** Approximately 0.3 Sones
- **110 CFM:** Approximately 0.8 Sones



Image: A bar chart illustrating Sones levels and their corresponding sound comparisons. It shows that less than 1 Sone is "Whisper quiet," 1 Sone is a "Running Fridge," 2 Sones is a "Quiet office," 3 Sones is "Conversation," 4 Sones is "TV noise," and 5 Sones is a "Busy restaurant."

5. Maintenance

Regular cleaning and maintenance will ensure optimal performance and longevity of your fan.

5.1 Cleaning the Grille

1. Turn OFF power to the fan at the service panel.
2. Gently pull down the grille to detach it from the fan housing.
3. Wash the grille with a mild detergent and water. Rinse thoroughly and allow to dry completely.
4. Reattach the dry grille to the fan housing.

5.2 Cleaning the Fan Motor and Housing

5. Turn OFF power to the fan at the service panel.
6. Remove the grille as described above.
7. Carefully wipe down the fan blades and interior of the housing with a damp cloth. Do not allow water to enter the motor.
8. Ensure all components are dry before restoring power and reattaching the grille.

6. Troubleshooting

Problem	Possible Cause	Solution
Fan does not operate.	No power, loose wiring, faulty switch.	Check circuit breaker. Verify all wiring connections. Test or replace wall switch.
Fan is noisy.	Dirty fan blades, loose mounting, duct obstruction.	Clean fan blades and housing. Ensure fan is securely mounted. Check ductwork for obstructions.
Poor ventilation.	Incorrect CFM setting, duct obstruction, fan too small for room.	Verify CFM setting is appropriate for room size. Check ductwork for obstructions. Consider a higher CFM fan if room size exceeds recommendations.

7. Specifications

Model Name	WhisperFit DC
Model Number	FV-0511VF1
Brand	Panasonic
Air Flow Capacity	50-80-110 CFM (selectable)
Noise Level	0.3 - 0.8 Sones
Power Source	Corded Electric
Voltage	120 Volts
Wattage	15 watts

Motor Type	Brushless DC
Installation Type	Ceiling Mount (Retrofit)
Housing Depth	5-5/8 inches
Product Dimensions	13"D x 13"W x 5.6"H
Item Weight	9.08 pounds
Certifications	Energy Star, UL

8. Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the official Panasonic website or contact their customer service department. Keep your proof of purchase for warranty claims.
Online Support: Visit Panasonic Ventilation Fans

© 2024 Panasonic. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0973N9G21

More documents and user manuals: **https://manuals.plus/**