Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iGPSPORT BH50

iGPSPORT BH50 Silicone Computer Case User Manual

For iGS50E GPS Bike Computer

1. Introduction

The iGPSPORT BH50 Silicone Computer Case is designed to provide comprehensive protection for your iGS50E GPS bike computer. Crafted from high-tensile silicone material, this case offers a soft yet durable barrier against dust, drops, and everyday wear, ensuring the longevity and pristine condition of your device.



Figure 1: iGPSPORT BH50 Silicone Computer Case. A black silicone protective case designed for the iGS50E GPS bike computer, featuring precise cutouts for buttons and ports, and a snug fit for comprehensive device protection.

2. Product Features

- **High Tensile Silicone Material:** Provides excellent elasticity and durability.
- **All-Inclusive Design:** Offers 360-degree protection for the iGS50E device.
- **Dust-Proof:** Helps prevent dust and debris from entering the device.
- **Anti-Drop:** Absorbs impact from accidental drops, reducing damage risk.
- **Precise Cutouts:** Ensures full access to all buttons and ports without removing the case.

3. Setup Instructions

Follow these steps to properly install the BH50 Silicone Computer Case onto your iGS50E GPS bike computer:

1. **Prepare Your Device:** Ensure your iGS50E GPS bike computer is clean and free of any dust or debris before installation.
2. **Align the Case:** Gently align the iGS50E device with the opening of the silicone case. Ensure the button cutouts on the case match the buttons on your device.
3. **Insert the Device:** Carefully push the iGS50E into the silicone case. Start from one end and work your way around, ensuring a snug fit.
4. **Adjust for Fit:** Once the device is fully inside, gently adjust the edges of the silicone case to ensure it sits flush and securely around the iGS50E, covering all exposed areas while leaving the screen and necessary ports accessible.
5. **Verify Button Functionality:** Press each button on your iGS50E through the case to confirm they are fully functional and responsive.

4. Operating with the Case

The iGPSPORT BH50 Silicone Computer Case is designed to be a protective layer for your iGS50E and does not interfere with its normal operation. Once installed, you can use your iGS50E GPS bike computer as usual. The case provides enhanced grip and protection during your rides.

- All buttons remain accessible and functional.
- Charging ports and mounting points are not obstructed.
- The screen remains fully visible and usable.

5. Maintenance and Care

To ensure the longevity and appearance of your iGPSPORT BH50 Silicone Computer Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly and allow to air dry completely before re-installing on your device.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemicals, as these can damage the silicone material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.
- **Inspection:** Periodically inspect the case for any signs of wear or damage. While durable, extreme impacts can cause damage.

6. Troubleshooting

This section addresses common concerns you might encounter with your silicone computer case.

- **Case Does Not Fit Properly:** Ensure you have the correct model case for your iGS50E device. The BH50 case is specifically designed for the iGS50E. Re-check the alignment during installation.
- **Buttons Are Stiff or Unresponsive:** Verify that the case is correctly aligned and not obstructing the buttons. Gently adjust the case around the buttons. If the issue persists, temporarily remove the case to confirm the device buttons are

functioning correctly without the case.

- **Case Appears Dirty or Stained:** Refer to the "Maintenance and Care" section for cleaning instructions. Regular cleaning can prevent buildup.

7. Specifications

Feature	Detail
Model Number	BH50
Material	High Tensile Silicone
Compatibility	iGS50E GPS Bike Computer
Item Weight	0.704 ounces (approximately 20 grams)
Package Dimensions	4.45 x 2.83 x 1.02 inches
Color	Black (other colors may be available separately)

8. Warranty and Support

For specific warranty information or technical support regarding your iGPSPORT BH50 Silicone Computer Case, please refer to the official iGPSPORT website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

iGPSPORT Official Website: www.igpsport.com

© 2023 iGPSPORT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097H2Z8HP

More documents and user manuals: **https://manuals.plus/**