Manuals+
Q & A | Deep Search | Upload

T-WOLF Q5

T-Wolf Q5 Wireless Optical Mouse User Manual

Model: Q5

1. Introduction

Thank you for choosing the T-Wolf Q5 Wireless Optical Mouse. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new wireless mouse. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.
The T-Wolf Q5 is a wireless optical mouse designed for use with PCs and laptops, offering reliable connectivity and comfortable usage.

2. Package Contents

Please check the package contents to ensure all items are present:

- T-Wolf Q5 Wireless Optical Mouse
- USB Receiver (stored inside the mouse battery compartment)
- User Manual (this document)
- (Batteries are not typically included and must be purchased separately)

3. Setup Guide

1. **Install Batteries:**

   Locate the battery compartment on the underside of the mouse. Slide the battery cover open. Insert two AAA batteries (not included) according to the polarity indicators (+/-) inside the compartment. Close the battery cover securely.

Image: The underside of the T-Wolf Q5 mouse, showing the open battery compartment ready for battery insertion and the USB receiver slot.

2. **Connect USB Receiver:**

   The USB receiver is typically stored inside the battery compartment for safekeeping. Gently remove the USB receiver. Plug the USB receiver into an available USB port on your computer or laptop.

3. **Power On the Mouse:**

   Locate the power switch on the underside of the mouse. Slide the switch to the "ON" position. The mouse should now be powered on and ready for use.

4. **Automatic Connection:**

   Your computer should automatically detect and install the necessary drivers for the mouse. This is usually a plug-and-play process and does not require manual driver installation. Once installed, the mouse cursor will respond to your movements.

4. Operating Instructions

The T-Wolf Q5 Wireless Optical Mouse features standard mouse functionalities:

- **Left Click Button:** Used for selecting items, opening files, and executing commands.
- **Right Click Button:** Used for accessing context menus and additional options.
- **Scroll Wheel:** Used for scrolling through documents and web pages. It can also function as a middle click button.
- **DPI Adjustment Button (if present):** Some models may include a button near the scroll wheel to adjust the mouse's sensitivity (DPI). Pressing this button cycles through different DPI settings.

Image: An angled top view of the T-Wolf Q5 wireless optical mouse, highlighting its ergonomic design and button layout.

Power Saving Mode

To conserve battery life, the mouse will automatically enter a power-saving sleep mode after a period of inactivity. To wake the mouse, simply move it or click any button.

5. Maintenance

- **Cleaning:**

  To clean the mouse, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials, as these can damage the surface.

- **Battery Replacement:**

  When the mouse performance degrades or it stops responding, it's likely time to replace the batteries. Follow the battery installation steps in Section 3.1.

- **Storage:**

  If you plan not to use the mouse for an extended period, it is recommended to turn off the power switch and remove the batteries to prevent leakage.

6. Troubleshooting

Problem	Possible Solution

Problem	Possible Solution
Mouse not responding	• Ensure the mouse is powered on. • Check battery levels and replace if necessary. • Ensure the USB receiver is securely plugged into a working USB port. • Try plugging the USB receiver into a different USB port. • Restart your computer.
Erratic cursor movement	• Clean the optical sensor on the underside of the mouse. • Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). • Check for interference from other wireless devices.
Short battery life	• Use high-quality alkaline batteries. • Ensure the mouse is turned off when not in use for extended periods.

7. Specifications

Feature	Detail
Brand	T-WOLF
Model Number	Q5
Connectivity Type	Wireless (2.4GHz)
Movement Detection	Optical
Compatible Devices	Personal Computer, Laptop
Operating System Support	Linux, Windows 7, Windows XP (and newer versions)
Color	Blue and Black
Material	Mixed
Item Weight	140 g
Power Source	Batteries (2x AAA, not included)

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

Related Documents - Q5

	T-WOLF Q13 Wireless Gaming Mouse User Manual User manual for the T-WOLF Q13 Wireless Gaming Mouse, detailing its features, specifications, and FCC compliance information.

	[T-WOLF T70 Tri-Mode Mechanical Keyboard User Manual and Specifications] Detailed specifications, features, and operating instructions for the T-WOLF T70 Tri-Mode Mechanical Keyboard, supporting Bluetooth, 2.4G wireless, and Type-C wired connections.
	[Quick Guide: R-NZ Wireless Slim Mouse - Model K:43-055-746] Concise guide for the R-NZ Wireless Slim Mouse (Model K:43-055-746), covering parts, package contents, features, installation, and recycling. Includes technical specifications like DPI settings and operating range.
	[T'nB Rechargeable Wireless Mouse Bluetooth + USB 2.4GHz User Manual] User guide for the T'nB MWGRADIENT rechargeable wireless mouse, detailing setup via USB 2.4GHz and Bluetooth for Windows and Mac, along with essential safety information.
	[Mad Catz R.A.T. 8+ ADV Gaming Mouse Quick Start Guide] A quick start guide for the Mad Catz R.A.T. 8+ ADV gaming mouse, detailing product information, button functions, and adjustments.



AULA

Key Layout

Product specifications

- Mouse size: 125×65×41±0.2mm
- Product weight: about 90g
- Number of keys: 7
- Connection mode: Bluetooth/2.4G/wired mode
- Operating voltage/current: DC5V==100mA
- Charging interface: TYPE-C
- CPI resolution: 800 red - 1200 green (default) - 1600 blue - 2400 purple yellow 6000 monochrome breathing.
- Battery capacity: 800mAh
- Return rate: 500HZ by default
- Operating platform: Windows XP/Vista/7/8/10, working normally in windows

AULA

Installation and operation instructions

- Additional bottom mode switch: three gear toggle switch. Turn it to Bluetooth mode 1/2.Also light, and turn it to the middle When the power is off/unplugged, the 2.4G mode is red.
- The bottom button is the mode switch button 2.4G/Bluetooth channel 1/Bluetooth channel 2.
- The overall backlight of the low voltage indicator light flashes slowly, indicating that the overall backlight is always on red when charging, and the indicator light is full/return to the current shortcut
- 1. 2.4G mode Plug and Play: 2.4G code matching mode, press left, middle and right for 2 seconds, and the yellow lamp flashes. The first lamp at the bottom is red 2. Bluetooth mandatory code matching mode Press left, middle and right for 2 seconds, and the yellow lamp flashes. The second lamp at the bottom is the second.Wired indicator at the bottom is blue. 3. Wired mode Plug and Play.
- The corresponding indicator light at the bottom is: when the toggle switch is turned down, it is in 2.4G state, the first light is on, and the bottom Press the key to disable the function. The middle part is to turn off the power. When the toggle switch is turned to the middle, it is turned off. When it is turned up, it can freely indicate Bluetooth channel 1 and Bluetooth channel 2, which can be switched through the bottom button and cannot be switched to the A bottom indicator.
- Wireless receiver code matching: Long press the left button, the middle key and right middle key together for 3 seconds to enter forced code matching.The overall backlight on the front of the mouse flashes yellow, and the first indicator light on the bottom is red. The receiver is in code matching mode. When the mouse goes to sleep, Click any key of the mouse again to wake up and continue code matching. When the receiver is inserted,The indicator flashes for 2s and then enters the current light effect.After it corresponds to the DPI color. When the receiver is not inserted in 2.4G mode, the mouseAfter the current light effect is ce ased, the mouse enters the sleep state. Click any key of the mouse and right to wake up the mouse. When it is on for 1s The headlight effect mouse cannot search the receiver and goes to sleep. Bluetooth mode: Slow flash blue for 2s and then enters the current light effect. After 3 minutes, it will enter back, and the device is not connected successfully, and it enters into deep state.
- Mouse sleep/wake-up mode: It1 enters the first level sleep, inove the mouse/click any key to wake up;
  After 60s, it will enter level 2 sleep, move or press the key to wake up;
  10 minutes into deep sleep mode. When the computer goes into hibernation, the mouse also goes into hibernation.
  Deep sleep, You need to wake up the mouse itself with any key on a single mouse and click any key Press the key to wake up the computer.

AULA

Certificate Wolf spider game mouse series: high quality products

Part name	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Plastic parts	×	○	×	○	○	○
Metal parts	×	○	○	○	○	○
Circuit board assembly	×	○	×	○	○	○
Cable	×	○	○	○	○	○

Remarks:

○=It means that the content of the toxic and harmful substance in all homogeneous materials of the component is below the limit specified in GB / T26245-2010 standard.

X = indicates that the content of the toxic and harmful substances in at least one homogeneous part of the component exceeds the limit specified in GB / T26245-2010 standard.

Service life of environmental protection:
According to the administrative measures for pollution control of electronic information products of the people's Republic of China, electronic information products sold within the territory of the people's Republic of China must.

AULA

Dear user

Dear users, thank you for your choice Brand products, in order to protect your legitimate rights and interests, better service for you, our company strictly in accordance with the people's Republic of China "microcomputer commodity repair, replacement and return responsibility provisions", to provide you with three guarantees after-sales service, product warranty instructions are as follows.

1. Since the date of purchase, under normal use, the product failure caused by poor electrical performance can be guaranteed for one year, but the damage caused by man-made damage (such as self disassembly, handling damage, bumping, soaking in water, improper input current and voltage, etc.) and damage caused by natural disasters (such as fire, flood, earthquake, rat damage, etc.) are not covered by this warranty.
2. The replacement of consumables (such as batteries, foot stickers, etc.) and accessories is not covered by the warranty card.
3. Please fill in all the columns in this warranty card truthfully and stamp it with the seal of the dealer.
4. Once lost, this warranty card will not be reissued. Please keep it properly.
5. This warranty card is only valid within the territory of the people's Republic of China.

AULA

User warranty card

Trade name	From the date of purchase Year Month Day	
Warranty period	Valid for 1 year	
Customer	Full name:	
	Telephone:	Postal code:
	Address:	
Dealer Name		Address:
	Telephone:	Postal code:

[AULA Wolf Spider SC100 Wireless Gaming Mouse User Manual]

Detailed user manual for the AULA Wolf Spider SC100 wireless gaming mouse, covering key layout, product specifications, installation, operation instructions, environmental protection certificate, and warranty information.