Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome HMAUBE213WT

iHome HMAUBE213WT BT True Wireless Earbuds XT12 User Manual

Model: HMAUBE213WT

Introduction

Thank you for purchasing the iHome HMAUBE213WT BT True Wireless Earbuds XT12. This manual provides comprehensive instructions to help you set up, operate, and maintain your new earbuds, ensuring optimal performance and longevity. Please read this manual thoroughly before use and retain it for future reference.

What's in the Box

- iHome HMAUBE213WT BT True Wireless Earbuds XT12 (Left and Right Earbuds)
- Charging Case
- USB Charging Cable
- User Manual (this document)



Image: The iHome HMAUBE213WT BT True Wireless Earbuds XT12, shown in white, with their compact charging case. The earbuds feature a sleek design with the iHome logo visible on each earbud and the case.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case acts as a portable power bank for your earbuds.

1. Place both earbuds into the charging case, ensuring they are correctly seated in their respective slots.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer USB port, wall adapter).
3. The indicator lights on the case and/or earbuds will illuminate to show charging status. Refer to the specific light patterns for full charge indication.
4. Once fully charged, disconnect the charging cable.

2. Pairing with a Bluetooth Device

The earbuds use Bluetooth 5.0 for wireless connectivity, offering a range of up to 10 meters (33 feet).

1. Ensure the earbuds are charged.
2. Open the charging case and remove both earbuds. They should automatically enter pairing mode.
3. On your Bluetooth-enabled device (smartphone, laptop, tablet), navigate to the Bluetooth settings.
4. Turn on Bluetooth.
5. Search for available devices. The earbuds should appear as "iHome XT12" or a similar name.
6. Select the earbuds from the list to initiate pairing.
7. Once paired, a confirmation sound or indicator light change may occur. The earbuds are now ready for use.
8. For subsequent uses, the earbuds should automatically connect to the last paired device when removed from the case and the device's Bluetooth is active.

Operating the Earbuds

The iHome XT12 earbuds feature touch controls for media playback and call management.

Media Control

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds (when not on a call).

Maintenance

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners, alcohol, or chemical solvents. Avoid getting moisture into any openings.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures and direct sunlight.

- **Water Resistance:** These earbuds are **NOT water resistant**. Avoid exposure to water, sweat, rain, or any liquids to prevent damage.

Troubleshooting

Problem	Possible Solution
Earbuds not turning on/charging	Ensure the charging case is charged. Verify earbuds are correctly seated in the charging case. Clean the charging contacts on both earbuds and inside the case with a dry cotton swab. Try a different USB charging cable and power source.
Only one earbud playing audio	Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them. Ensure both earbuds are paired correctly. If not, unpair from your device and re-pair both earbuds. Check the audio balance settings on your connected device.
Earbuds not pairing with device	Ensure Bluetooth is enabled on your device. Make sure the earbuds are in pairing mode (usually indicated by a flashing light). Forget/remove the earbuds from your device's Bluetooth list and attempt to pair again. Move the earbuds closer to your device (within 10 meters). Restart your Bluetooth device.
Poor sound quality or disconnections	Ensure the earbuds are within the 10-meter Bluetooth range of your device. Minimize obstacles between the earbuds and your device. Check for interference from other wireless devices. Ensure earbuds are fully charged.

Specifications

- **Model Name:** iHome XT12 (HMAUBE213WT)
- **Connectivity Technology:** Wireless (Bluetooth)
- **Wireless Communication Technology:** Bluetooth 5.0
- **Bluetooth Range:** 10 Meters (33 feet)
- **Control Type:** Media Control
- **Control Method:** Touch
- **Ear Placement:** In Ear
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Water Resistance Level:** Not Water Resistant
- **Included Components:** Earbuds, Charging Case
- **Manufacturer:** IHOME
- **UPC:** 805112076932
- **Item Weight:** 7 ounces

- **Package Dimensions:** 6.97 x 3.78 x 2.01 inches

Safety Information

Please read and follow these safety guidelines to prevent damage to your earbuds or personal injury:

- Do not expose earbuds or charging case to extreme temperatures, direct sunlight, or high humidity.
- Do not immerse in water or any liquids. These earbuds are not water resistant.
- Avoid dropping, impacting, or disassembling the device.
- Do not use damaged charging cables or power adapters.
- Keep out of reach of children and pets.
- Prolonged exposure to loud volume levels can cause hearing damage. Adjust volume to a safe level.
- Use caution or temporarily discontinue use in potentially hazardous situations, such as driving or cycling, where the ability to hear ambient sounds is crucial.

Warranty and Support

Specific warranty details are typically provided with your purchase documentation or on the manufacturer's official website. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact iHome customer service. Refer to the iHome official website for the most current contact information and support resources.
You can visit the iHome Store on Amazon for more information:iHome Store

© 2023 iHome. All rights reserved.
iHome is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BK4N95J

More documents and user manuals: **https://manuals.plus/**