Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO HDKF-001

TRESKO Foldable Pet Crate Instruction Manual

Model: HDKF-001 | Size: 62 x 45 x 52 cm

Brand: TRESKO

1. Introduction

This manual provides instructions for the safe and proper use, assembly, and maintenance of your TRESKO Foldable Pet Crate. Please read all instructions carefully before use and retain this manual for future reference.

The TRESKO pet crate is designed to provide a secure and comfortable space for your pet, suitable for home use, travel, and transport. It features a robust metal wire construction, dual secure doors, a removable tray for easy cleaning, and a foldable design for convenient storage.



Image 1.1: General view of the TRESKO Foldable Pet Crate.

2. Product Features

- **Robust Construction:** Made from thick, durable metal wire with an anti-rust coating to ensure long-lasting use and prevent collapse.
- **Dual Doors:** Features two foldable doors (front and side) for flexible access, making it easier for your pet to enter and exit.
- **Secure Latches:** Each door is equipped with double latches to ensure maximum security and prevent accidental opening.
- **Removable Bottom Tray:** Includes a waterproof and scratch-resistant plastic bottom tray that can be easily removed for cleaning and hygiene.
- **Foldable Design:** An innovative folding mechanism allows the crate to be quickly collapsed for effortless storage and portability.
- **Integrated Carry Handle:** A convenient carry handle is included for easy lifting and transport of the folded or

assembled crate.



Image 2.1: Illustration of the crate's robust construction, anti-rust grid, and durable bottom tray.



Image 2.2: Details of the secure double closure mechanism and rounded edges for pet safety.

3. Setup and Assembly

The TRESKO pet crate is designed for quick and easy setup. It arrives in a folded state.

1. **Unfold the Crate:** Carefully lift the crate from its folded position. The side panels will naturally expand.
2. **Secure the Sides:** Bring the side panels up and connect them to the top panel using the integrated hooks or latches. Ensure all connections are secure.
3. **Position the Tray:** Slide the removable plastic tray into the bottom of the crate. Ensure it sits flat and securely within the base.
4. **Check Doors:** Verify that both the front and side doors open and close smoothly, and that the double latches engage properly.



Image 3.1: The crate in its folded state, illustrating its compact storage and dimensions.

4. Operating Instructions

4.1 Using the Doors

The crate features two doors for convenient access:

- **Opening:** Slide the double latches upwards and outwards to disengage them. Pull the door open.
- **Closing:** Push the door shut until it aligns with the frame. Slide the double latches inwards and downwards to secure the door. Ensure both latches are fully engaged.



Image 4.1: Close-up of the double latch mechanism on the crate door, ensuring secure closure.

4.2 Folding for Storage

To fold the crate for storage or transport:

1. Remove your pet and any accessories from the crate.
2. Remove the plastic bottom tray.
3. Disengage the hooks or latches connecting the side panels to the top panel.
4. Gently push the top panel downwards, allowing the side panels to collapse inwards.
5. Secure the folded crate with the integrated carry handle or any provided clips to prevent it from unfolding during transport.

5. Maintenance and Cleaning

Regular cleaning and maintenance will extend the life of your pet crate and ensure a hygienic environment for your pet.

- **Daily Cleaning:** Wipe down the metal surfaces with a damp cloth to remove dirt and pet hair.
- **Tray Cleaning:** The removable plastic tray can be easily pulled out for thorough cleaning. Wash it with mild soap and water, then rinse and dry completely before returning it to the crate.
- **Deep Cleaning:** Periodically, clean the entire crate with a pet-safe disinfectant. Ensure all surfaces are dry before allowing your pet back inside.
- **Inspection:** Regularly inspect the crate for any signs of damage, such as bent wires, loose latches, or cracks in the plastic tray. Replace damaged parts if necessary to maintain safety.



Image 5.1: The removable bottom tray facilitates easy and quick cleaning.

6. Troubleshooting

- **Crate not unfolding/folding smoothly:** Check for any obstructions or misaligned wires. Ensure all latches are disengaged when folding. Apply a small amount of silicone spray to hinges if movement is stiff.
- **Doors not closing securely:** Ensure the door is properly aligned with the frame. Check that the double latches are not bent and engage fully into their slots.
- **Tray does not fit:** Ensure the crate is fully assembled and squared. The tray should slide in easily. If it's warped, it may need replacement.
- **Pet escaping:** Verify that all doors are securely latched and that there are no gaps or damaged areas in the wire mesh.

7. Specifications

Feature	Detail
Model Number	HDKF-001
Product Dimensions (L x W x H)	62 x 45 x 52 cm
Material	Metal
Specific Product Uses	Indoor, Outdoor, Transport
Special Features	Waterproof, Foldable, Removable Tray, Secure
Weight	Approximately 1 kg

8. Warranty and Support

For information regarding returns, defective products, or damages, please refer to the retailer's return policy or contact their customer support directly. Typically, products can be returned within 30 days of receipt if you change your mind, and specific procedures apply for defective or damaged items.

© 2026 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09C2521NZ

More documents and user manuals: **https://manuals.plus/**